

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Vieta Pro](#) /

› [Vieta Pro Party 220 Portable Bluetooth Speaker User Manual](#)

Vieta Pro Party 220

Vieta Pro Party 220 Portable Bluetooth Speaker User Manual

Model: Party 220 (VM-HW455BK)

1. INTRODUCTION

Thank you for choosing the Vieta Pro Party 220 Portable Bluetooth Speaker. This powerful and versatile speaker is designed to deliver high-quality audio for various occasions, including parties, events, and karaoke sessions. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

The Vieta Pro Party 220 is a self-amplified portable speaker featuring advanced audio technology. It boasts 500W of powerful sound, Bluetooth 5.3 connectivity, Auracast technology, and a long-lasting 10-hour battery. Designed for portability, it includes an integrated handle and trolley-style wheels. Key features include:

- **500W RMS Sound Output:** Delivers robust and clear stereo sound with 2" tweeters and 8" woofers.
- **Bluetooth 5.3 with Auracast:** Ensures stable and fast wireless connections, allowing multiple Auracast-compatible speakers to connect simultaneously.
- **Karaoke Compatibility:** Includes a wireless microphone and supports additional microphones. Features LED lights that synchronize with music.
- **10-Hour Battery Life:** Enjoy extended music playback with the rechargeable battery.
- **Multiple Connectivity Options:** Mini Jack 3.5mm, AUX, Micro USB, USB MP3 player, and SD card slot.
- **True Wireless Stereo (TWS):** Connect two Party 220 speakers for an immersive stereo experience.
- **Portable Design:** Integrated handle and wheels for easy transport.



Image 2.1: The Vieta Pro Party 220 speaker highlighting its main features such as 500W power, Bluetooth 5.3, Auracast, app control, remote control, USB player, RGB LED lights, MicroSD reader, wireless microphone, and 10-hour battery life.

3. WHAT'S IN THE BOX

Upon unpacking, please ensure all items are present and in good condition:

- Vieta Pro Party 220 Portable Bluetooth Speaker
- Power Cable
- Wireless Microphone
- Remote Control
- User Manual (this document)

4. SETUP

4.1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided power cable to the speaker's power input and then to a suitable power outlet. The charging indicator will illuminate. Once fully charged, the indicator may change color or turn off, depending on the model.

A full charge provides up to 10 hours of continuous playback.



Image 4.1: The Vieta Pro Party 220 speaker in a home environment, illustrating its long battery life of up to 10 hours.

4.2. Powering On/Off

Locate the Power button on the speaker's control panel. Press and hold the Power button for a few seconds to turn the speaker ON or OFF.

5. OPERATING INSTRUCTIONS

5.1. Bluetooth Pairing

1. Turn on the Vieta Pro Party 220 speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light (usually blue).
2. Enable Bluetooth on your audio device (smartphone, tablet, computer).

3. Search for "Vieta Pro Party 220" in the list of available Bluetooth devices.
4. Select the speaker to pair. Once connected, the LED indicator will stop flashing and remain solid.

5.2. Auracast Technology

The Party 220 supports Auracast, allowing you to connect multiple compatible speakers (including other Party 220 units or different brands supporting Auracast) for a synchronized audio experience. Refer to the specific instructions for Auracast pairing, usually initiated via a dedicated button or through the Vieta Pro app (if available).

5.3. True Wireless Stereo (TWS) Pairing

To achieve a true stereo sound experience, you can pair two Vieta Pro Party 220 speakers:

1. Ensure both Party 220 speakers are turned on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the TWS button (if available) or follow the TWS pairing instructions in the speaker's specific controls.
3. The primary speaker will search for the secondary speaker. Once connected, you will hear an audible confirmation, and the LED indicators will reflect the TWS connection status.
4. Now, connect your audio device to the primary speaker via Bluetooth as described in section 5.1. Audio will play in stereo across both speakers.

5.4. Wired Connections (AUX, USB, MicroSD)

- **AUX Input:** Connect an external audio device using a 3.5mm audio cable to the AUX input port. The speaker will automatically switch to AUX mode or require manual selection via the Mode button.
- **USB Playback:** Insert a USB flash drive containing MP3 audio files into the USB port. The speaker will automatically detect and play the files. Use the control panel or remote to navigate tracks.
- **MicroSD Card Playback:** Insert a MicroSD card with MP3 audio files into the MicroSD slot. The speaker will automatically detect and play the files.

5.5. Karaoke Function and Wireless Microphone

The Party 220 comes with a wireless microphone for karaoke. Simply turn on the microphone, and it should automatically connect to the speaker. Adjust microphone volume using the dedicated controls on the speaker or remote control. The speaker also has inputs for additional wired microphones.



Image 5.5: A close-up view of the wireless microphone included with the Vieta Pro Party 220 speaker, ready for karaoke use.

5.6. LED RGB Lights

The speaker features dynamic RGB LED lights that can enhance your audio experience. Use the dedicated button on the control panel or the remote control to cycle through different light modes, synchronize them with the music, or turn them off.



Image 5.6: The Vieta Pro Party 220 speaker showcasing its vibrant RGB LED lighting feature.

5.7. Remote Control

The included remote control allows for convenient operation of the speaker from a distance. Functions typically include power, volume, track navigation, mode selection, EQ settings, and LED light control.

6. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use for extended periods.
- **Water Exposure:** While the speaker may have some resistance, avoid direct exposure to water or excessive moisture unless explicitly stated as waterproof.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Battery is depleted; Power cable not connected properly.	Charge the speaker; Ensure power cable is securely connected.
No sound	Volume too low; Incorrect input mode; Device not paired.	Increase volume on speaker and source device; Select correct input mode (Bluetooth, AUX, USB); Re-pair Bluetooth device.
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in pairing mode; Move device closer; Turn off other Bluetooth devices.
Microphone not working	Microphone off; Battery low in microphone; Volume too low.	Turn on microphone; Replace microphone batteries; Increase microphone volume.
TWS pairing fails	Speakers not in TWS pairing mode; Too far apart.	Ensure both speakers are in TWS pairing mode; Place speakers closer together.

8. SPECIFICATIONS



GRAN POTENCIA DE SONIDO

Image 8.1: The Vieta Pro Party 220 speaker, highlighting its powerful sound output.

Feature	Detail
Model Name	Party 220
Model Number	VM-HW455BK
Brand	Vieta Pro
Speaker Type	Outdoor, Portable, Self-amplified
Connectivity Technology	Bluetooth 5.3, AUX, USB, MicroSD
Wireless Communication	Bluetooth
Max Speaker Output Power	500 Watts (RMS)
Audio Output Mode	Stereo (with TWS)

Feature	Detail
Frequency Response	20 MHz
Power Source	Battery Powered
Battery Life	Up to 10 hours
Control Method	Remote Control, On-device buttons
Special Features	Anti-shock, USB Port, Shock resistant, Wireless speakers, Auracast, Karaoke, LED RGB lights
Compatible Devices	MP3 Player, Mobile, PC, DJ Mixer, Tablet, Television
Product Dimensions	33.7D x 30W x 70.5H cm
Item Weight	5 Kilograms
Material	Plastic
Color	Black

9. WARRANTY AND SUPPORT

The Vieta Pro Party 220 speaker comes with a limited warranty. Please refer to the warranty card included in your packaging for detailed terms and conditions. For technical support, troubleshooting assistance beyond this manual, or warranty claims, please contact Vieta Pro customer service through their official website or the contact information provided with your product documentation.

Please retain your proof of purchase for warranty purposes.