



[Manuals.plus](#) /

> [HOOOWOOO](#) /

> HOOOWOOO Ergonomic Office Chair Instruction Manual

HOOOWOOO Ergonomic Office Chair (ASIN: B0G2VJP8FF)

HOOOWOOO Ergonomic Office Chair Instruction Manual

Model: Ergonomic Office Chair (ASIN: B0G2VJP8FF)

INTRODUCTION

Thank you for choosing the HOOOWOOO Ergonomic Office Chair. This manual provides essential information for the proper assembly, operation, maintenance, and troubleshooting of your new chair. Please read these instructions carefully before assembly and retain them for future reference.

SETUP AND ASSEMBLY

Your HOOOWOOO Ergonomic Office Chair is designed for straightforward assembly. All necessary tools and hardware are included. It is recommended to assemble the chair on a soft, clean surface to prevent damage.

Assembly Steps:

- Unpack Components:** Carefully remove all parts from the packaging and lay them out. Verify that all components listed in the parts diagram (not provided in this manual, refer to packaging) are present.
- Attach Casters to Base:** Insert the five caster wheels into the holes at the end of each leg of the chair base. Push firmly until they click into place.
- Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled chair base. Ensure it is seated securely.
- Attach Seat Mechanism:** Align the seat mechanism with the pre-drilled holes on the underside of the seat cushion. Secure it using the provided screws and Allen wrench. Ensure the front of the mechanism faces the front of the seat.
- Attach Backrest:** Connect the backrest to the seat assembly using the provided screws. Ensure a firm and stable connection.
- Connect Seat to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the center hole of the seat mechanism aligns with the top of the gas lift. Press down firmly to secure.

After assembly, test all functions to ensure proper operation and stability before regular use.

OPERATING INSTRUCTIONS

The HOOOWOOO Ergonomic Office Chair offers several adjustments to customize your seating experience.

Chair Adjustments:

- **Height Adjustment:** To raise the seat, lift the lever located under the right side of the seat while taking your weight off the chair. To lower the seat, lift the lever while seated. Release the lever at your desired height.
- **Swivel Function:** The chair is designed to swivel 360 degrees, allowing for easy rotation and access to different areas of your workspace without needing to move the entire chair.
- **Mobility:** The smooth-rolling caster wheels allow for easy movement across various floor surfaces. Ensure the path is clear of obstructions to prevent damage to the wheels or floor.

CARE AND MAINTENANCE

Regular care will help maintain the appearance and longevity of your HOOOWOOO Ergonomic Office Chair.

Upholstery Care:

- **Suede Fabric:**
 - Regularly vacuum with a soft brush attachment to remove dust and loose particles.
 - For spills, blot immediately with a clean, dry cloth. Do not rub.
 - For stubborn stains, consult a professional upholstery cleaner or use a suede-specific cleaning product, testing on an inconspicuous area first.
 - Avoid direct sunlight to prevent fading.
- **PU Leather:**
 - Wipe clean with a damp cloth and mild soap solution. Dry immediately with a clean, soft cloth.
 - Avoid harsh chemicals, abrasive cleaners, or solvents, as these can damage the material.
 - Regularly wipe down to prevent dirt buildup.

General Maintenance:

- **Check Fasteners:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary to maintain stability.
- **Caster Wheels:** Clean caster wheels regularly to remove hair, dust, and debris that can impede smooth movement.
- **Gas Lift:** Do not attempt to disassemble or repair the gas lift cylinder. If it malfunctions, contact customer support.

TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Chair is unstable or wobbly.	Loose screws or improper assembly.	Check and tighten all screws and bolts, especially those connecting the seat, backrest, and mechanism to the base. Ensure the gas lift is fully seated in the base.
Difficulty adjusting seat height.	Gas lift malfunction or lever obstruction.	Ensure the height adjustment lever is fully engaged. If the gas lift is unresponsive, it may need replacement. Contact customer support.
Caster wheels do not roll smoothly.	Debris caught in wheels or damaged casters.	Turn the chair over and remove any hair, dust, or debris from the caster wheels. If wheels are damaged, they may need replacement.
Chair makes squeaking noises.	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone-based lubricant to moving parts or connection points if the noise persists. Avoid oil-based lubricants on plastic parts.

SPECIFICATIONS

Below are the general specifications for the HOOOWOOO Ergonomic Office Chair. Please note that manual measurements may have a slight error margin of +0.4" to 0.8".

- **Brand:** HOOOWOOO
- **Model:** Ergonomic Office Chair (ASIN: B0G2VJP8FF)
- **Upholstery Material:** Suede Fabric or PU Leather (Polyester & Polyester Blend)
- **Color (as reviewed):** Suede Fabric, brown
- **Weight Capacity:** 350 lbs
- **Product Dimensions (Overall):** 25"D x 27"W x 39"H (as per product data)
- **Detailed Dimensions (approximate):**
 - Backrest Height: 16.1"
 - Backrest Width: 18.9"
 - Armrest Length: 11.4"
 - Armrest Width: 3.4"
 - Armrest Height from Seat: 4.3"
 - Seat Depth: 20.1"
 - Seat Width: 19.7"
 - Overall Width (Base): 25.6" (side view), 27.4" (front view)
 - Seat Height Range: 19.1" - 22.1"
 - Overall Height Range: 36.4" - 39.4"

DIMENSION

Manual Measurement, Please Allow +0.4"-0.8" Error.

350 lbs
Weight Capacity



Image: Detailed dimensions and weight capacity of the HOOOWOOO Ergonomic Office Chair. The image displays side and front views of the chair with various measurements indicated by arrows, including backrest height (16.1"), armrest length (11.4"), seat depth (20.1"), armrest height (4.3"), overall width (25.6" and 27.4"), seat width (19.7"), armrest width (3.4"), seat height range (19.1"~22.1"), and overall height range (36.4"~39.4"). It also highlights a 350 lbs weight capacity.

WARRANTY INFORMATION

Specific warranty details for the HOOOWOOO Ergonomic Office Chair are not provided in this manual. For information regarding warranty coverage, terms, and conditions, please refer to the product packaging, the seller's website, or contact HOOOWOOO customer support directly.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a defective part, please contact the seller or HOOOWOOO customer service. Contact information can typically be found on the product packaging, the retailer's website, or the HOOOWOOO official website.