

[Manuals.plus](#) /

› [LUXOAK](#) /

› LUXOAK BMB014 Queen Floating Bed Frame with RGBW LED Lights - Instruction Manual

LUXOAK BMB014

LUXOAK BMB014 Queen Floating Bed Frame with RGBW LED Lights

Instruction Manual

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in injury or damage to the product.

- Keep all packaging materials away from children.
- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assembly should be performed by two adults.
- Do not overtighten screws or bolts during assembly.
- Place the bed frame on a flat, stable surface.
- Do not jump on the bed frame.
- The maximum weight capacity for this Queen size bed frame is 1000 lbs. Do not exceed this limit.
- Keep electrical components (LED lights, power adapter) away from water and moisture.

2. PACKAGE CONTENTS

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.


- Headboard Brackets (2)
- Side Rails (2)
- Center Support Beam (1)
- Support Legs (9)
- Metal Slats (Multiple)
- Hardware Pack (Screws, bolts, Allen wrench)

- RGBW LED Light Strip (1)
- LED Remote Control (1)
- Power Adapter for LED Lights (1)
- Instruction Manual (1)

3. ASSEMBLY INSTRUCTIONS

Assembly typically takes approximately 30 minutes with two people. No box spring is required for this bed frame.

1. **Prepare the Area:** Clear a spacious area for assembly. Lay out all components and hardware.
2. **Assemble Side Rails:** Attach the two side rails to the headboard brackets using the provided bolts and Allen wrench. Ensure they are securely fastened but do not overtighten.
3. **Install Support Legs:** Attach the 9 support legs to the designated points on the side rails and center support beam. Ensure all legs are oriented correctly for stability.
4. **Connect Center Support Beam:** Secure the center support beam between the two side rails. This beam provides crucial central support for the mattress.
5. **Place Metal Slats:** Lay the metal slats across the frame, fitting them into the designated slots. Ensure all slats are evenly spaced and securely seated. The frame features a noise-free design with integrated padding on the slats to prevent squeaking.
6. **Attach Mattress Slide Stoppers:** Install the mattress slide stoppers on the frame as indicated in the diagram to prevent the mattress from shifting.
7. **Install LED Light Strip:** Carefully attach the RGBW LED light strip to the underside of the bed frame. Ensure the adhesive is firm and the strip is positioned to illuminate the floor evenly. Connect the LED strip to the power adapter.
8. **Final Check:** Double-check all bolts and connections to ensure they are tight and secure. The bed frame should be stable and level.



Noise-free
Design

Image: Illustration of the bed frame's easy assembly process, highlighting key connection points.

Mattress Slide Stopper




Image: Detail of the noise-free design, showing the integrated padding on the metal slats to prevent sound.

AVAILABLE COLORS




Image: Close-up view of the mattress slide stopper, designed to keep the mattress securely in place.

4. OPERATING INSTRUCTIONS: RGBW LED LIGHTS

The integrated RGBW LED lights enhance your room's ambiance. Use the provided remote control to manage the lighting effects.

4.1 Connecting the LED System

1. Ensure the LED light strip is securely attached to the bed frame.
2. Connect the LED strip to the power adapter.
3. Plug the power adapter into a standard electrical outlet.

4.2 Using the Remote Control

The remote control allows you to customize the LED lighting:


- **Power Button:** Turns the LED lights On/Off.
- **Color Selection:** Choose from 20 static colors.
- **Brightness Adjustment:** Adjust the light intensity with 4 levels of brightness.

- **Dynamic Effects:** Select from 20 dynamic lighting modes (e.g., flash, strobe, fade, smooth).
- **Dynamic Speed:** Adjust the speed of dynamic effects with 8 levels.
- **RGBW Buttons:** Directly select Red, Green, Blue, or White light.



Meet your under-bed storage needs
and keep your room tidy.

Furniture Design



Sweeping robot comes and goes at will

Image: Visual representation of the RGBW LED light features, including color options, dynamic effects, and adjustable brightness/speed.



Image: The LUXOAK floating bed frame with blue LED lights activated, creating an ambient glow beneath the bed.

5. MAINTENANCE

Proper maintenance ensures the longevity and appearance of your bed frame.

- **Cleaning:** Wipe the metal frame with a dry cloth to remove dust. For stubborn marks, use a slightly damp cloth and dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all bolts and screws to ensure they remain tight. Retighten if necessary to maintain stability and prevent noise.
- **LED Lights:** Ensure the LED strip and power adapter are free from dust and debris. Do not attempt to repair the LED strip if damaged; contact customer support.

6. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose bolts or uneven floor.	Ensure all bolts are securely tightened. Move the bed to a level surface or use shims under legs if necessary.
Squeaking noise from the frame.	Loose connections or friction between metal parts.	Retighten all hardware. Verify slats are properly seated. The frame has a noise-free design, but re-checking connections can resolve issues.
LED lights are not turning on.	Power connection issue, remote battery, or faulty strip.	Check if the power adapter is securely plugged into the outlet and the LED strip. Ensure the remote control has working batteries. If issues persist, contact customer support.
Mattress slides on the frame.	Mattress stoppers not installed or improperly positioned.	Ensure the mattress slide stoppers are correctly installed and secured at the foot of the bed.

7. SPECIFICATIONS

QUEEN

80"L x 60"W x 9"H



Capacity

Image: Detailed dimensions of the Queen size bed frame (80"L x 60"W x 9"H) and its impressive 1000 lbs weight capacity.

Feature	Detail
Model Number	BMB014
Size	Queen
Product Dimensions	80"L x 60"W x 9"H
Material	Heavy-Duty Metal
Weight Capacity	1000 lbs
Item Weight	39.5 pounds
Under-Bed Clearance	7.4 inches

Feature	Detail
Special Feature	RGBW LED Lighting, Noise-Free Design, Mattress Slide Stoppers
Assembly Required	Yes (Approx. 30 minutes for 2 people)
Box Spring Required	No



Image: Visualizing the 7.4-inch under-bed clearance, ideal for storing various items like suitcases, shoes, or cartons, and allowing robot vacuum access.

FLOATING BED DESIGN

Hidden bed legs to eliminate any risk of tripping or collision



Image: The innovative floating bed design with hidden legs, demonstrating how it eliminates tripping hazards and provides ample space for robot vacuums.

8. WARRANTY AND SUPPORT

LUXOAK products are manufactured with quality and care. For any questions, concerns, or warranty claims, please contact LUXOAK customer support through the retailer where you purchased the product.

For additional information and products, visit the official LUXOAK store: [LUXOAK Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G2XFCRT1>

More documents and user manuals: <https://manuals.plus/>