

## VolenGo H1100

# VolenGo H1100 Label Maker Machine User Manual

Model: H1100

## INTRODUCTION

The VolenGo H1100 is a portable, handheld label maker designed for efficient and versatile labeling tasks. It features a backlit LCD screen for clear viewing in various lighting conditions and a QWERTY keyboard for easy text input. This device utilizes durable, laminated label tapes suitable for both indoor and outdoor applications, making it ideal for organizing items at home, in the office, or for school supplies.

## WHAT'S INCLUDED

Please verify that all items are present in your package:

- 1 x VolenGo H1100 Label Maker Machine
- 1 x Sample White Label Tape (12mm x 4m)
- 5 x Soft Color Label Tapes (12mm x 8m)
- 1 x USB-C Cable (for power option)

## SETUP

### 1. Powering the Device

The H1100 label maker can be powered by two methods:

- **AAA Batteries:** Insert 6 AAA dry cell batteries (not included) into the battery compartment located on the back of the device. Ensure correct polarity.
- **USB-C Cable:** Connect the provided USB-C cable to the label maker and a compatible USB power adapter (not included) or a computer USB port.

### 2. Loading Label Tape

1. Open the tape compartment cover on the back of the label maker.
2. Insert the label tape cassette with the tape facing the print head. Ensure the tape is properly aligned

and clicks into place.

3. Close the tape compartment cover securely.

## Original VolenGo BZ Tape Laminated Waterproof Labels

**Oil-Proof**

**Abrasion Resistant**

**Temperature Resistant**

**Strong Adhesion**

Image: VolenGo H1100 label maker with a tape cassette, illustrating the features of laminated waterproof labels such as oil-proof, abrasion resistance, temperature resistance, and strong adhesion.

## OPERATING INSTRUCTIONS

### 1. Power On/Off

Press the **Power** button to turn the label maker on or off.


### 2. Using the Backlit LCD

The H1100 features a backlit LCD screen for improved visibility. If the backlight is off, press the dedicated backlight key (often indicated by a lightbulb icon) to activate it. This is particularly useful in low-light environments.

# LCD SCREEN WITH BACKLIGHT Can be used in dimly lit areas



Other label makers  
NO BACKLIGHT, Hard to read



# VS



One-Touch Key  
to Light Up

Image: The VolenGo H1100 label maker displaying its backlit LCD screen, contrasted with a standard label maker without a backlight, highlighting the improved visibility in dim conditions.

### 3. Text Entry and Editing

- Use the **QWERTY keyboard** to type your desired text.
- Use the arrow keys (**Left/Right**) to move the cursor.
- Press **Backspace/Delete** to remove characters.
- The **Shift** key allows access to uppercase letters and secondary characters.

### 4. Formatting Labels

The H1100 offers various formatting options:

- **Font:** Press the **Font** button to select from multiple font styles and sizes (Small, Medium, Large).
- **Frame:** Use the **Frame** button to add decorative borders around your text.
- **Symbol:** Press the **Symbol** button to insert various symbols and icons.
- **Cable Mode:** For specific cable labeling, use the **Cable** button to access specialized modes.

# Multiple template settings

## 22 language


- |            |                |             |
|------------|----------------|-------------|
| 1.Cestina  | 9.Magyar       | 17.Suomi    |
| 2.Dansk    | 10.Neder-lands | 18.Svenska  |
| 3.Deutsch  | 11.Norsk       | 19.Turkce   |
| 4.English  | 12.Polski      | 20.Eestlane |
| 5.Espanol  | 13.Portugues   | 21.Lettish, |
| 6.Francais | 14.Romana      | 22.Lietuvos |
| 7.Hrvatski | 15.Slovenski   |             |
| 8.Italiano | 16.Slavensky   |             |

## 3 Font size

Small,Medium,Large

ABC **ABC** **ABC**

## 100+Borders



## 800+symbols



## 21 Different Styles Fonts

Normal,Bold,Italic,Font\_A~P,  
Horizontal,Vertical,

ABC\$£€39  
**ABC\$£€39**  
*ABC\$£€39*

Image: The VolenGo H1100 label maker interface demonstrating its extensive customization options, including support for 22 languages, three font sizes, over 100 borders, more than 800 symbols, and 21 distinct font styles.

## 5. Saving and Recalling Labels

The H1100 includes built-in memory to save frequently used label designs. Refer to the on-screen menu options (accessible via the **Menu** button) to save and recall your labels.

## 6. Printing Labels

After composing and formatting your label, press the **Print** button (often indicated by a printer icon) to print. The label maker can print multiple labels at once, up to 20, depending on the settings.

## APPLICATIONS

The VolenGo H1100 label maker is versatile and suitable for a wide range of labeling needs:

## Effortless Home Organization

Keep Your Kitchen, Drawers & Organization Projects Looking Sharp!



Image: Labels applied for home organization, including on storage drawers and shampoo bottles, demonstrating clear and neat labeling.

## School Essentials Label Tapes

Bright Colors & Durable Adhesive for Organizing Books, Lockers & Classroom Supplies!



Image: Labels used for school essentials, such as on books and classroom supplies, aiding in organization for students.

## Professional Office Labeling Solutions

Durable, Colorful Tape for Filing, Desk Organization & Streamlined Workspaces!



Image: Labels applied for professional office organization, including on file folders and electronic devices, promoting a streamlined workspace.



Image: The VolenGo H1100 label maker shown in diverse usage scenarios, including organizing items at home, labeling files in an office, marking school supplies, and identifying cables in a network setup.

## MAINTENANCE

- **Cleaning the Print Head:** If print quality degrades, gently clean the print head using a cotton swab lightly dampened with isopropyl alcohol. Ensure the device is off and dry before use.
- **Cleaning the Cutter:** Periodically check the tape cutter for adhesive residue. If necessary, carefully clean it with a dry cloth.
- **Tape Storage:** Store unused label tape cassettes in a cool, dry place away from direct sunlight to maintain adhesive quality.
- **Battery Care:** Remove AAA batteries if the device will not be used for an extended period to prevent leakage.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not power on.	Low or depleted batteries; incorrect battery insertion; loose USB-C connection.	Replace AAA batteries; check battery polarity; ensure USB-C cable is securely connected to a power source.
Poor print quality (faded, streaky).	Dirty print head; low battery power; incorrect tape type.	Clean the print head; replace batteries or use USB-C power; ensure you are using compatible VolenGo 12mm label tapes.
Tape jam or tape not feeding.	Tape cassette not inserted correctly; tape tangled inside; cutter blade obstructed.	Reinsert the tape cassette, ensuring it clicks into place; open the compartment and untangle any tape; clean the cutter blade.

Problem	Possible Cause	Solution
LCD screen is dim or off.	Backlight is off; low battery power.	Press the backlight key; replace batteries or use USB-C power.

## SPECIFICATIONS

---

- **Model:** H1100
- **Print Resolution:** 203 DPI
- **Compatible Tape Width:** 12mm (0.47 inches)
- **Power Source:** 6 x AAA batteries (not included) or USB-C cable (included)
- **Display:** Backlit LCD
- **Keyboard:** QWERTY
- **Memory:** Built-in, for saving label designs
- **Languages Supported:** 22 (e.g., English, German, French, Spanish)
- **Font Styles:** 21 different styles
- **Borders:** 100+ options
- **Symbols:** 800+ options

## WARRANTY AND SUPPORT

---

VolenGo products are manufactured to high-quality standards. For warranty information, technical support, or to purchase additional supplies, please visit the official VolenGo website or contact our customer service team through the retailer where you purchased the product. Please retain your proof of purchase for warranty claims.

**Online Support:** [Visit the VolenGo Store on Amazon](#)