

[Manuals.plus](#) /

› [Headwolf](#) /

› Headwolf FPad7 8-inch Android 15 Tablet User Manual

Headwolf FPad7

Headwolf FPad7 8-inch Android 15 Tablet User Manual

Your comprehensive guide to setting up and using your Headwolf FPad7 tablet.

1. INTRODUCTION

The Headwolf FPad7 is an advanced 8-inch Android 15 tablet designed for high performance and versatility. Featuring a MediaTek Dimensity 7050 (MT8791T) processor, a stunning 2560x1600 resolution display, and extensive memory, it is suitable for a wide range of tasks from productivity to entertainment. This manual provides detailed instructions to help you get the most out of your device.



Image: Headwolf FPad7 tablet showcasing its display and sleek design.

2. SAFETY INFORMATION

Please read all safety information before using your device to ensure safe and proper use. Keep this manual for future reference.

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Use only approved chargers and accessories to prevent damage and ensure safety.
- Keep the device away from water and other liquids.
- Do not attempt to disassemble or repair the device yourself. Contact qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are present in your Headwolf FPad7 package:

- Headwolf FPad7 Tablet
- USB-C Cable
- PD18W Charging Adapter
- SIM Card Pin
- User Manual (Japanese)



Image: Contents of the Headwolf FPad7 package, including the tablet, charger, cable, and manual.

4. PRODUCT OVERVIEW

Familiarize yourself with the physical components and key features of your Headwolf FPad7 tablet.

4.1 Physical Components



Image: Detailed diagram illustrating the location of buttons, ports, and cameras on the Headwolf FPad7.

- **Front Camera:** 8MP for video calls and selfies.
- **Back Camera:** 16MP for high-resolution photos and videos.
- **Card Slot:** Supports dual SIM cards or one SIM card and one SD card for expanded storage.
- **Volume Buttons:** Adjust the audio volume.

- **Reset Button:** Used to restart the device if it becomes unresponsive.
- **Power Button:** Turns the device on/off or puts it to sleep/wakes it up.
- **USB-C Charging Port:** For charging and data transfer.

4.2 Key Features

- **Processor:** MediaTek Dimensity 7050 (MT8791T) Octa-core CPU with ARM Mali-G68 MC4 GPU for smooth performance.
- **Display:** 8.4-inch 2560x1600 IPS display with 450nit brightness and Widevine L1 support.
- **Memory & Storage:** 16GB LPDDR5 RAM (8GB physical + 8GB virtual expansion) and 256GB UFS 3.1 ROM.
- **Connectivity:** 4G LTE, Wi-Fi 6 (802.11ax), Bluetooth 5.2.
- **Battery:** 6500mAh with PD18W fast charging.
- **Operating System:** Android 15 with features like Private Space, Single App Recording, App Pair, and Google Gemini AI.
- **Sensors:** 6-axis gyroscope, GPS (Beidou, Galileo, Glonass), Face Recognition.

5. SETUP

5.1 Initial Power On

Press and hold the Power button until the Headwolf logo appears. Follow the on-screen prompts to complete the initial setup.

5.2 Language and Time Zone Settings

During the initial setup, you will be prompted to select your preferred language and time zone. If you need to change the language to Japanese, follow the steps in the video below.

Video: Instructions on how to set the display language to Japanese on an Android 15 tablet.

5.3 Wi-Fi Connection

Connect your tablet to a Wi-Fi network for internet access. It is recommended to skip Wi-Fi connection during initial setup if your Wi-Fi environment is unstable, and connect later. The FPad7 supports Wi-Fi 6 for faster and more stable connections.

6. OPERATING INSTRUCTIONS

6.1 Display Settings

Adjust the brightness, font size, and display size to your preference for optimal viewing comfort. The FPad7's 2560x1600 display offers crisp visuals.

Video: Guide on adjusting brightness, display size, and text size on an Android tablet.

6.2 Memory Expansion

The FPad7 features smart virtual memory expansion, allowing the 8GB RAM to be extended by up to an additional 8GB from storage, boosting execution speed by 30%.



Image: Visual representation of the tablet's LPDDR5 RAM and UFS 3.1 ROM, highlighting memory expansion.

6.3 4G LTE Connectivity

Insert a SIM card into the card slot to enable 4G communication, including calls and SMS. Ensure your SIM card's frequency band is supported by the device. The FPad7 supports a wide range of 2G, 3G, and 4G bands.



Image: The Headwolf FPad7 demonstrating 4G LTE capabilities for communication on the go.

6.4 Camera Usage

Capture high-quality photos and videos with the 16MP rear camera and take clear selfies or make video calls with the 8MP front camera.

2.5K超高解像度ディスプレイ タブレットの新たな頂点



8.4インチ



2560x1600



視野角

FPad7は、2560x1600の解像度を持つ8.4インチの2.5Kディスプレイを搭載しており、優れた視覚体験を提供します。豊かな色再現性、優れたコントラスト、高輝度により、明るい環境でも鮮明で鮮やかなコンテンツを表示します。映画を観たり、ゲームをプレイしたり、デザインの草案を閲覧したりする際に、すべてが驚くべき詳細で表現されます。8.4インチの画面サイズと超広視野角を組み合わせることで、広く没入感のある視界を提供します。



Image: The Headwolf FPad7's front and rear cameras, highlighting their high-resolution capabilities.

6.5 Face Recognition

Utilize face recognition for smart and secure unlocking of your device, enhancing daily convenience and security.

6.6 GPS Navigation

The tablet supports GPS, Beidou, Galileo, and Glonass satellite systems, providing accurate location information for navigation apps and outdoor activities.

4G LTE対応SIMフリータブレット

SIM対応については次の3つの条件が必要です:

- 1.SIMの周波数帯域が対応していること
- 2.正しいAPN設定がされていること
- 3.タブレットとSIMが互換性があること

*周波数帯域が対応しており、APNの設定が正確でも正常に使用できない場合、SIMとタブレットが互換性がない可能性があるため、ご注意ください。

4G

B1/2/3/4/5/7/8/18/19/20/26/
28AB/66/B38/39/40/41

3G

B1/2/5/8

2G

B2/3/5/8

2.4G/5GHz wifi接続



Image: The Headwolf FPad7 used for GPS navigation in a vehicle.

6.7 Wireless Projection

The FPad7 supports wireless projection, allowing you to cast your screen to compatible devices for a larger viewing experience.

6.8 USB-C Port Functions

The USB-C port supports data transfer (USB 2.0), charging, and OTG (On-The-Go) functionality for connecting external devices like USB drives.

7. MAINTENANCE

To ensure the longevity and optimal performance of your Headwolf FPad7, follow these maintenance guidelines:

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive cleaners or solvents.
- **Battery Care:** Avoid fully discharging the battery frequently. For long-term storage, charge the battery to about 50%.
- **Software Updates:** Regularly check for and install system updates to ensure your device has the latest features and security patches.
- **Storage Management:** Periodically clear unnecessary files and apps to free up storage space and maintain performance.

8. TROUBLESHOOTING

Here are solutions to some common issues you might encounter:

Issue	Possible Solution
Device does not power on	Ensure the battery is charged. Connect the charger and try again. If unresponsive, press and hold the power button for 10-15 seconds.
Wi-Fi connection issues	Restart the tablet and your Wi-Fi router. Check if other devices can connect to the network. Ensure the Wi-Fi password is correct.
Slow performance	Close unused applications. Clear cache and temporary files. Consider performing a factory reset if the issue persists (back up your data first).
Battery drains quickly	Reduce screen brightness. Disable unused features like Bluetooth or GPS. Close background apps. Check for apps consuming excessive power in battery settings.

9. SPECIFICATIONS

Detailed technical specifications for the Headwolf FPad7 tablet:

Feature	Specification
Brand	Headwolf
Model Name	FPad7
Operating System	Android 15
Screen Size	8.4 inches
Display Resolution	2560x1600 pixels
CPU	MediaTek Dimensity 7050 (MT8791T) @ 2 GHz
RAM	16 GB LPDDR5 (8GB + 8GB Expansion)
Storage	256 GB UFS 3.1

Feature	Specification
Rear Camera	16 MP
Front Camera	8 MP
Battery Capacity	6500 mAh
Fast Charging	PD18W
Connectivity	4G LTE, Wi-Fi 6 (802.11ax), Bluetooth 5.2
Navigation	GPS, Beidou, Galileo, Glonass
Weight	660 g

10. WARRANTY AND SUPPORT

Headwolf provides comprehensive support for your FPad7 tablet:

- **Manufacturer Warranty:** 1 year.
- **Repair Center:** Tokyo repair center available.
- **Customer Support:** Japanese language support is available.

For any inquiries, please contact customer support through your Amazon account:

1. Go to the product page, click on the store name, then 'Ask a question'.
2. Alternatively, go to your Amazon account → Order History → Select the relevant order → Contact Seller.

Note: Damage caused by human factors, disasters, or other force majeure events is not covered under warranty.

© 2026 Headwolf. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question