

VINGLI VLKIC111B

VINGLI Rolling Kitchen Cart User Manual

Model: VLKIC111B

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your VINGLI Rolling Kitchen Cart, Model VLKIC111B. Please read this manual thoroughly before assembly and use to ensure safe and correct operation. Keep this manual for future reference.



Image: The VINGLI Rolling Kitchen Cart, Model VLKIC111B, featuring a black finish and a wooden countertop, positioned in a room with a coffee maker and decorative items.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Ensure all parts are properly secured before use.
- Do not allow children to play on, with, or around the cart.
- Do not exceed the maximum weight capacity of 120 lbs (54.4 kg).
- Use caution when moving the cart on uneven surfaces to prevent tipping.
- Regularly check all fasteners to ensure they remain tight. Loose fasteners can compromise stability.

PACKAGE CONTENTS

Before beginning assembly, verify that all components and hardware are present and undamaged. If any parts are

missing or damaged, please contact VINGLI customer support for assistance.

- All necessary engineered wood panels and rubberwood countertop.
- Drawer components and slides.
- Cabinet door with barn door design.
- Four 360° swivel wheels (two with locking mechanism).
- Side hooks and towel rods.
- Assembly hardware (screws, dowels, cam locks, etc.).
- Assembly instructions.

SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended to have two people for assembly. A Phillips head screwdriver and a hammer (not included) may be required. Lay out all parts on a soft, clean surface to prevent scratches.

1. **Identify Components:** Carefully identify each component by comparing it to the parts list and diagrams in the included assembly instructions. Note that some pieces may be labeled incorrectly; refer to the visual diagrams for accurate identification.
2. **Assemble Frame:** Follow the step-by-step diagrams to connect the main frame components using the provided hardware. Ensure all connections are secure but do not overtighten screws until the entire frame is loosely assembled.
3. **Install Drawer Slides:** Attach the drawer slides to the designated panels of the cart and the drawer box according to the instructions. Ensure they are level and aligned for smooth operation.
4. **Assemble Drawer:** Construct the drawer box and install it onto the slides.
5. **Attach Cabinet Door:** Install the cabinet door, ensuring the hinges are properly aligned for smooth opening and closing. The barn door design requires careful alignment.
6. **Install Wheels:** Attach the four swivel wheels to the bottom of the cart. Ensure the two lockable wheels are positioned where they can be easily accessed.
7. **Attach Side Accessories:** Secure the side hooks and towel rods to the designated areas on the cart.
8. **Final Tightening:** Once all components are in place and aligned, carefully tighten all screws and fasteners. Avoid overtightening, which can damage the engineered wood.

Thoughtful Design Details



Handy Towel Rack for Easy Access



Durable Solid Wood Countertop



Elegant Golden Handle



Secure Magnetic Door Catch



Sleek and Functional Side Hooks



Smooth-Gliding Drawer Slides



Image: Close-up views of the cart's design elements, including the towel rack, drawer handle, magnetic door catch, side hooks, and smooth-gliding drawer slides.

OPERATING INSTRUCTIONS

The VINGLI Rolling Kitchen Cart is designed for versatile use in various spaces.

- **Mobility:** The cart is equipped with four 360° swivel wheels for easy movement. To move the cart, ensure the wheel locks are disengaged.
- **Stability:** To secure the cart in a stationary position, engage the locks on the two lockable wheels. This prevents unintended movement.

4 Universal Durable Caster Wheels



Image: A detailed view illustrating the 360-degree omnidirectional swivel wheels and the locking mechanism for stable positioning.

- **Storage:** Utilize the top surface for appliances such as microwaves or coffee makers, ensuring the total weight does not exceed 120 lbs. The drawer provides enclosed storage for utensils, while the cabinet and open shelves offer space for various kitchen essentials.



Image: An overhead view of the open drawer, showcasing its internal dividers designed for organizing cutlery and other small kitchen tools.



Image: A close-up of the cart's open cabinet, revealing internal storage space, and the side hooks used for hanging kitchen utensils.

- **Side Hooks and Towel Rods:** Use the integrated side hooks for hanging oven mitts, towels, or small cooking tools. The towel rods are suitable for kitchen towels or similar items.



Image: The VINGLI Rolling Kitchen Cart positioned in a kitchen, demonstrating its use as a microwave stand and storage unit for various kitchen items.

MAINTENANCE

Proper care and maintenance will extend the life of your kitchen cart.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish. For the rubberwood countertop, use a mild wood cleaner if necessary.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten as needed to maintain stability.
- **Weight Distribution:** Distribute weight evenly across shelves and the countertop to prevent stress on the frame.

TROUBLESHOOTING

If you encounter issues with your VINGLI Rolling Kitchen Cart, refer to the following common solutions:

Problem	Possible Cause	Solution
Cart is wobbly or unstable.	Loose fasteners; uneven assembly.	Ensure all screws and bolts are securely tightened. Review assembly steps to confirm correct installation of all parts.
Drawer does not slide smoothly.	Drawer slides misaligned; obstruction.	Check that drawer slides are correctly installed and aligned. Ensure no objects are obstructing the drawer's path.
Wheels do not roll freely.	Wheel locks engaged; debris in wheels.	Disengage wheel locks. Check for and remove any debris (e.g., hair, lint) caught in the wheel mechanisms.
Cabinet door does not close properly.	Hinges misaligned; magnetic catch not engaging.	Adjust hinges as needed. Ensure the magnetic catch is properly aligned and secured.

SPECIFICATIONS

Feature	Detail
Model Number	VLKIC111B
Product Dimensions	15.75"D x 29.13"W x 35"H (40cm D x 74cm W x 89cm H)
Item Weight	38.5 pounds (17.5 kg)
Maximum Weight Capacity	120 pounds (54.4 kg)
Frame Material	Engineered Wood
Countertop Material	Rubberwood
Color	Black
Number of Shelves	1 (internal cabinet shelf)
Wheels	4 swivel wheels, 2 lockable

Load-Bearing Capacity: 180 LBS



Image: A detailed diagram illustrating the overall dimensions of the kitchen cart and the internal dimensions of its drawer.

WARRANTY AND SUPPORT

For warranty information, please refer to the manufacturer's official website or contact VINGLI customer support directly. Details regarding specific warranty periods and coverage are typically provided with your purchase documentation.

For further assistance, technical support, or to report missing/damaged parts, please contact VINGLI customer support through their official channels. Contact information can usually be found on the VINGLI brand website or your purchase receipt.

