



[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Queen Metal Loft Bed Instruction Manual

Bellemave Queen Loft Bed B0G34K1YYH

Bellemave Queen Metal Loft Bed Instruction Manual

INTRODUCTION

Welcome to your new Bellemave Queen Metal Loft Bed. This manual provides essential information for safe assembly, proper use, and maintenance of your loft bed. Please read these instructions thoroughly before assembly and retain them for future reference.

SAFETY INFORMATION

General Safety Guidelines

- Always follow assembly instructions carefully.
- Ensure all connections are securely tightened before use.
- Do not allow children under 6 years of age on the upper bunk.
- Use only mattresses that comply with the recommended dimensions for a Queen size bed.
- Periodically check and tighten all bolts and fasteners to maintain structural integrity.
- Do not use substitute parts. Contact Bellemave for genuine replacement components.
- Guardrails are provided to prevent falls. Ensure they are properly installed and maintained.

Weight Capacity

Consult the product specifications section or the label on your bed frame for the maximum weight capacity. Do not exceed the stated weight limit to prevent damage or injury.

PACKAGE CONTENTS

Before beginning assembly, carefully unpack all components and verify that all parts are present and undamaged. Refer to the detailed parts list included in your physical product package.

Included Components: Metal Frame components, Guardrails, Ladders (2), Slats, and all necessary Hardware (bolts, nuts, washers, etc.).

SETUP AND ASSEMBLY INSTRUCTIONS

Preparation

- Clear a spacious and level area for assembly, ensuring enough room to maneuver the bed frame components.
- Lay out all components and hardware on a soft, clean surface (e.g., a blanket or carpet) to prevent scratches or damage.
- Review the detailed, user-friendly assembly instructions with numbered parts provided in your product packaging.
- All necessary tools for installation are typically included with the hardware kit.

Assembly Steps

The assembly process for the Bellemave Queen Metal Loft Bed typically involves the following sequence:

1. Assemble the main vertical and horizontal frame components.
2. Attach the guardrails securely to the upper bunk frame.
3. Install the two ladders, ensuring they are firmly attached and stable for access from either side.
4. Place the mattress support slats evenly across the bed frame.
5. Perform a final check and tighten all bolts and fasteners securely using the provided tools.

For detailed, step-by-step instructions with illustrations, please refer to the separate assembly manual included in your product packaging.

UNIT:INCH




Image: Dimensions diagram of the Bellemave Queen Metal Loft Bed, showing overall length (82.7 inches), width (63 inches), height (64.6 inches), and various internal measurements for the bed frame and ladder steps.

USAGE INSTRUCTIONS

Accessing the Loft Bed

Use the provided dual-side ladders for safe and convenient access to the upper sleeping area. Always face the ladder when climbing up or down, and maintain three points of contact (two hands and one foot, or two feet and one hand).

Space Utilization

The open space beneath the loft bed is designed for versatile use. It can accommodate various items such as a desk, wardrobe, shelving unit, or a seating area, effectively optimizing room space and functionality.



Image: The Bellemave Queen Metal Loft Bed installed in a room, demonstrating the open space beneath the bed being utilized with a sofa and a small desk, highlighting its space-saving design.

MAINTENANCE

Cleaning

To clean the metal frame, wipe it with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the finish and integrity of the metal.

Fastener Checks

Periodically (e.g., every 3-6 months), inspect all bolts, screws, and fasteners. Tighten any that have become loose to ensure the bed's structural integrity, stability, and safety.

TROUBLESHOOTING

Squeaking Noises

If the bed frame produces squeaking noises, check all connections and tighten any loose bolts. Ensure the bed is placed on a level surface. Applying a small amount of lubricant to bolt threads (if accessible) can also help.

Instability

If the bed feels unstable or wobbly, immediately cease use and re-check all assembly steps. Ensure all parts are correctly aligned and securely fastened according to the manual. Verify that the bed is on a flat, even floor.

Missing Parts or Damaged Components

If you discover any missing parts or damaged components upon unboxing, do not proceed with assembly. Contact Bellemave customer support for assistance and replacement parts.

SPECIFICATIONS

Feature	Detail
Model	Queen Loft Bed
ASIN	B0G34K1YYH
Style	Modern
Size	Queen
Color	Black No Desk
Frame Material	Metal
Included Components	Guardrails, Ladders, Slats
Age Range Description	Adult, Teen
Required Assembly	Yes
Item Dimensions (L x W x H)	82.7"L x 63"W x 64.6"H

WARRANTY AND SUPPORT

Warranty Information

This Bellemave Queen Metal Loft Bed comes with a **Limited Warranty**. Please refer to the warranty card included in your package for specific terms, conditions, and duration of coverage.

Customer Support

For any questions, assistance with assembly, or to report missing or damaged parts, please contact Bellemave customer support. Contact information can typically be found on the product packaging or the official Bellemave website.

Visit the official Bellemave Store: [Bellemave Store on Amazon](#)