Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VGR YS-V197+995

VGR 197 & 995 Professional Hair Clippers and Trimmer Set User Manual

Model: YS-V197+995

1. Important Safety Instructions

Please read all instructions carefully before using the VGR 197 & 995 Hair Clippers and Trimmer Set. Keep this manual for future reference.

- Always use with caution near the face and eyes.
- Be aware of heat generation during extended use.
- Do not immerse the devices in water.
- Keep out of reach of children.
- Ensure the devices are fully charged before first use for optimal battery life.
- Do not use if the blades are damaged, as this may cause injury.

2. Product Overview

The VGR 197 & 995 set includes a professional hair clipper and a precision trimmer, designed for comprehensive hair grooming.



Image 2.1: The VGR 197 Hair Clipper and VGR 995 Hair Trimmer.

2.1 Key Features

- **VGR 197 Hair Clipper:** 6500 RPM motor, 2000mAh battery, 200 minutes runtime, Ceramic & Stainless Steel Blades.
- **VGR 995 Hair Trimmer:** 7000 RPM motor, 2000mAh battery, 300 minutes runtime, Titanium Blades.
- USB-C Fast Charging for both devices.
- LED Display for power status and oil reminder.
- Ergonomic design with leather-textured grip.

2.2 Package Contents

Please check the package for the following items:

- 1 x VGR 197 Hair Clipper
- 1 x VGR 995 Hair Trimmer
- 10 x Guide Combs (various sizes for clipper and trimmer)
- 1 x Cleaning Brush
- 1 x Lubricating Oil
- 1 x Hair Comb
- 2 x USB Charge Cables



Image 2.2: Included accessories: clippers, trimmer, guide combs, oil, brush, comb, USB cables.

3. Setup and Charging

3.1 Initial Charge

Before first use, fully charge both the hair clipper and the trimmer. This typically takes approximately 3 hours for each device.

1. Connect the USB charging cable to the charging port at the bottom of the clipper/trimmer.
2. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a USB port on a computer.
3. The LED indicator will show charging status. It will change or turn off when fully charged.



Image 3.1: Charging and operating times for VGR 197 (200 mins) and VGR 995 (300 mins).

3.2 Attaching Guide Combs

Select the desired guide comb length for your haircut. The set includes various sizes for both the clipper and trimmer.

1. Ensure the device is turned off.
2. Align the guide comb with the blade and slide it on until it clicks securely into place.
3. To remove, gently pull the comb away from the blade.



Image 3.2: Guide combs for different cutting lengths (1.5mm to 13mm).

4. Operating Instructions

4.1 VGR 197 Hair Clipper



Image 4.1: VGR 197 Hair Clipper features: 5-position taper lever, ceramic blade, 7000 RPM motor, USB-C charging, ergonomic design, LED display.

1. **Power On/Off:** Press the power button located on the side of the clipper to turn it on or off.
2. **Adjusting Taper Lever:** Use the taper lever on the side of the clipper to adjust the cutting length without changing guide combs. This allows for blending and fading.
3. **Hair Cutting:** Start with a longer guide comb if unsure. Move the clipper against the direction of hair growth for an even cut.

4.2 VGR 995 Hair Trimmer



Image 4.2: VGR 995 Hair Trimmer features: Precision T-blade, three-speed adjustment, indicator light, USB charging.

1. **Power On/Off:** Press the power button to activate or deactivate the trimmer.
2. **Precision Trimming:** The T-blade is ideal for creating sharp lines, edging, and detailing around the neckline, beard, and sideburns.
3. **Speed Adjustment:** Some models may feature multiple speed settings. Press the power button repeatedly to cycle through available speeds.

4.3 Official Product Video

Your browser does not support the video tag.

Video 4.3: An official overview of the VGR 197 & 995 Hair Clippers and Trimmer Set, demonstrating key features and components.

5. Maintenance

5.1 Cleaning the Blades

Regular cleaning ensures optimal performance and hygiene.

1. Turn off the device and disconnect it from any power source.
2. Use the provided cleaning brush to remove any hair clippings from the blades.
3. For a more thorough clean, you may carefully detach the blade head (refer to specific model instructions if applicable) and brush away debris.

5.2 Lubricating the Blades

Apply a few drops of the provided lubricating oil to the blades after every few uses, or when the blades feel sluggish.

1. Turn off the device.
2. Apply 1-2 drops of oil across the top of the blades.

3. Turn the device on for a few seconds to distribute the oil.
4. Wipe off any excess oil with a soft cloth.

5.3 Storage

Store the clipper and trimmer in a cool, dry place, away from direct sunlight and moisture. Ensure they are clean and oiled before storing for extended periods.

6. Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on	Low battery; Power button not pressed correctly	Charge the device fully; Ensure power button is pressed firmly.
Blades pull hair	Blades are dull or dirty; Lack of lubrication	Clean and oil the blades; If problem persists, blades may need replacement.
Device not charging	Faulty cable or adapter; Charging port issue	Try a different USB cable and power adapter; Ensure cable is fully inserted.
Excessive vibration or noise	Blades misaligned; Debris in motor	Clean blades thoroughly; Contact customer support if issue continues.

7. Specifications

Feature	VGR 197 Hair Clipper	VGR 995 Hair Trimmer
Model Number	YS-V197+995	
Motor Speed	6500 RPM	7000 RPM
Battery Capacity	2000mAh Lithium-Ion	
Runtime	200 minutes	300 minutes
Charging Time	Approx. 3 hours	
Blade Material	Ceramic & Stainless Steel	Titanium
Power Source	Battery Powered (USB-C Charging)	
Product Dimensions	2.17 x 1.38 x 6.69 inches (overall package)	

8. Warranty and Support

VGR products are manufactured with quality and performance in mind. This product comes with a **1-year limited warranty** from the date of purchase, covering manufacturing defects.

For warranty claims, technical support, or any questions regarding your VGR 197 & 995 Hair Clippers and Trimmer Set, please contact VGR customer service through the retailer where the product was purchased or visit the official VGR website for contact information.

Please retain your proof of purchase for warranty validation.

© 2023 VGR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G34LGD1V

More documents and user manuals: **https://manuals.plus/**