

[Manuals.plus](#) /

› [Evenflo](#) /

› Evenflo GoTime LX Booster Car Seat User Manual

Evenflo GoTime LX

Evenflo GoTime LX Booster Car Seat User Manual

Model: GoTime LX

Brand: Evenflo

INTRODUCTION AND OVERVIEW

The Evenflo GoTime LX Booster Seat is designed to provide a safe and comfortable seating solution for older children in vehicles. This booster seat accommodates children weighing 40 to 120 lbs, with a height range of 44 to 60 inches, and a minimum age of 5 years. It offers two modes of forward-facing use: a high-back booster and a backless booster, adapting to your child's growth.

Key features include a deep design with overlapping head and body sides for enhanced support, a one-hand adjustable headrest with 7 height positions, and dual-integrated cup holders for convenience. The seat is also designed for easy cleaning with a removable and machine-washable padded seat cover.

KEY FEATURES

- **Enhanced Safety Design:** Features a deep design with overlapping head and body sides for added support, meeting or exceeding all applicable federal safety standards.
- **Adjustable Height:** Easy one-hand height adjustment to 7 positions ensures a proper fit for your growing child.
- **Two Modes of Use:** Seamlessly transitions from a high-back booster to a backless booster for children aged 5 years and up, weighing 40 to 120 lbs.
- **Proper Belt Positioning:** Includes a belt clip to correctly position the vehicle's seat belt on the child's shoulder.
- **Integrated Cup Holders:** Dual cup holders keep drinks and snacks accessible, promoting driver focus.
- **Easy Maintenance:** Padded seat is removable and machine-washable for convenient cleaning.

WHAT'S IN THE BOX

- 1 Evenflo GoTime LX Booster Car Seat

SETUP AND INSTALLATION

Before installation, ensure you read the complete instruction manual provided with your booster seat. Proper installation is crucial for your child's safety.

High-Back Booster Setup:

1. **Assemble Components:** Connect the high-back portion to the booster base. Ensure the connection is secure and audible clicks are heard if applicable.



Image: The Evenflo GoTime LX Booster Car Seat shown disassembled into its high-back and base components, ready for assembly or conversion to backless mode.

2. **Adjust Headrest Height:** Use the one-hand adjustment mechanism to raise or lower the headrest. The shoulder belt guide should be positioned just above your child's shoulders.



Image: A sequence of images showing the headrest of the Evenflo GoTime LX Booster Car Seat being adjusted to different height positions.

3. **Position in Vehicle:** Place the booster seat firmly against the vehicle's seat back.
4. **Secure Child:** Route the vehicle's lap belt under the armrests and across your child's lap, ensuring it lies low on the hips. Route the shoulder belt through the red belt guide on the headrest, ensuring it lies flat across your child's chest and shoulder, not on the neck or face.



Image: A close-up view of the red seat belt guide on the Evenflo GoTime LX Booster Car Seat, demonstrating the correct path for the vehicle's shoulder belt.

Backless Booster Conversion:

1. **Remove High-Back:** Detach the high-back portion from the booster base according to the manual's instructions.
2. **Use Belt Positioning Clip:** When using the backless booster, attach the included belt positioning clip to the vehicle's shoulder belt to ensure proper fit across your child's shoulder.

OPERATING INSTRUCTIONS

Ensure your child is properly secured in the booster seat before every journey. The vehicle's seat belt is the primary restraint system when using this booster.

- **Child Placement:** Guide your child to sit fully back in the booster seat.
- **Lap Belt Positioning:** Pull the vehicle's lap belt across your child's upper thighs, ensuring it is snug and low on the hips. It should not rest on the stomach.
- **Shoulder Belt Positioning:** Pull the vehicle's shoulder belt across your child's chest and shoulder. Use the red belt guide on the high-back booster or the included belt positioning clip for the backless booster to ensure the belt is centered on the shoulder and not touching the neck or falling off the shoulder.
- **Tighten Belt:** Pull the shoulder belt to remove any slack from both the lap and shoulder portions of the

vehicle's seat belt.

- **Cup Holders:** Utilize the dual-integrated cup holders for beverages or small snacks.



Image: A close-up view of one of the dual cup holders on the Evenflo GoTime LX Booster Car Seat, shown with a small snack pouch inside.

MAINTENANCE

Regular cleaning and maintenance will help prolong the life of your Evenflo GoTime LX Booster Car Seat.

- **Fabric Care:** The padded seat cover is removable and machine-washable. Refer to the care label on the fabric for specific washing instructions. Typically, use cold water on a gentle cycle and tumble dry on low heat or air dry.
- **Plastic Components:** Wipe plastic parts with a soft cloth and mild soap and water. Do not use abrasive cleaners or solvents.
- **Buckle and Latch:** Periodically check the buckle and belt path for debris. Clean with a damp cloth if necessary. Do not use lubricants.
- **Inspection:** Regularly inspect the booster seat for any signs of wear, damage, or missing parts. If any damage is found, discontinue use and contact customer support.

TROUBLESHOOTING

If you encounter issues with your Evenflo GoTime LX Booster Car Seat, refer to the following common

solutions:

- **Loose Fit in Vehicle:** Ensure the booster seat is placed flush against the vehicle's seat back. Verify that the vehicle's seat belt is routed correctly through all guides and pulled taut.
- **Shoulder Belt Not Fitting Correctly:** Adjust the headrest height to ensure the shoulder belt guide is just above your child's shoulders. For backless mode, ensure the belt positioning clip is used to correctly position the shoulder belt.
- **Difficulty Adjusting Headrest:** Check for any obstructions or debris in the adjustment mechanism. Ensure the adjustment handle is fully engaged when attempting to move the headrest.
- **Buckle Sticking:** Clean the buckle mechanism with a damp cloth to remove any food crumbs or debris. Do not use oils or lubricants.
- **Child Discomfort:** Re-check all belt routings and headrest height to ensure they are appropriate for your child's size. Ensure the seat is free of any foreign objects.

SPECIFICATIONS

Specification	Detail
Minimum Weight Recommendation	40 Pounds
Maximum Weight Recommendation	120 Pounds
Minimum Height Recommendation	44 Inches
Maximum Height Recommended	60 Inches
Number of Height Positions	7
Installation Type	Seat Belt
Orientation	Forward-Facing Booster Car Seat
Material Type	Polyester, Polyurethane Foam
Item Weight	7.1 Pounds
Item Dimensions (D x W x H)	15.2"D x 28.19"W x 28.19"H



Image: The Evenflo GoTime LX Booster Car Seat with its key dimensions (depth, width, height) clearly indicated.

WARRANTY AND SUPPORT

Manufacturer's Warranty: The Evenflo GoTime LX Booster Car Seat comes with a 90-day limited manufacturer's warranty. Please retain your proof of purchase for warranty claims.

Customer Support: For assistance with installation, troubleshooting, or any other inquiries, Evenflo offers ParentLink® customer service. You can access real-time online help, including live video support with a certified car seat safety technician, to ensure proper vehicle installation and address any concerns.

For more information, visit the official Evenflo website or contact their customer service directly.