Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DGIVOVO G5055-OR1

DGIVOVO Wall Mounted Pressure Washer G5055-OR1 User Manual

Model: G5055-OR1 | Brand: DGIVOVO

1. Introduction

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your DGIVOVO Wall Mounted Pressure Washer, Model G5055-OR1. Please read this manual thoroughly before using the product and retain it for future reference.



Image: The DGIVOVO Wall Mounted Electric Pressure Washer in action, demonstrating its use for car cleaning.

2. Safety Information

WARNING: Always follow basic safety precautions when using this product to reduce the risk of injury or damage.

- **Total Stop System (TSS):** The pump automatically shuts off when the trigger is not engaged, saving energy and extending pump life.

- **Safety Lock:** Prevents accidental activation of the pressure washer when not in use. Always engage the safety lock when the unit is unattended or during nozzle changes.
- **GFCI Protection:** The power cord is equipped with a Ground Fault Circuit Interrupter for electrical safety. Do not bypass or modify this device.
- Always wear appropriate personal protective equipment, including eye protection, when operating the pressure washer.
- Do not direct the water jet at people, animals, electrical devices, or the unit itself.
- Ensure all connections are secure before operation to prevent leaks and maintain pressure.



Image: Close-up of the pressure washer's upgraded design, highlighting the safety lock on the spray gun and the GFCI protection on the power plug.

3. Package Contents

Verify that all components are present before beginning installation or operation:

- DGIVOVO Wall Mounted Pressure Washer Unit
- High-Pressure Spray Gun with Remote Control
- 100FT Retractable High-Pressure Hose
- Wall Mounting Bracket and Hardware (screws, hover pin)
- 5 Quick-Connect Nozzles (0°, 15°, 25°, 40°, Turbo Nozzle)
- Foam Cannon
- 10FT Power Cord with GFCI
- User Manual (this document)

4. Product Features

- **Powerful Motor:** 1800W motor delivers up to 5000 PSI and 3.2 GPM for effective cleaning.
- **Retractable Hose:** Features a 100FT high-pressure hose with an electrical hose reversion system for convenient storage.
- **Adjustable Pressure:** 5 adjustable pressure levels controlled via the spray gun's remote or directly on the unit.
- **Versatile Nozzles:** Includes 5 quick-connect nozzles (0°, 15°, 25°, 40°, and a Turbo Nozzle) for various cleaning tasks.

- **Foam Cannon:** Integrated foam cannon for efficient application of cleaning solutions.
- **Wall-Mounted Design:** Space-saving design with 180° free swivel for extended reach and flexibility.
- **Safety Features:** Equipped with Total Stop System (TSS) and a safety lock on the spray gun.



Image: An internal view highlighting the 1800W powerful motor and the compact dimensions (22"L x 8"W x 18"H) of the pressure washer unit.

Image: The control panel on the pressure washer and the remote control on the spray gun, showing options for pressure adjustment and electrical hose reversion.

5. Setup and Installation

Follow these steps to properly mount and set up your pressure washer:

1. **Determine Mounting Height and Mark Points:** Choose a suitable wall location. Hold the mounting bracket against the wall at the desired height and mark the drilling points for the screws.
2. **Install Base Frame and Screws:** Drill holes at the marked points. Insert appropriate wall anchors (if

necessary) and secure the base frame to the wall using the provided screws. Ensure it is firmly attached.

3. **Mount Pressure Washer Unit:** Carefully lift the pressure washer unit and align it with the installed base frame. Slide it into place and insert the hover pin to secure the unit to the bracket.
4. **Connect Water Supply:** Connect a garden hose (not included) to the water inlet on the pressure washer. Ensure the connection is tight to prevent leaks.
5. **Connect Power:** Plug the GFCI-equipped power cord into a suitable grounded electrical outlet.



Image: A visual guide demonstrating the three steps for wall mounting: marking points, installing the base frame, and attaching the pressure washer unit with a hover pin.

Your browser does not support the video tag.

Video: This video demonstrates the installation process of the DGIVOVO Wall Mounted Pressure Washer, including marking mounting points, securing the bracket, and attaching the main unit. It also shows the 180-degree swivel feature, hose extension/retraction, pressure adjustment, and nozzle usage.

6. Operation

6.1 Assembling the Spray Gun

Connect the spray gun components securely. Ensure the wand is firmly attached to the gun handle.

6.2 Extending and Retracting the Hose

To extend the 100FT high-pressure hose, simply pull it out to the desired length. The hose will lock in place. To retract, press the "REVERSE" button on the unit or the remote control on the spray gun. The electrical hose reversion system will automatically rewind the hose.



Image: A person utilizing the 100FT retractable pressure hose to clean a large driveway, demonstrating the extensive reach and remote control capabilities.

6.3 Adjusting Pressure Levels

The pressure washer offers 5 adjustable pressure levels. These can be controlled using the buttons on the spray gun's remote control or directly on the main unit's control panel. Use the up and down arrows to select the appropriate pressure for your cleaning task.

6.4 Using Nozzles and Foam Cannon

Select the appropriate quick-connect nozzle for your cleaning application. The included nozzles are:

- **0° (Red):** For intense spot cleaning and stubborn stains.
- **15° (Yellow):** For aggressive cleaning of hard surfaces.
- **25° (Green):** For general cleaning of various surfaces.
- **40° (White):** For gentle cleaning and rinsing.
- **Turbo Nozzle:** Provides a rotating jet for powerful, wide-area cleaning.

Attach the foam cannon for applying soap or cleaning solutions. Fill the foam cannon with your desired solution, connect it to the spray gun, and spray evenly over the surface before rinsing.



Image: An illustration detailing the 6 spray modes available, including the 0°, 15°, 25°, and 40° quick-connect nozzles, the Turbo Nozzle, and the efficient Foam Cannon.



Image: Demonstrates the versatility of the pressure washer with different nozzles for cleaning various surfaces like lichen-covered pavement and dirty fences.

Image: Shows the effective use of the turbo nozzle for tough cleaning and the foam cannon for applying thick foam during car washing.

7. Maintenance

- **Nozzle Cleaning:** Regularly inspect and clean nozzles to prevent blockages and maintain spray patterns. Use the included nozzle cleaning tool if necessary.
- **Hose Inspection:** Check the high-pressure hose for any signs of wear, cuts, or leaks before each use. Replace damaged hoses immediately.
- **Water Inlet Filter:** Clean the water inlet filter periodically to prevent debris from entering the pump.
- **Winter Storage:** If storing in freezing temperatures, drain all water from the pump, hose, and spray gun to prevent damage. Consider using a pump protector.
- **General Cleaning:** Wipe down the exterior of the unit with a damp cloth. Do not use harsh chemicals.

8. Troubleshooting

Problem	Possible Cause	Solution
Unit does not start	No power supply; GFCI tripped; Power switch off.	Check power connection; Reset GFCI; Turn power switch ON.
Low pressure	Insufficient water supply; Clogged nozzle; Air in pump; Kinked hose.	Ensure full water flow; Clean nozzle; Purge air from system; Straighten hose.
Water leaks	Loose connections; Damaged O-rings.	Tighten all connections; Replace worn O-rings.
Hose not retracting	Hose tangled; Obstruction; Electrical issue.	Ensure hose is free of tangles; Check for obstructions; Contact support if electrical issue suspected.

9. Specifications

Brand: DGIVOVO

Model Number: G5055-OR1

Power Source: AC Electric

Maximum Pressure: 5000 PSI

Maximum Flow Rate: 3.2 GPM

Motor Power: 1800 W

Hose Length: 100 Feet (Retractable)

Product Dimensions (L x W x H):22" x 8" x 18"

Color: Orange

UPC: 717373088473

Safety Standards: OPEI, Safety Standards

10. Warranty and Support

For any questions, concerns, or technical assistance, please contact DGIVOVO customer service. We offer 24/7 service to ensure your satisfaction.
Refer to your purchase documentation for specific warranty details and contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G3871RY2

More documents and user manuals: **https://manuals.plus/**