Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMSHADE half umbrella

HOMSHADE 9FT Half Patio Umbrella with Solar LED Lights User Manual

Model: Half Umbrella | Brand: HOMSHADE

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your HOMSHADE 9FT Half Patio Umbrella with Solar LED Lights. Please read this manual thoroughly before use to ensure proper function and longevity of your product. This umbrella is designed for small outdoor spaces such as balconies, decks, and patios, offering shade and ambient lighting.

Safety Information

- Always close the umbrella during strong winds, heavy rain, or other severe weather conditions to prevent damage or injury.
- Ensure the umbrella base is stable and adequately weighted. A base is not included with this umbrella and must be purchased separately.
- Do not hang objects from the umbrella ribs or pole.
- Keep children and pets away from the umbrella during opening and closing operations.
- Avoid placing the umbrella near open flames or heat sources.
- Regularly inspect all components for wear and tear. Replace damaged parts immediately.

Package Contents

Verify that all components are present before beginning assembly.

- Umbrella Canopy with Solar LED Lights
- Upper Pole
- Lower Pole with Crank Mechanism
- Solar Panel (integrated)



Image: Illustration of the umbrella components, including the canopy, pole sections, and crank system.

Setup Instructions

No tools are required for assembly.

1. **Attach the Upper Pole to the Lower Pole:** Carefully align the upper pole with the lower pole. Insert the upper pole into the lower pole until it clicks securely into place. Ensure the connection is firm.
2. **Insert into Umbrella Base:** Place the assembled umbrella pole into a suitable, weighted umbrella base (not included). Ensure the base is heavy enough to support the umbrella, especially in windy conditions.
3. **Position the Umbrella:** Position the flat side of the half umbrella flush against a wall, fence, or railing.
4. **Open the Umbrella:** Turn the hand crank clockwise to slowly open the umbrella canopy. Continue cranking until the canopy is fully extended and taut.
5. **Activate Solar Lights:** Locate the ON/OFF switch for the solar LED lights, usually near the solar panel on top of the canopy or on the pole. Switch it to the "ON" position. The lights will automatically illuminate when it gets dark, provided the solar panel has charged during the day.



Image: Visual guide for assembling the umbrella pole and opening the canopy.

Your browser does not support the video tag.

Video: Demonstrates the setup process of the outdoor half umbrella, including pole assembly and opening the canopy.

Operating Instructions

Opening and Closing the Umbrella

- To open, turn the hand crank clockwise until the canopy is fully extended.
- To close, turn the hand crank counter-clockwise until the canopy is fully retracted.
- Always close the umbrella when not in use or during adverse weather conditions.

Solar LED Lights

- The integrated solar panel charges the LED lights during daylight hours.
- Ensure the solar panel receives direct sunlight for optimal charging. Even on cloudy days, some charging occurs.
- To activate the lights, switch the ON/OFF button (typically located on the pole or near the solar panel) to the "ON" position. The lights will automatically turn on at dusk and off at dawn.
- For prolonged storage, switch the lights to "OFF" to preserve battery life.



Image: The half patio umbrella providing ambient lighting with its solar LED lights in an evening setting.

Your browser does not support the video tag.

Video: Shows the patio umbrella with solar lights in operation, highlighting its illumination feature.

Maintenance

Cleaning the Canopy

- Clean the polyester canopy fabric with mild soap and water. Use a soft brush or cloth to gently scrub any soiled areas.
- Rinse thoroughly with clean water and allow the canopy to air dry completely before closing or storing.
- Do not use harsh chemicals or abrasive cleaners, as these can damage the fabric and its UV/waterproof coating.

Frame and Pole Care

- Wipe down the alloy steel frame and pole with a damp cloth periodically to remove dirt and debris.
- Inspect the crank mechanism and ribs for any signs of rust or damage. Lubricate moving parts if necessary.

Storage

- When not in use for extended periods, especially during off-season or severe weather, close the umbrella and secure it with a tie strap if available.
- Store the umbrella in a dry, protected area to prolong its lifespan.




Image: Detail of the durable 220GSM solution-dyed fabric, highlighting its quality and fade resistance.

Troubleshooting

Problem	Possible Cause	Solution
Umbrella does not open/close smoothly.	Crank mechanism is stiff or obstructed.	Check for any debris or obstructions in the crank mechanism. Apply a silicone-based lubricant to moving parts if needed.
LED lights do not turn on.	1. Solar panel not sufficiently charged. 2. ON/OFF switch is in the "OFF" position. 3. Solar panel is dirty or obstructed.	1. Ensure solar panel receives direct sunlight for at least 6-8 hours. 2. Flip the ON/OFF switch to "ON". 3. Clean the solar panel surface with a soft, damp cloth.
Umbrella is unstable or tips over.	1. Insufficiently weighted base. 2. Strong winds.	1. Use a heavier umbrella base or add additional weights. 2. Close the umbrella immediately during windy conditions.

Specifications

Brand	HOMSHADE
Model Name	Half Umbrella

Size	9 FT
Color	Navy Blue (*Note: Other colors may be available for different models*)
Material	Polyester (220GSM Solution-Dyed Fabric)
Frame Material	Alloy Steel
Special Features	Solar LED Lights, UV Protection (UPF 50+), Water-Resistant, Tear Resistant, Crank System
Item Weight	9.5 Pounds
Shape	Semicircular



Image: Infographic detailing the umbrella's features: 1800mA Solar Panel, 20 LED Lights, 5 Iron Ribs, On/Off switch, and Smooth Crank System.

Warranty and Support

For warranty information or customer support, please refer to the product packaging or contact HOMSHADE directly through their official website or the retailer where the product was purchased. Keep your purchase receipt for warranty claims.
HOMSHADE is committed to providing high-quality products and customer satisfaction.



Image: Display of various quality certifications and standards met by HOMSHADE products, ensuring reliability.

© 2024 HOMSHADE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G392QH8J

More documents and user manuals: **https://manuals.plus/**