

DUMOS DM-TVK9C01-BK

DUMOS TV Stand with 9 Fabric Drawers Instruction Manual

Model: DM-TVK9C01-BK

1. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use of this product. Failure to follow these instructions may result in injury or product damage.

- Always secure the furniture to the wall using the provided anti-tip kit to prevent tipping. This is crucial for safety, especially in households with children or pets.
- Adjust the feet carefully to ensure stability on uneven surfaces. An unstable stand can lead to accidental tipping.
- Follow the assembly instructions closely to avoid injury and ensure proper construction.
- Do not overload the TV stand or its drawers. Refer to the 'Specifications' section for weight limits.
- Keep small parts and packaging materials away from children during assembly.

Anti-tip Design


Prevent Incidents



Image: Illustration of the anti-tip design, demonstrating how to secure the TV stand to the wall to prevent accidental tipping. This is a critical safety measure.



Robust Handle



Anti-Tip Kits



Adjustable Feet

Image: Detailed view of the robust handle, anti-tip kits, and adjustable feet, highlighting key features for stability and safety.

2. SETUP AND ASSEMBLY

The DUMOS TV Stand is designed for straightforward assembly. All necessary parts and detailed

instructions are included to ensure a smooth setup process.

2.1. Before You Begin

- Unpack all components and verify against the parts list provided in the packaging.
- Ensure you have the required tools (typically a screwdriver, not always included).
- Clear a spacious area for assembly to prevent damage to the product or your flooring.

2.2. Assembly Steps

1. Assemble the metal frame components according to the diagrams in the included instruction booklet. Ensure all screws are tightened securely.
2. Attach the particle board top to the assembled frame.
3. Insert the fabric drawers into their designated slots.
4. Install the adjustable feet at the bottom of the stand. Adjust them to ensure the stand is level and stable.
5. Secure the anti-tip kit to the back of the TV stand and then to a wall stud using appropriate hardware.

If you encounter any difficulties during assembly, please refer to the detailed instruction booklet or contact customer support.

3. OPERATING INSTRUCTIONS

This DUMOS TV Stand is designed to accommodate televisions up to 75 inches and provide ample storage for various household items.

3.1. Placing Your Television

- Carefully place your television on the center of the stand's top surface. Ensure the TV's base fits entirely within the stand's dimensions.
- Distribute the weight evenly to maintain stability.
- The stand is suitable for 55", 65", and 70" screens, and can support up to 75" TVs depending on their base dimensions and weight.



Image: The DUMOS TV stand in a living room, demonstrating its capacity to hold a television and blend with home decor.



Image: The TV stand accommodating a large television, highlighting its compatibility with various screen sizes from 55 to 75 inches.

3.2. Using the Fabric Drawers

- The nine deep fabric drawers provide ample storage for media collections, gaming accessories, clothing, bed linens, and other items.
- Use the easy-grip handles to smoothly open and close the drawers.

- Organize items within the drawers to maintain a tidy living space.



Image: An overhead view showing the spacious fabric drawers open and filled with various items, demonstrating the stand's storage capacity.



Image: Close-up of the drawers illustrating diverse storage possibilities for various items, emphasizing its versatility.

4. MAINTENANCE

Proper care will extend the life and appearance of your DUMOS TV Stand.

- **Cleaning the Surface:** Wipe the particle board top with a damp cloth, then immediately dry with a clean, dry cloth to prevent water marks or damage.
- **Cleaning Fabric Drawers:** For light cleaning, use a soft, dry cloth. For spills, gently blot with a damp cloth and mild soap, then air dry. Do not machine wash the fabric drawers.
- **Frame Care:** The metal frame can be wiped clean with a damp cloth. Avoid abrasive cleaners.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

5. TROUBLESHOOTING

If you encounter any issues with your DUMOS TV Stand, refer to the following common solutions:

Problem	Possible Cause	Solution
Stand is wobbly or unstable.	Uneven floor; loose connections.	Adjust the leveling feet at the bottom of the stand. Ensure all assembly screws are tightened.
Drawers do not slide smoothly.	Drawer not inserted correctly; obstruction.	Remove the drawer and reinsert it, ensuring it aligns with the frame. Check for any items obstructing the drawer's path.
Missing parts during assembly.	Packaging error.	Carefully check all packaging materials. If parts are still missing, contact DUMOS customer support with your model number and a list of missing components.

For issues not listed here, please contact DUMOS customer support for assistance.

6. SPECIFICATIONS

Feature	Detail
Model Number	DM-TVK9C01-BK
Product Dimensions	63 x 13.8 x 26.8 inches (L x W x H)
Item Weight	43.2 pounds
Material	MDF, non-woven fabric, metal frame
Number of Drawers	9
Color	Black
TV Size Compatibility	Up to 75 inches
Special Features	Adjustable feet, Anti-tip design, Thickened metal frame, Rear support bar
Product Care	Wipe with Damp Cloth, Wipe with Dry Cloth
Assembly Required	Yes (Instructions Included)

SIZE INFORMATION

110LBS



11LBS




Image: Size information diagram detailing the dimensions of the TV stand and its compatibility with various TV sizes.

3 LAYER UPGRADED FABRIC



Sturdier and resistant to distortion



Smooth-operating handle



Wear-resistant fabric

Image: Illustration of the 3-layer upgraded fabric used in the drawers, emphasizing its durability and resistance to distortion.



Image: Detailed view of the construction, including the thickened tube frame, triangular supporting rod, and adjustable feet, ensuring stability.

7. WARRANTY AND SUPPORT

DUMOS stands behind the quality of its products. For specific warranty information, please refer to the documentation included with your purchase or visit the official DUMOS website.

If you require assistance with assembly, have questions about product features, or need to report a defect, please contact DUMOS customer support. Have your model number (DM-TVK9C01-BK) and purchase information ready when contacting support.

DUMOS Customer Service: Please refer to your purchase platform or the DUMOS brand store for contact details.

8. ADDITIONAL RESOURCES

8.1. Product Overview Video

Your browser does not support the video tag.

Video: An official DUMOS brand story video providing a general overview of DUMOS products, including furniture items like TV stands and storage solutions. This video highlights the brand's commitment to organizing and elevating living spaces.

