

[Manuals.plus](#) /

› [WattFlo](#) /

› WattFlo Pressure Washer Instruction Manual - Model B0G3P9VWCB

WattFlo B0G3P9VWCB

WattFlo Pressure Washer Instruction Manual

Model: B0G3P9VWCB

1. INTRODUCTION

Thank you for choosing the WattFlo Pressure Washer. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new pressure washer. Please read this manual thoroughly before use and retain it for future reference.

Electric Pressure Washer



Figure 1.1: WattFlo Pressure Washer in use, demonstrating key features.

2. SAFETY INFORMATION

Always follow basic safety precautions when using this product to reduce the risk of injury or damage. This includes, but is not limited to:

- Wear appropriate personal protective equipment (PPE) such as safety glasses, gloves, and hearing protection.
- Ensure all connections are secure before operating the unit.
- Do not direct the water stream at people, pets, or electrical devices.
- Keep the work area clear of obstructions and ensure stable footing.
- Never operate the pressure washer without a water supply connected and turned on.
- Unplug the unit from the power source before performing any maintenance or when not in use.
- The unit features an Automatic Total Stop System, which automatically shuts off the pump when the trigger is not engaged, prolonging pump life and saving energy.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- WattFlo Pressure Washer Unit
- High-Pressure Hose (23 feet)
- Spray Gun with Safety Lock
- Quick-Connect Nozzles (0°, 15°, 25°, 40°)
- Foam Cannon (500ml capacity)
- Power Cord (16.5 feet)
- Water Inlet Fitting (for 3/4" standard US garden hose)
- User Manual

4. SETUP

Follow these steps to set up your pressure washer:

1. **Assemble the Handle:** Attach the handle to the main unit if it is not pre-assembled. Ensure it clicks securely into place.
2. **Connect the High-Pressure Hose:** Connect one end of the 23-foot high-pressure hose to the outlet on the pressure washer unit and the other end to the spray gun. Tighten all connections by hand.
3. **Connect Water Supply:** The pressure washer supports three water intake options:
 - **Direct Faucet Connection:** Attach a standard 3/4" garden hose (not included) to the water inlet fitting on the pressure washer and then to a water faucet. Ensure the faucet is fully open.
 - **Bucket Self-Priming:** Place the water inlet hose (not included) into a bucket of clean water. Ensure the hose remains submerged during operation.
 - **Pool Self-Priming:** Similar to bucket self-priming, place the water inlet hose into a pool.




Figure 4.1: Water intake options for the WattFlo Pressure Washer.

4. **Connect Power:** Plug the 16.5-foot power cord into a grounded electrical outlet. Ensure the outlet meets the power requirements specified in the 'Specifications' section.
5. **Purge Air from System:** Before turning on the power, squeeze the trigger on the spray gun to allow water to flow through the system and expel any trapped air. Continue until a steady stream of water emerges.

5. OPERATING INSTRUCTIONS

5.1. Starting the Pressure Washer

1. Ensure the water supply is connected and turned on, and air has been purged from the system.
2. Turn the power switch on the unit to the 'ON' position.
3. Engage the safety lock on the spray gun, then squeeze the trigger to begin spraying.

5.2. Using Quick-Connect Nozzles

The pressure washer includes four quick-connect nozzles, each designed for specific cleaning tasks. To change a nozzle, pull back the collar on the spray gun's quick-connect fitting, insert the desired nozzle, and release the collar to lock it in place. Always ensure the nozzle is securely attached before operating.




Figure 5.1: Quick-Connect Nozzles.

- **0° Red Nozzle (Powerful Jet):** Delivers a concentrated, high-impact stream for tough stains, cracks, and metal surfaces. Use with caution as it can damage surfaces.
- **15° Orange Nozzle (Focused Clean):** Provides a powerful, narrow spray for intensive cleaning of asphalt, brick, and concrete.
- **25° Green Nozzle (General Use):** Offers a versatile, medium-angle spray suitable for general cleaning of decks,

fences, and patios.

- **40° White Nozzle (Gentle Spray):** Produces a wide, gentle spray ideal for cleaning vehicles, windows, and outdoor furniture.

5.3. Using the Foam Cannon

The 500ml foam cannon is designed for efficient application of cleaning solutions, especially for car washing. Fill the foam cannon with your preferred pressure washer-safe detergent. Attach it to the spray gun's quick-connect fitting. The external foam cannon design prevents detergent from passing through the pump, ensuring safe operation.



Figure 5.2: Using the 500ml Foam Cannon for car washing.

5.4. Compatible Accessories

The 1/4" quick-connect interface allows compatibility with various cleaning accessories, including turbo nozzles, surface cleaners, extension wands, and undercarriage tools (accessories sold separately).

1/4" Quick Connect

Compatible with following accessories



Figure 5.3: 1/4" Quick Connect and compatible accessories.

5.5. Stopping the Pressure Washer

1. Release the trigger on the spray gun. The Automatic Total Stop System will engage.
2. Turn the power switch on the unit to the 'OFF' position.
3. Turn off the water supply.
4. Squeeze the trigger on the spray gun to release any remaining pressure in the system.
5. Disconnect the power cord from the electrical outlet.
6. Disconnect the water supply hose and high-pressure hose.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your pressure washer.

- **Cleaning Nozzles:** If a nozzle becomes clogged, use the included nozzle cleaning tool (if applicable) or a thin wire to clear any debris. Rinse thoroughly.

- **Water Inlet Filter:** Periodically check and clean the water inlet filter to prevent debris from entering the pump.
- **Storage:** After each use, drain all water from the pump, hoses, and spray gun to prevent freezing in cold weather. Store the unit in a dry, protected area. The unit features dedicated storage for the spray gun, power cord, high-pressure hose, detergent bottle, and nozzles.




Figure 6.1: Integrated storage features for accessories and cables.

7. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not start	No power supply; Power switch off; Circuit breaker tripped	Check power connection; Turn power switch ON; Reset circuit breaker
Low pressure	Insufficient water supply; Clogged nozzle; Air in pump; Kinked hose	Ensure full water flow; Clean nozzle; Purge air from system; Straighten hose
Water leaks	Loose connections; Damaged O-rings	Tighten all connections; Replace damaged O-rings
Motor stops during operation	Thermal overload; Automatic Total Stop System engaged	Allow motor to cool; Release trigger and restart

8. SPECIFICATIONS

Technical details for the WattFlo Pressure Washer:

- **Brand:** WattFlo
- **Model:** B0G3P9VWCB
- **Power Source:** AC
- **Item Weight:** 18 Pounds
- **Hose Length:** 23 Feet (High-Pressure Hose)
- **Power Cord Length:** 16.5 Feet
- **Product Dimensions:** 11"L x 18"W x 14"H
- **Tank Volume (Foam Cannon):** 500 Milliliters
- **Maximum Flow Rate:** 2.5 Gallons Per Minute (GPM)

- **Nozzles:** 0°, 15°, 25°, 40° Quick-Connect
- **Water Intake Options:** Faucet, Bucket Self-Priming, Pool Self-Priming



Figure 8.1: The 1800W motor provides efficient and powerful cleaning.

9. OFFICIAL PRODUCT VIDEOS

Watch these official videos for visual guidance on using your WattFlo Pressure Washer.

Your browser does not support the video tag.

Video 9.1: Demonstration of the WattFlo Pressure Washer in action, showcasing its cleaning capabilities.

Your browser does not support the video tag.

Video 9.2: Detailed overview of the WattFlo Pressure Washer's features and assembly process.

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the contact details provided with your purchase documentation or visit the official WattFlo website. Keep your purchase receipt as proof of purchase for warranty claims.