

TeqHome B0G3PP33M4

TeqHome 2000W Portable Electric Double Coil Hot Plate

Model: B0G3PP33M4

1. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse the cord, plugs, or the heating unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool completely before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the power cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to "OFF", then remove the plug from the wall outlet.
- Do not use the appliance for other than its intended use.
- A short power-supply cord is provided to reduce the hazards resulting from entanglement or tripping over a longer cord.
- If an extension cord is used: The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance. The longer cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

2. PRODUCT OVERVIEW

The TeqHome 2000W Portable Electric Double Coil Hot Plate is designed for versatile cooking in various settings, including home, RVs, camping, and offices. It features two independent coil burners with adjustable temperature controls, offering efficient and convenient cooking.

Key Features:

- **Dual 6-inch Coil Burners:** Provides two cooking zones for simultaneous use.
- **2000W Total Power:** Ensures fast and efficient heating.
- **5 Adjustable Temperature Levels:** Precise control for various cooking needs.
- **Wide Cookware Compatibility:** Works with aluminum, copper, cast iron, and non-magnetic stainless steel.
- **Compact & Portable Design:** Lightweight and easy to store and transport.
- **Durable Construction:** Made with stainless steel body and cast-iron cooktop.
- **Safety Features:** Built-in over-heat protection and non-slip feet.



Figure 2.1: TeqHome 2000W Portable Electric Double Coil Hot Plate.




Figure 2.2: Close-up view of the hot plate showing temperature control knobs, coil plates, stainless steel construction, and anti-skid feet.

3. SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the hot plate on a stable, heat-resistant, and level surface. Ensure there is adequate ventilation around the unit to prevent overheating. Do not place it directly against a wall or under cabinets that may be damaged by heat.
3. **Feet Pads:** If not already installed, attach the four bottom feet pads to ensure stability and prevent slipping.
4. **Power Connection:** Ensure the power cord is not touching any hot surfaces. Plug the hot plate into a standard 110V electrical outlet.

Lightweight And Portable

For easy storage

17.51 x 9.45 x 2.52in



Figure 3.1: The compact design allows for easy storage in small spaces.

4. OPERATING INSTRUCTIONS

4.1 Temperature Control

Each burner is controlled by an independent knob, allowing you to select from 5 heating levels. Turn the knob clockwise to increase the heat and counter-clockwise to decrease it or turn it OFF.

- **OFF:** Burner is off.
- **Level 1-2 (Low Temp):** Approximately 302°F - 500°F (150°C - 260°C) - Ideal for keeping food warm or gentle simmering.
- **Level 3-4 (Middle Temp):** Approximately 698°F - 842°F (370°C - 450°C) - Suitable for stir-frying and general cooking.
- **Level 5 (High Temp):** Up to 1022°F (550°C) - For deep frying and rapid boiling.

The red indicator light will illuminate when the burner is actively heating. It will extinguish once the set temperature is reached and cycle on and off to maintain the desired heat level.



Figure 4.1: 5 Power Levels and their recommended uses.

4.2 Cookware Compatibility

The TeqHome hot plate is compatible with a wide range of cookware types. For optimal performance, use cookware with flat bottoms that make full contact with the heating coils.

- **Compatible Cookware:** Aluminum pans, copper pans, cast iron frying pans, and non-magnetic stainless steel pans.
- **Avoid:** Cookware with convex, concave, or uneven bottoms, as this can lead to inefficient heating and potential instability.

Compatible With Most Cookware

Fit cookware as large as 6in diameter and as heavy as 11lbs



Frying Pan



Steak Pan



Aluminum Pot



Cast Iron Pan



Wok



Stainless Steel Pot



Glass Pot



Tea Pot



Figure 4.2: Examples of compatible cookware for the hot plate.

4.3 General Usage

1. Place your desired cookware, filled with food or liquid, onto the center of the heating coil.
2. Turn the corresponding temperature control knob to the desired heating level (1-5). The indicator light will turn on.
3. Monitor your cooking. Adjust the temperature as needed.
4. Once cooking is complete, turn the knob to the "OFF" position and unplug the unit from the power outlet. Allow the hot plate to cool completely before handling or cleaning.

5 Power Levels

Powered by 1000W per plate, heat up fast and efficiently
Dual plates allow you to use both sides simultaneously



Figure 4.3: Hot plate in use with various cooking tasks.

Your browser does not support the video tag.

Video 4.1: Demonstration of the TeqHome 2000W Electric Double Coil Burner Stove in operation, showing temperature adjustment and boiling water.

5. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will extend the life of your hot plate and ensure safe operation.

1. **Cool Down:** Always unplug the hot plate from the power outlet and allow it to cool completely before attempting any cleaning.
2. **Do Not Immerse:** Never immerse the hot plate unit, cord, or plug in water or any other liquid.
3. **Exterior Cleaning:** Wipe the exterior surfaces with a damp cloth or sponge. For stubborn stains, a mild, non-abrasive cleaner can be used.

4. **Coil Cleaning:** The heating coils can be cleaned with a soft brush or cloth. Do not use abrasive materials or sharp objects that could damage the coils.

5. **Drying:** Ensure all parts are thoroughly dry before storing or reusing the appliance.

Easy Cleaning

Please do not immerse the hot plate into the water or other liquids.

Simply wipe with a damp sponge or wet cloth for easy cleaning after cooling down completely. When the hot plate is not in use, be sure to slide the switch to the "off" position and unplug the plug.



Figure 5.1: Cleaning the hot plate with a damp cloth.

6. TROUBLESHOOTING

If you encounter issues with your hot plate, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hot plate does not turn on.	Not plugged in, knob set to OFF, power outage, circuit breaker tripped.	Ensure cord is securely plugged into a working outlet. Turn knob to a heating level (1-5). Check household circuit breaker.

Problem	Possible Cause	Solution
Hot plate is not heating sufficiently.	Low temperature setting, improper cookware, insufficient preheating time.	Increase temperature setting. Use flat-bottomed cookware that makes full contact with the coil. Allow adequate time for the unit to reach temperature.
Indicator light is off, but the unit is still warm.	Normal operation (thermostat cycling).	This is normal. The indicator light cycles on and off to maintain the set temperature.
Smoke or odor during first use.	Protective coating burning off.	This is normal for the first few uses. Ensure good ventilation. It should dissipate quickly.

7. SPECIFICATIONS

Brand	TeqHome
Model	B0G3PP33M4
Color	Black
Material	Powder Coating Iron Sheet; 201 Stainless Steel Heating Tube; Copper Clad Aluminum Wire
Special Feature	Portable, Temperature Control, 5 Levels of Adjustment, 2 Burner, Slip-Proof
Heating Elements	2 (Coil type)
Product Dimensions	17.51"D x 9.45"W x 2.52"H
Wattage	2000 watts
Controls Type	Knob
Voltage	110 Volts
Item Weight	2.6 Pounds
Included Components	1 x Double Coil Burner with Cord Adapter, 4 x Bottom Feet Pads, 1 x User Manual
Recommended Uses	Indoor, outdoor, RV, camping

Product Dimensions



Figure 7.1: Product dimensions and versatile cooking applications.

8. WARRANTY AND SUPPORT

TeqHome is committed to providing high-quality products and excellent customer service.

- **Warranty:** This product comes with a 5-year warranty.
- **Customer Service:** TeqHome offers lifetime customer service for this product.
- **Return Policy:** A 90-day hassle-free return policy is available.
- **Contact:** For any problems encountered during purchase or use, please feel free to contact TeqHome customer service through the Amazon platform.

