



[Manuals.plus](#) /

> [Portronics](#) /

> Portronics PowerShutter Air 10K 10000mAh Wireless Magnetic Power Bank User Manual

## Portronics Power Shutter 10K

# Portronics PowerShutter Air 10K User Manual

MODEL: POWER SHUTTER 10K (POR-2807)

## Introduction

---

Thank you for choosing the Portronics PowerShutter Air 10K 10000mAh Wireless Magnetic Power Bank. This device is designed to provide convenient and efficient charging for your smartphones and other compatible devices, both wirelessly and via cable. Please read this manual carefully to ensure proper use and optimal performance of your power bank.

## Product Overview

---

The Portronics PowerShutter Air 10K is a versatile power bank featuring a 10,000mAh capacity, 15W wireless magnetic charging, and 22.5W PD wired charging. It includes a built-in Type-C cable for added convenience.

- **High Capacity:** 10,000mAh battery for extended power.
- **15W Wireless Charging:** Fast wireless charging with strong magnetic hold for compatible devices.
- **22.5W PD Wired Charging:** Power Delivery (PD) via Type-C port for rapid wired charging.
- **Built-in Type-C Cable:** Integrated detachable Type-C to Type-C cable for convenience.
- **LED Indicator:** Displays battery level and wireless charging status.
- **Ultra-Slim Design:** Compact and lightweight (16mm thin, 160g) for portability.
- **Safety Features:** Advanced chipset protects against overcharging, short circuits, and overheating.

# 10000mAh

High Capacity Power Bank



*Image: The Portronics PowerShutter Air 10K power bank, highlighting its 10000mAh capacity.*

# Ultra Slim & Portable Design



Compact



120g



Light Weight



Flight Approved



*Image: Side view of the Portronics PowerShutter Air 10K, illustrating its ultra-slim 16mm design and light weight.*

## Setup

---

- Unboxing:** Carefully remove the power bank and all accessories from the packaging. Verify that all components listed in the "What's in the Box" section are present.
- Initial Charge:** Before first use, fully charge the PowerShutter Air 10K. Connect the power bank to a compatible USB wall adapter (not included) using the built-in Type-C cable or another Type-C to Type-C cable. The LED indicator will show charging progress and turn solid when fully charged.

## Operating Instructions

---

### 1. Charging the Power Bank

To recharge your PowerShutter Air 10K:

- Connect the built-in Type-C cable or an external Type-C to Type-C cable to the power bank's Type-C port.
- Plug the other end of the cable into a USB wall charger (minimum 5V/2A recommended for efficient charging).
- The LED indicator lights will illuminate to show the charging status. All lights will be solid when fully charged.

## 2. Charging Devices Wirelessly (15W)

The PowerShutter Air 10K supports 15W magnetic wireless charging for compatible devices (e.g., iPhone 12 and above, or other Qi-enabled devices with magnetic cases/rings).

1. Ensure your device is Qi-enabled and has magnetic charging capabilities or is equipped with a compatible magnetic case/ring.
2. Align your device's wireless charging area with the magnetic charging pad on the power bank. The strong magnetic hold will secure your device in place.
3. Wireless charging will begin automatically. The LED indicator on the power bank will show that wireless charging is active.



*Image: The Portronics PowerShutter Air 10K wirelessly charging a smartphone, illustrating the 15W wireless output and magnetic connection.*

# Charge through Magnetic Cases



Magnetic Cases



iPhone Without Cases



Non-Magnetic Cases



Note: Only Works With iPhone Compatible Magnetic cases

*Image: Diagram showing compatibility with magnetic cases and iPhones without cases for wireless charging. Non-magnetic cases are not supported for magnetic charging.*

**For Non-Magnetic Wireless Phones:** If your phone supports wireless charging but lacks magnetic capabilities, you can use the included metal ring. Attach the metal ring to the back of your phone to enable magnetic alignment with the power bank.

# Make Your Non Magnetic Wireless Phone Magnetic with a Metal Ring



Enhance your Android's wireless charging by turning your non-magnetic phone into a magnetic one—just attach a metal ring to the back

*Image: A smartphone with a metal ring attached to its back, demonstrating how to make a non-magnetic wireless phone compatible with magnetic charging.*

### 3. Charging Devices via Cable (22.5W PD)

The power bank offers 22.5W Power Delivery (PD) fast charging via its Type-C port and the built-in Type-C cable.

- **Using the Built-in Cable:** Detach the built-in Type-C to Type-C cable from the power bank. Connect one end to the power bank's Type-C port and the other end to your device's Type-C charging port.
- **Using the Type-C Port:** Alternatively, use your own compatible Type-C to Type-C or Type-C to Lightning cable. Connect one end to the power bank's Type-C port and the other to your device.
- Charging will commence automatically. The LED indicator will show the power bank's remaining charge.

# 22.5W

Wired Output Bi-Directional  
Type C Port



*Image: The Portronics PowerShutter Air 10K connected via its built-in Type-C cable to a smartphone, demonstrating 22.5W wired charging.*

# In Built Type C to Type C Strong Cable



Lanyard Support

Image: Close-up of the Portronics PowerShutter Air 10K showing the integrated Type-C to Type-C cable and lanyard support.

## Maintenance

- Keep the power bank away from water, moisture, and extreme temperatures.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Avoid dropping or subjecting the power bank to strong impacts.
- Store the power bank in a cool, dry place when not in use. For long-term storage, charge it to about 50% every three months to preserve battery life.

## Troubleshooting

Problem	Possible Cause	Solution
Power bank not charging.	Cable not connected properly; faulty cable/adaptor; power bank battery depleted.	Ensure connections are secure. Try a different cable or wall adaptor. Allow the power bank to charge for a longer period.

Problem	Possible Cause	Solution
Device not charging wirelessly.	Misalignment; non-compatible case; device not Qi-enabled; foreign objects between device and power bank.	Realign device on the charging pad. Remove non-magnetic cases. Ensure your device supports Qi wireless charging. Remove any metal objects or cards.
Device not charging via cable.	Cable not connected properly; faulty cable; device not compatible with Type-C port.	Check cable connections. Try a different cable. Ensure your device's charging port is clean and functional.
Slow charging.	Using a low-power adapter; cable quality; device charging limitations.	Use a fast-charging wall adapter (e.g., 20W PD or higher). Ensure the cable is rated for fast charging. Some devices may limit charging speed.
Power bank or device gets warm during charging.	Normal operation; poor ventilation; excessive load.	Slight warmth is normal. Ensure adequate ventilation. Avoid charging in direct sunlight or confined spaces. If it becomes excessively hot, discontinue use and contact support.

## Specifications

Feature	Detail
Model Name	Power Shutter 10K
Model Number	POR-2807
Battery Capacity	10000 mAh
Wireless Output	15W
Wired Output (Type-C PD)	22.5W
Connector Type	USB Type C
Battery Cell Type	Lithium Polymer
Item Weight	160 Grams
Dimensions (L x W x Thickness)	13L x 10.8W x 3.2Th Centimeters
Box Contents	Powerbank 1N, Documentation 1N, Charging Cable 1N
Country of Origin	India

## Warranty and Support

Your Portronics PowerShutter Air 10K comes with a **1-Year Warranty** from the date of purchase. For any assistance, support, or warranty claims, please contact Portronics customer service.

**Customer Support Email:** [help@portronics.com](mailto:help@portronics.com)

**Customer Support Phone/WhatsApp:** +91 9555-245-245 (10am - 6pm)

**Manufacturer Address:** Portronics Digital Pvt. Ltd., First Floor Property No D 8 Upper Basement Sector 8 Noida  
Uttar Pradesh 201301



**PortCare**

**Your Personalized Support**  
Hassle-Free Assistance | Complete Peace of Mind

Upto 1 Year Warranty

Dedicated Human Support

Easy Pickup & Quick Exchange

**For any assistance:**  
Call/Whatsapp @ 9555-245-245  
Support/Email @ <https://support.portronics.com>  
(10am - 6pm)

*Image: PortCare support details, including warranty, human support, and contact information.*