

[Manuals.plus](#) /

› [xdoobo](#) /

› xdoobo Home 1978 II Soundbar Instruction Manual

xdoobo Home 1978 II

xdoobo Home 1978 II Soundbar Instruction Manual

INTRODUCTION

Welcome to your new xdoobo Home 1978 II Soundbar. This soundbar is designed to enhance your home entertainment experience with powerful 80W audio and versatile connectivity options. Please read this manual carefully before use to ensure proper setup and operation.

WHAT'S IN THE BOX

- xdoobo Home 1978 II Soundbar
- Power Adapter
- User Manual

PRODUCT FEATURES

- **Powerful 80W Audio:** Four 20W full-range drivers with dual air ducts for deep bass and clear highs.
- **Multiple Connectivity:** Supports HDMI ARC, Optical, AUX, USB, and Coaxial connections.
- **Bluetooth 5.3:** Stable wireless streaming from smartphones and tablets.
- **Wide Soundstage:** Four-driver speaker structure for immersive audio.
- **Slim Design:** 900mm length fits under most TVs.




Image: Internal view of the soundbar highlighting its four full-range speakers, designed for powerful and clear audio output.

SETUP

1. Soundbar Placement

Place the soundbar on a stable, flat surface directly in front of your television. Ensure there are no obstructions blocking the sound output.




Image: The xdobo Home 1978 II Soundbar positioned centrally under a television, demonstrating optimal placement for an immersive home viewing experience.

2. Power Connection

Connect the power adapter to the DC IN port on the soundbar, then plug the adapter into a wall outlet.

3. Audio Connection Options

Choose one of the following methods to connect the soundbar to your TV or other audio source:

HDMI ARC Connection (Recommended)

Connect an HDMI cable from the **HDMI ARC** port on the soundbar to the **HDMI ARC** port on your TV. Ensure your TV's HDMI ARC function is enabled in its settings.

Optical Connection

Connect an Optical cable from the **OPTICAL** port on the soundbar to the Optical Digital Audio Out port on your TV.

AUX Connection

Connect a 3.5mm AUX cable from the **AUX** port on the soundbar to the headphone jack or audio out port on your TV or device.

Coaxial Connection

Connect a Coaxial cable from the **COAXIAL** port on the soundbar to the Coaxial Digital Audio Out port on your TV.

USB Connection

Insert a USB drive into the **USB** port on the soundbar to play audio files directly.

OPERATING INSTRUCTIONS

1. Power On/Off

Press the **Power** button on the soundbar or remote control to turn the unit on or off.

2. Input Source Selection

Press the **Input** button on the soundbar or remote control repeatedly to cycle through available input sources: HDMI ARC, Optical, AUX, Coaxial, USB, and Bluetooth.

3. Volume Control

Use the **Volume Up (+)** and **Volume Down (-)** buttons on the soundbar or remote control to adjust the volume.

4. Bluetooth Pairing

1. Select Bluetooth mode on the soundbar. The indicator light will flash.
2. On your mobile device, enable Bluetooth and search for "XDOBO Home 1978 II".
3. Select the soundbar from the list to pair. Once connected, the indicator light will stop flashing.
4. You can now stream audio from your device to the soundbar.

MAINTENANCE

Cleaning

Wipe the soundbar with a soft, dry cloth. Do not use liquid cleaners or abrasive materials. Ensure the soundbar is powered off and unplugged before cleaning.

Storage

If storing the soundbar for an extended period, disconnect it from power and store it in a cool, dry place.

TROUBLESHOOTING

No Power

Ensure the power adapter is securely connected to the soundbar and a working power outlet.

No Sound

Check that the correct input source is selected on the soundbar. Verify that the volume is not muted or set too low. Ensure audio cables are securely connected to both the soundbar and your TV/device. For HDMI ARC, confirm your TV's ARC function is enabled.

Bluetooth Pairing Issues

Ensure the soundbar is in Bluetooth pairing mode. Move your device closer to the soundbar. Disconnect and re-pair the device. Clear previous Bluetooth connections on your device if necessary.

SPECIFICATIONS



Image: A detailed view of the xdoobo Home 1978 II Soundbar, emphasizing its compact form factor and branding.

Model Name	XD-Home 1978 II
Output Power	80 Watts
Connectivity	Bluetooth 5.3, HDMI ARC, Optical, AUX, USB, Coaxial
Frequency Response	70 Hz
Speaker Type	Soundbar
Dimensions (D x W x H)	3.6" x 35.5" x 2.9"
Weight	3 Kilograms
Input Voltage	120 Volts

WARRANTY AND SUPPORT

Warranty Information

This xdoobo Home 1978 II Soundbar comes with a 1-Year Manufacturer Warranty. Please retain your proof of

purchase for warranty claims.

Customer Support

For technical assistance or warranty inquiries, please visit the official xdoxo website or contact their customer service department.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G3WZZSDR>

More documents and user manuals: <https://manuals.plus/>