Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bewinner Bewinnerwnhgzaxvt9

Bewinner Manual Bread Slicing Machine Instruction Manual

Model: Bewinnerwnhgzaxvt9

Introduction

Thank you for choosing the Bewinner Manual Bread Slicing Machine. This device is designed for efficient and precise slicing of various bread types and other ingredients, offering adjustable thickness for customized results. Please read this manual thoroughly before use to ensure safe operation and optimal performance.

Safety Information

- Always keep hands clear of the blade during operation and cleaning. The blade is sharp and can cause injury.
- Ensure the machine is placed on a stable, flat, and dry surface before use. The suction cups must be firmly attached to prevent movement.
- Keep the device out of reach of children.
- Do not attempt to slice frozen items or extremely hard materials that may damage the blade or mechanism.
- Exercise caution when handling the blade during assembly, disassembly, and cleaning.
- Inspect the machine for any damage before each use. Do not operate if any parts are damaged.

Package Contents

Please verify that all items are present in the package:

- 1 x Manual Bread Cutter
- 1 x Handle
- 4 x Suction Cups
- 1 x User Manual (this document)
- 1 x Bread Clamp

Setup

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Suction Cups:** Insert the four suction cups into the designated holes on the bottom of the wooden base. Press firmly to ensure they are securely seated.
3. **Secure to Surface:** Place the bread slicer on a clean, dry, and smooth countertop. Press down on the machine to engage the suction cups, ensuring it is stable and does not slide.
4. **Install Handle:** Attach the hand crank handle to the gear drive shaft on the side of the slicing mechanism. Tighten any securing screws if present.



Image: The underside of the bread slicer, illustrating the four suction cups designed to secure the device to a countertop.



Image: The fully assembled bread slicing machine, showing the handle and the overall structure, including the wooden base and stainless steel components.

Operating Instructions

1. **Prepare the Machine:** Ensure the slicer is securely fastened to your countertop using the suction cups.
2. **Adjust Thickness:** Rotate the knob located on the side of the machine to select your desired slice thickness. The thickness can be adjusted from 0mm to 15mm. Turn clockwise for thinner slices and counter-clockwise for thicker slices.
3. **Position Ingredient:** Place the bread or other ingredient firmly against the guide plate. Use the provided bread clamp for safety and stability, especially as the item gets smaller.
4. **Begin Slicing:** While holding the ingredient steady with one hand (or the bread clamp), slowly and steadily turn the hand crank with the other hand. The blade will rotate and slice the item.
5. **Collect Slices:** Sliced pieces will fall onto the base or can be collected directly.
6. **After Use:** Once slicing is complete, carefully remove any remaining food and proceed to cleaning.



Image: A detailed view of the gear drive system and the circular blade, demonstrating the slicing mechanism.



Image: The bread slicer in use, demonstrating how a loaf of bread is fed through the machine to produce even slices.

Adjustable Thickness

The Bewinner Manual Bread Slicing Machine features an adjustable thickness knob, allowing you to customize your slices from 0mm (paper-thin) up to 15mm (extra thick). To adjust, simply rotate the black knob on the side of the machine. Turning the knob clockwise will decrease the slice thickness, while turning it counter-clockwise will increase it. This flexibility is ideal for preparing various items, from delicate sandwich slices to hearty toast or thick-cut meats.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and hygienic operation of your bread slicer.

1. **Immediate Cleaning:** Clean the machine immediately after each use to prevent food residue from drying and hardening.

2. **Disassembly:** The machine features a removable design for easy cleaning. Carefully detach the blade guard and other removable components as instructed in the assembly section (reverse the setup steps).
3. **Washing:** Wash the blade and stainless steel components with warm, soapy water. Use a brush to remove any stubborn food particles. Rinse thoroughly under running water.
4. **Wooden Base:** Wipe the wooden base with a damp cloth. Do not submerge the wooden base in water, as this can cause damage. Dry immediately.
5. **Drying:** Ensure all parts are completely dry before reassembling or storing to prevent rust and bacterial growth.
6. **Storage:** Store the bread slicer in a clean, dry place.



Image: The bread slicer being rinsed under a faucet, highlighting its direct washability and removable components for thorough cleaning.

TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Slices are uneven or torn.	Ingredient not held firmly; blade dull; incorrect slicing speed.	Ensure bread is firmly against the guide. Use the bread clamp. Turn the crank at a consistent, moderate speed. The blade is designed for durability, but if performance degrades significantly, contact support.
Machine slides during operation.	Suction cups not engaged; countertop is wet or uneven.	Ensure countertop is clean, dry, and smooth. Press down firmly on the machine to engage all four suction cups.
Difficulty turning the hand crank.	Food residue obstructing the blade or mechanism; attempting to slice overly hard items.	Clean the machine thoroughly, especially around the blade and gear mechanism. Do not attempt to slice items beyond the machine's intended use (e.g., frozen foods).

Specifications

Feature	Detail
Model Number	Bewinnerwnhgzaxvt9
Material	Stainless steel, ABS, Solid Wood, Silicone
Blade Diameter	170mm (6.7 inches)
Adjustable Thickness	0-15mm
Product Dimensions (L x W x H)	Approx. 280 x 200 x 186mm (11.0 x 7.9 x 7.3 inches)
Item Weight	Approx. 2234g (4.91 lbs)
Handle Material	Plastic
Base Features	4 Suction Cup Feet for Stability



Image: Dimensional drawing of the bread slicer, indicating its length, width, and height for reference.

Warranty and Support

For warranty information, technical support, or any inquiries regarding your Bewinner Manual Bread Slicing Machine, please refer to the purchase documentation or contact the seller directly. Keep your proof of purchase for any warranty claims.

© 2023 Bewinner. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G42J8HF6

More documents and user manuals: **https://manuals.plus/**