

MilleLoom KMtfGpQzY9HHQUxv_Tfd-gVKT00

MilleLoom King Size Dual Control Heated Electric Blanket User Manual

Model: KMtfGpQzY9HHQUxv_Tfd-gVKT00


1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your MilleLoom Heated Electric Blanket. Failure to follow these instructions may result in fire, electric shock, or injury. Keep this manual for future reference.

- **ETL Certified Safety:** This blanket is ETL certified, ensuring it meets recognized safety standards. It features smart NTC & PTC heating wires that continuously monitor and adjust heat output to prevent overheating.
- **Do Not Use With:** Infants, children, incapacitated persons, or individuals insensitive to heat.
- **Avoid Folding or Bunching:** Do not use the blanket folded, bunched, or tucked in. This can cause localized overheating.
- **Keep Dry:** Do not use the blanket in wet conditions. Keep controls away from water.
- **Power Source:** Only connect to a 120V AC electrical outlet. Do not use with generators, power converters, or extension cords.
- **Inspection:** Regularly inspect the blanket, cord, and controls for any signs of damage. If damaged, discontinue use immediately and contact customer support.
- **Cleaning:** Always disconnect the power cord from the wall outlet and the control unit from the blanket before cleaning. Refer to the 'Maintenance' section for detailed cleaning instructions.
- **Storage:** Store the blanket loosely folded in a cool, dry place when not in use. Avoid placing heavy items on it.

FAST HEATING

Enhanced Stability & Larger Space



Upgraded PTC/NTC heating wires, safer and more reliable.
Overheat Protection & Fast Heating.



Figure 1: Internal Structure and Safety Features. This diagram illustrates the construction of the MilleLoom heated blanket, highlighting the integrated PTC/NTC heating wires designed for enhanced stability, safety, and rapid heating, preventing overheating.

2. PRODUCT OVERVIEW

The MilleLoom King Size Dual Control Heated Electric Blanket (90x100 inches) is designed to provide warmth and comfort. It features a luxurious tufted cable design with thick 240GSM jacquard long plush sherpa on one side and 220GSM sherpa fleece on the other. This blanket includes dual controls, allowing two users to independently adjust their preferred heat and time settings.

- **Material:** Plush Sherpa (240GSM jacquard long plush sherpa and 220GSM sherpa fleece).

- **Size:** King Size, 90 x 100 inches.
- **Controls:** Two independent digital controllers with LCD display.
- **Heat Settings:** 10 adjustable heat levels.
- **Timer Settings:** 1 to 10-hour auto shut-off timer.
- **Safety Features:** ETL certified, NTC & PTC heating wires for overheat protection.
- **Care:** Machine washable (after disconnecting controls).



Figure 2: MilleLoom King Size Heated Electric Blanket. This image displays the blanket folded, showcasing its plush texture and the two independent digital control units.

Excellent Design



Super Soft



Warm



Thick



Cozy

Figure 3: Blanket Design and Texture. This image illustrates the blanket's appearance when spread on a bed, along with detailed views highlighting its soft, warm, thick, and cozy characteristics.

3. SETUP INSTRUCTIONS

Follow these steps to set up your heated electric blanket for first use:

1. **Unpack:** Carefully remove the blanket and controllers from the packaging. Retain packaging for storage if desired.
2. **Inspect:** Before use, visually inspect the blanket, power cords, and control units for any signs of damage. Do not use if any damage is observed.
3. **Position the Blanket:** Lay the blanket flat on your bed, ensuring it is not folded, bunched, or tucked under the mattress. The connectors for the control units should be positioned near the head of the bed for easy access.
4. **Connect Controls:** Locate the two connection ports on the blanket. Firmly plug each control unit's connector into its respective port on the blanket. Ensure a secure connection.
5. **Connect to Power:** Plug the power cords from each control unit into a standard 120V AC wall

outlet. Avoid using extension cords or power strips.

Larger Heating Areas



Figure 4: Controller Connection. This image shows the two digital controllers and illustrates the process of connecting and disconnecting the power cord from the blanket.

4. OPERATING INSTRUCTIONS

Your MilleLoom heated blanket features dual controls, allowing independent operation for each side of the blanket.

4.1 Powering On/Off

- To turn on, press the **POWER** button on the control unit. The LCD display will illuminate.
- To turn off, press the **POWER** button again. The display will turn off, and heating will cease.

4.2 Adjusting Heat Settings

- With the blanket powered on, use the **+** or **-** buttons next to the 'Heat' indicator to cycle through 10 heat levels (L1 to L10).

- Select your desired heat level. The blanket will begin to warm up.

4.3 Setting the Timer

- Press the **TIMER** button on the control unit. The display will show the current timer setting.
- Use the **+** or **-** buttons next to the 'Time' indicator to select a shut-off time from 1 to 10 hours.
- The blanket will automatically turn off after the selected time has elapsed.
- **Note:** The blanket has an automatic 8-hour shut-off timer upon first use, which can be adjusted.

4.4 Dual Control Operation

Each control unit operates one half of the King Size blanket independently. This allows two users to customize their warmth without affecting the other side.



Figure 5: Comfortable Use. This image depicts a person enjoying the warmth of the MilleLoom heated blanket, illustrating its intended use for comfortable sleep.

5. MAINTENANCE AND CARE

Proper care will extend the life of your MilleLoom Heated Electric Blanket. Always follow these instructions carefully.

5.1 Before Cleaning

1. Ensure the blanket is turned off and unplugged from the wall outlet.
2. Disconnect both control units from the blanket by firmly pulling the connectors apart. Do not immerse control units or cords in water.

5.2 Machine Washing

- Place the blanket in a washing machine.
- Wash on a **gentle cold cycle** using a mild detergent.
- Do not bleach, iron, or dry clean.

5.3 Drying

- After washing, gently stretch the blanket back to its original size and shape.
- Air dry or tumble dry on **low heat**. Ensure the blanket is completely dry before reconnecting controls or storing.

5.4 Storage

- Ensure the blanket is clean and completely dry.
- Loosely fold or roll the blanket. Do not crease or tightly fold the heating wires.
- Store in a cool, dry place, away from direct sunlight and heavy objects that could compress the blanket.

Machine Washable



Faster Heating Rate



Higher Temperature Range

Figure 6: Machine Washable Feature. This image demonstrates the machine washability of the blanket, showing it in a washing machine and its appearance on a bed and folded.

6. TROUBLESHOOTING

If you experience issues with your MilleLoom Heated Electric Blanket, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blanket is not heating.	Not plugged in, control unit not connected, power outage, or control unit malfunction.	Ensure power cord is securely plugged into a working wall outlet. Check that the control unit is firmly connected to the blanket. Verify power to the outlet. If issues persist, contact customer support.

Problem	Possible Cause	Solution
Control unit display is off or flashing.	Power issue, loose connection, or internal error.	Unplug the blanket from the wall outlet for 5 minutes, then reconnect. Ensure all connections are secure. If flashing, it may indicate an error code; refer to the control unit's specific error guide or contact support.
Blanket is too hot or not warm enough.	Incorrect heat setting, blanket bunched, or external factors.	Adjust the heat setting on the control unit. Ensure the blanket is spread flat and not bunched. Allow 20 minutes for the blanket to reach the desired temperature.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	MilleLoom
Model Name	KMtfGpQzY9HHQUxv_Tfd-gVKT00
Size	King Size (90"L x 100"W)
Color	Off White
Fabric Type	Polyester (Sherpa)
Heat Settings	10 Levels
Timer Settings	1-10 Hours (with 8-hour default auto shut-off)
Special Feature	Durable, Dual Control, Auto Shut-Off, Machine Washable
Item Weight	9.96 pounds
UPC	199914118014




Figure 7: Blanket Size and Cord Lengths. This chart provides detailed dimensions for different blanket sizes and the lengths of their control and power cords.

8. WARRANTY AND SUPPORT

MilleLoom is committed to providing high-quality products. For specific warranty information, please refer to the documentation included with your purchase or contact MilleLoom customer support directly.

If you have any questions, require assistance with setup, operation, or troubleshooting, or need to report a defect, please contact our customer support team. Contact details can typically be found on the product packaging or the official MilleLoom website.

