



[Manuals.plus](#) /

› [HONOR](#) /

› HONOR Magic8 Lite 5G Smartphone User Manual

HONOR Magic8 Lite

HONOR Magic8 Lite 5G Smartphone User Manual

Model: Magic8 Lite

1. PRODUCT OVERVIEW

The HONOR Magic8 Lite 5G is a robust and feature-rich smartphone designed for durability and high performance. It boasts industry-leading resistance to drops, water, and dust, a long-lasting battery, a high-resolution camera, and an immersive display, all powered by an efficient processor with advanced AI capabilities.



Figure 1: HONOR Magic8 Lite 5G Smartphone, Midnight Black variant.

Key Features:

- **Triple Resistance:** SGS Five-Star Overall Drop Resistance (up to 2.5 meters), IP69K and IP68 water and dust resistance.
- **Long-lasting Battery:** 7500 mAh silicon-carbon battery with up to 3 days of autonomy and 66W SuperCharge. Functions as a portable power bank.
- **Advanced Camera System:** 108 MP Ultra-Sensing Camera with Optical Image Stabilization (OIS) and Electronic Image Stabilization (EIS) for clear photos and stable 4K videos. Includes AI photography features.
- **Immersive Display:** 6.79-inch 1.5K OLED display with 6000 nits peak brightness, 120 Hz refresh rate, and HONOR Eye Comfort Display technology.
- **Powerful Performance:** Snapdragon 6 Gen 4 (4nm) mobile platform for smooth multitasking and gaming, integrated with Google Gemini and other AI functionalities.

2. DEVICE SETUP

2.1 Package Contents

Verify that your package contains the following items:

- HONOR Magic8 Lite 5G Smartphone
- USB-C Cable
- Power Adapter (66W SuperCharge)
- SIM Ejector Tool
- Quick Start Guide
- Warranty Card

2.2 Inserting SIM Cards

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM ejector tool into the small hole next to the tray and press firmly until the tray pops out.
3. Place your Nano-SIM card(s) into the designated slots on the tray. Ensure the gold contacts face downwards. The device supports Dual SIM functionality.
4. Carefully reinsert the SIM card tray into the phone.

The device also supports eSIM functionality. Refer to your carrier for activation details.

2.3 Initial Charging and Power On

1. Connect the USB-C cable to the phone's charging port and the other end to the 66W power adapter. Plug the adapter into a power outlet.
2. Allow the phone to charge for at least 15 minutes before initial use.
3. To power on, press and hold the Power button (located on the side) until the HONOR logo appears on the screen.
4. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and Google account setup.



Figure 2: The 7500mAh silicon-carbon battery provides extended usage.

3. OPERATING INSTRUCTIONS

3.1 Basic Navigation

- **Touch Screen:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Screen:** Access apps, widgets, and notifications.
- **Gestures:** Customize navigation gestures in Settings for a fluid experience.

3.2 Camera Usage

The HONOR Magic8 Lite 5G features a 108 MP Ultra-Sensing Camera with OIS and EIS for superior image and video capture.

1. Open the Camera app from your home screen or lock screen.
2. Select your desired mode (Photo, Video, Portrait, Night, Pro, etc.).

3. Tap the shutter button to take a photo or start/stop video recording.
4. Utilize AI features like AI Eraser, AI Cutout, and AI Outpainting for enhanced photo editing.
5. For underwater photography, ensure the device is properly sealed and use the dedicated underwater mode.

Figure 3: Examples of high-quality images captured by the 108 MP camera.

3.3 Battery Management

The 7500 mAh battery is designed for extended use. To optimize battery life:

- Enable power-saving modes when battery is low.
- Adjust screen brightness and screen timeout settings.
- Close background apps not in use.
- The device supports reverse charging, allowing it to act as a power bank for other devices. Connect the devices using a compatible USB-C cable.

Figure 4: The device can charge other accessories, acting as a power bank.

3.4 Display Features

The 6.79-inch 1.5K OLED display offers vibrant visuals and eye comfort features.

- **Eye Comfort Mode:** Reduces blue light to prevent eye strain. Activate it in Display Settings.
- **Dynamic Refresh Rate:** The 120 Hz adaptive refresh rate adjusts automatically for smooth scrolling and power efficiency.
- **High Brightness:** With 6000 nits peak brightness, the display remains clear even in direct sunlight.

Figure 5: The 1.5K OLED display offers exceptional clarity and color.

3.5 AI Features and Google Gemini

The device integrates advanced AI functionalities and Google Gemini for enhanced user experience.

- **Google Gemini:** Interact with Gemini for real-time translation, information retrieval, and more.
- **AI Writing Tools:** Utilize AI to assist with text composition and productivity tasks.
- **Magic Portal:** A shortcut for AI-powered tasks.

Figure 6: Google Gemini integration for intelligent assistance.

3.6 NFC Functionality

The HONOR Magic8 Lite 5G supports Near Field Communication (NFC) for quick and secure transactions and data exchange.

- Enable NFC in your phone's Settings.
- Tap your phone to compatible NFC readers for mobile payments or to share content with other NFC-enabled devices.

4. MAINTENANCE

4.1 Cleaning Your Device

Despite its IP69K and IP68 ratings for water and dust resistance, proper cleaning helps maintain your device's longevity.

- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals, abrasive materials, or compressed air.
- If the device gets wet, wipe it dry with a clean cloth before charging or opening any ports.

4.2 Software Updates

Regular software updates provide security patches, new features, and performance improvements. Ensure your device is connected to Wi-Fi and has sufficient battery before initiating an update.

- Navigate to **Settings > System & updates > Software update** to check for available updates.

4.3 Battery Care

The 7500 mAh battery is designed for a long lifespan. To maximize its performance:

- Avoid extreme temperatures (below -30°C or above 55°C) as they can degrade battery performance.
- Use only HONOR-approved chargers and cables.
- Avoid completely draining the battery frequently.



Figure 7: The device is designed to operate in a wide range of temperatures.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your HONOR Magic8 Lite 5G.

5.1 Device Not Turning On

- Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- Press and hold the Power button for at least 10-15 seconds to force a restart.

5.2 Charging Issues

- Check if the charging cable and adapter are securely connected.
- Try using a different HONOR-approved charger and cable.
- Inspect the charging port for any debris or damage.

5.3 Camera Not Functioning

- Restart the device.
- Clear the cache and data of the Camera app in **Settings > Apps > Camera > Storage**
- Ensure no other apps are currently using the camera.

5.4 Water/Dust Exposure

While the device is highly resistant, prolonged exposure or exposure to high-pressure jets (beyond IP69K/IP68 limits) can cause damage.

- If the device gets wet, dry it thoroughly before charging.
- Do not intentionally submerge the device in water beyond specified depths or for extended periods.
- If you suspect water damage, contact customer support.




Figure 8: The device is designed with advanced water resistance.

For other issues, refer to the official HONOR support website or contact customer service.

6. SPECIFICATIONS

Feature	Specification
Brand	HONOR
Model	Magic8 Lite
RAM	8 GB
Internal Storage	512 GB
Color	Midnight Black
Battery Capacity	7500 mAh
Display	6.79-inch 1.5K AMOLED, 120Hz, 6000 nits peak brightness
Rear Camera	108 MP with OIS
Processor	Snapdragon 6 Gen 4 (4nm)
Water & Dust Resistance	IP69K, IP68
Drop Resistance	SGS Five-Star Overall Drop Resistance (up to 2.5m)
Connectivity	5G, Dual SIM, NFC
Origin	China
ASIN	B0G43TWKGS




Figure 9: Detailed product information sheet.

For more detailed energy efficiency information, please refer to the EPREL database:

<https://eprel.ec.europa.eu/qr/2515767>

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Warranty terms and conditions are typically provided with your purchase documentation. Please retain your proof of purchase for warranty claims. For specific warranty details, refer to the warranty card included in your product package or visit the official HONOR website for your region.

7.2 Customer Support

For technical assistance, service, or further inquiries, please contact HONOR customer support:

- **Official Website:** <https://www.honor.com/de/>
- **Self-Repair Support:** <https://www.honor.com/de/support/self-repair/>
- **Email Support:** support@honor.com