

HP S03-0006

HP OmniDesk Slim Desktop PC User Manual

MODEL: S03-0006

[Overview](#) [Setup](#) [Introduction](#) [Package Contents](#) [Product](#)
[Operating](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. Introduction

This manual provides essential information for setting up, operating, and maintaining your HP OmniDesk Slim Desktop PC, Model S03-0006. This desktop PC is designed for daily tasks, offering an Intel Core i3-14100 processor, ample memory, and various connectivity options for productivity and entertainment.

2. Package Contents

Verify that all items are present in the package:

- HP S03-000 OmniDesk Slim Desktop PC
- Power Supply
- USB Black Wired Keyboard (if included with specific bundle)
- USB Wired Mouse (if included with specific bundle)

Note: Additional accessories may be sold separately.

3. Product Overview

The HP OmniDesk Slim Desktop PC features a compact design with essential components for efficient computing.

Ports




Figure 3.1: HP OmniDesk Slim Desktop PC showcasing its slim profile, Intel Core i3-14100 processor, 8GB DDR5 RAM, 256GB SSD, Intel UHD Graphics 710, Wi-Fi 6, Bluetooth 5.4, Windows 11, and dual display support.

3.1. Ports and Connectors

Familiarize yourself with the various ports on your desktop PC for connecting peripherals and displays.



Figure 3.2: Front and rear port layout of the HP OmniDesk Slim Desktop PC. Front ports include a headphone/microphone combo jack, USB Type-A 5Gbps ports, and a USB Type-C 10Gbps port. Additional ports (typically rear) include 4 USB 2.0 Type-A, 1 RJ-45 (Ethernet), 1 HDMI Out, and 1 DisplayPort 1.4.

- **Front Ports:**

- Headphone/microphone combo
- USB Type-A 5Gbps signaling rate (3 ports)
- USB Type-C 10Gbps signaling rate (1 port)

- **Rear Ports:**

- USB 2.0 Type-A (4 ports)
- RJ-45 (Ethernet)
- HDMI 1.4b (1 port)
- DisplayPort 1.4a (1 port)

4. Setup Guide

Follow these steps to set up your HP OmniDesk Slim Desktop PC:

1. **Connect Monitor:** Connect your monitor to the PC using an HDMI or DisplayPort cable. Ensure the cable is securely plugged into both the PC and the monitor.
2. **Connect Peripherals:** Plug in your USB keyboard and mouse into the available USB ports on the PC.

3. **Connect Power:** Connect the power supply cable to the PC's power input, then plug the other end into a wall outlet or surge protector.
4. **Power On:** Press the power button on the front of the PC. The system will boot up, and you will see the Windows 11 setup screen.
5. **Initial Windows Setup:** Follow the on-screen instructions to complete the Windows 11 setup, including language, region, network connection, and user account creation.

5. Operating Instructions

5.1. Basic Operation

- **Power On/Off:** Press the power button to turn on the PC. To shut down, click the Start button, then Power > Shut down.
- **Restart:** Click the Start button, then Power > Restart.
- **Sleep Mode:** Click the Start button, then Power > Sleep.

5.2. Connecting to a Network

Your PC supports both wired (Ethernet) and wireless (Wi-Fi) network connections.

- **Wired Connection:** Connect an Ethernet cable from your router or modem to the RJ-45 port on the back of the PC.
- **Wireless Connection (Wi-Fi 6):**
 1. Click the Wi-Fi icon in the taskbar.
 2. Select your desired Wi-Fi network from the list.
 3. Enter the network security key (password) if prompted, then click **Connect**.

5.3. Dual Display Support

To extend your desktop to a second monitor:

1. Connect the second monitor to an available video output port (HDMI or DisplayPort) on your PC.
2. Right-click on the desktop and select **Display settings**.
3. Under "Multiple displays," select how you want the displays to behave (e.g., Extend these displays, Duplicate these displays).

6. Maintenance

- **Software Updates:** Regularly check for and install Windows updates to ensure system stability and security. Go to **Settings > Windows Update**.
- **Driver Updates:** Keep your device drivers updated. HP Support Assistant (MyHP) can help manage these updates.
- **Cleaning:** Use a soft, dry cloth to clean the exterior of the PC. Avoid liquid cleaners directly on components. Ensure ventilation openings are clear of dust.
- **Backup Data:** Regularly back up important files to an external drive or cloud storage to prevent data loss.

7. Troubleshooting

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
PC does not power on.	<ul style="list-style-type: none"> • Ensure the power cable is securely connected to both the PC and a working power outlet. • Test the power outlet with another device. • Check the power supply unit for any indicator lights.
No display on monitor.	<ul style="list-style-type: none"> • Verify the monitor is powered on and connected correctly to the PC (HDMI or DisplayPort). • Ensure the correct input source is selected on the monitor. • Try connecting the monitor to a different video output port on the PC if available.
No internet connection.	<ul style="list-style-type: none"> • For wired connection, check if the Ethernet cable is properly connected. • For Wi-Fi, ensure Wi-Fi is enabled and you are connected to the correct network with the right password. • Restart your router/modem. • Check network adapter settings in Windows.
Peripherals (keyboard/mouse) not working.	<ul style="list-style-type: none"> • Ensure USB cables are securely plugged into the PC. • Try connecting them to different USB ports. • Restart the PC.

8. Specifications

Model Name	HP OmniDesk Desktop HP S03-000 PC
Model Number	OmniDesk Slim S03-0006
Processor	Intel Core i3-14100 (3.5 GHz, 6 MB Cache)
Graphics	Intel UHD Graphics 710 (Integrated)
RAM	8 GB DDR5 (4800 MT/s), Max 64 GB
Storage	256 GB SSD (Solid State Drive)
Operating System	Windows 11 Home
Connectivity	Realtek Wi-Fi 6 (2x2), Bluetooth 5.4, Gigabit Ethernet (RJ-45)

Ports	1x USB Type-C 10Gbps 3x USB Type-A 5Gbps 4x USB 2.0 Type-A 1x HDMI 1.4b 1x DisplayPort 1.4a 1x Headphone/microphone combo 1x RJ-45
Dimensions (H x W x D)	11.61 x 3.94 x 11.97 inches
Weight	8.38 Pounds
Certifications	ENERGY STAR certified, EPEAT Gold with Climate+

9. Warranty and Support

9.1. Warranty Information

This HP OmniDesk Slim Desktop PC comes with a **90-day limited warranty**. Please refer to the warranty documentation included with your product for specific terms and conditions.

9.2. Technical Support

For technical assistance, driver downloads, or further information, please visit the official HP support website. You can also utilize the pre-installed MyHP application for device customization, optimization, and access to helpful messages and settings.

Always provide your product model number (S03-0006) and serial number when contacting support.

