

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [YASHE](#) /

› [YASHE BCD-86 86L Mini Fridge with Freezer Instruction Manual](#)

YASHE BCD-86

YASHE BCD-86 86L Mini Fridge with Freezer Instruction Manual

Model: BCD-86

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your new YASHE BCD-86 mini fridge with freezer. Keep this manual for future reference.

- **Electrical Safety:** Ensure the power supply voltage matches the rating label on the appliance. Do not use extension cords or ungrounded adapters. Always unplug the appliance before cleaning or performing maintenance.
- **Ventilation:** Allow adequate space around the appliance for proper ventilation. Do not block any ventilation openings.
- **Placement:** Place the appliance on a firm, level surface away from direct sunlight, heat sources, and moisture.
- **Flammable Materials:** Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- **Children:** This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Disposal:** Dispose of the appliance according to local regulations for flammable refrigerants and insulation gas.

2. SETUP AND INSTALLATION

Proper installation is crucial for the optimal performance and longevity of your appliance.

2.1 Unpacking

- Carefully remove all packaging materials, including foam and adhesive tape.

- Inspect the appliance for any damage during transit. If damage is found, do not operate and contact customer support.
- Remove any protective film from the doors or cabinet.

2.2 Placement

- Place the refrigerator on a flat, stable surface.
- Ensure there is sufficient space around the unit for proper air circulation (at least 10 cm on sides and back, 20 cm on top).
- Avoid placing the unit near heat sources (e.g., oven, radiator) or in direct sunlight.



Image: The YASHE BCD-86 mini fridge is designed for compact spaces, fitting well in apartments, offices, dormitories, and bedrooms.

2.3 Leveling

- The appliance is equipped with adjustable leveling feet at the bottom.
- Turn the feet clockwise to raise the unit and counter-clockwise to lower it until the refrigerator is perfectly level. This ensures proper door sealing and efficient operation.

DETTAGLI DEL PRODOTTO



Guarnizione della porta rimovibile

7 impostazioni di temperatura

gamba di livellamento regolabile

ripiano in vetro regolabile

Image: Detail showing the adjustable leveling foot, which helps stabilize the refrigerator on uneven surfaces.

2.4 Initial Use

- After placement, allow the refrigerator to stand upright for approximately **24 hours** before plugging it into a power outlet. This allows the refrigerant to settle.
- Plug the appliance into a dedicated 220V-240V AC grounded electrical outlet.
- Allow the unit to cool down for several hours before placing food inside.

3. OPERATING INSTRUCTIONS

Your YASHE BCD-86 mini fridge features a dual-door design with a top freezer and a lower refrigerator compartment, offering flexible storage and precise temperature control.

3.1 Temperature Control

- The refrigerator has an adjustable thermostat with 7 temperature settings.
- The temperature range is from -18°C (freezer) to 5°C (refrigerator).
- Turn the thermostat dial to adjust the cooling intensity. Higher numbers indicate colder temperatures.

- For optimal storage of perishable foodstuffs, a temperature range of 3-5°C in the refrigerator compartment is recommended.
- The freezer temperature adjusts automatically based on the general refrigerator settings.



Image: The interior of the fridge and freezer compartments, demonstrating storage capacity. A detailed view of the 7-level temperature control knob with an integrated LED light is also shown.

3.2 Internal LED Lighting

- The refrigerator is equipped with automatic LED lighting.
- The light illuminates automatically when the refrigerator door is opened, making it easy to locate items, especially in low-light conditions.

3.3 Flexible Storage

- The refrigerator compartment includes adjustable glass shelves and a removable storage compartment.
- You can adjust the height of the shelves to accommodate taller items like bottles or larger containers.
- The removable compartment provides additional flexibility for organizing various food items.


DETTAGLI DEL PRODOTTO



Guarnizione della porta rimovibile



7 impostazioni di temperatura



gamba di livellamento regolabile



ripiano in vetro regolabile

Image: A hand demonstrating the adjustability and removability of the glass shelf, allowing for flexible storage configurations.

3.4 Noise Level

- The appliance operates at a low noise level of approximately 45dB.
- This quiet operation makes it suitable for environments where noise reduction is important, such as bedrooms, offices, and studios.

Funzionamento a basso rumore a **45dB**



Brezza leggera

0-20db



Silenzioso

20-45db



Sussurrante

50-60db



Rumoroso

60-80db



Image: Visual representation of the refrigerator's low noise output (45dB), indicating it is suitable for quiet environments.

4. MAINTENANCE AND CLEANING

Regular maintenance ensures the efficiency and hygiene of your refrigerator.

4.1 Cleaning the Interior

- Always unplug the appliance before cleaning.
- Wash the interior with a mild detergent and warm water. Use a soft cloth or sponge.
- Rinse thoroughly and dry completely to prevent odors and mold growth.
- The removable door seal can be detached for easier cleaning and to ensure optimal hygiene.

DETTAGLI DEL PRODOTTO



Image: A hand demonstrating the removal of the door seal, highlighting its ease of cleaning for better hygiene.

4.2 Cleaning the Exterior

- Wipe the exterior surfaces with a soft cloth dampened with mild detergent.
- Do not use abrasive cleaners or solvents, as they can damage the finish.

4.3 Defrosting

- This appliance features manual defrost.
- When ice accumulation in the freezer compartment reaches about 5mm (0.2 inches) thick, it is time to defrost.
- To defrost, unplug the unit, remove all food, and leave the freezer door open. Place towels at the bottom to absorb melting ice.
- Do not use sharp objects or heating devices to speed up defrosting, as this can damage the cooling system.
- Once defrosted, clean and dry the interior thoroughly before plugging the unit back in and returning food.

5. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate	No power supply Power cord not plugged in properly Circuit breaker tripped	Check power outlet Ensure cord is securely plugged in Reset circuit breaker
Unit is not cold enough	Temperature setting is too high Door is not closed properly Excessive door openings Warm food placed inside Poor ventilation	Adjust thermostat to a colder setting Check door seal and ensure it closes completely Minimize door openings Allow food to cool before placing in fridge Ensure adequate space around the unit
Unusual noises	Unit is not level Objects touching the back of the unit Normal operating sounds	Adjust leveling feet Move unit away from walls or other objects Gurgling, humming, or clicking sounds are normal for refrigerators
Water on floor (defrosting)	Drain hole blocked Excessive ice buildup	Clear the drain hole Defrost the unit manually

6. SPECIFICATIONS

Detailed technical specifications for the YASHE BCD-86 Mini Fridge with Freezer:

Feature	Specification
Model Number	BCD-86
Total Capacity	86 Liters
Refrigerator Capacity	56 Liters
Freezer Capacity	30 Liters
Product Dimensions (D x W x H)	17.52" x 16.69" x 34.17" (44.5 cm x 42.4 cm x 86.8 cm)
Item Weight	17 Kilograms (37.4 pounds)
Voltage	220-240 Volts (AC)
Annual Energy Consumption	118 Kilowatt Hours Per Year
Defrost System	Manual
Number of Doors	2
Shelves	2 (removable glass shelves)

Feature	Specification
Crispers/Drawers	1
Special Features	Digital Temperature Control, Large Capacity, Lightweight, LED Lighting, Adjustable Leveling Feet, Removable Door Seal
Color	Black



Image: A diagram illustrating the compact dimensions of the refrigerator, including its depth, width, and height.

86L Design compatto da Litri e grande capacità



Image: An interior view highlighting the 30-liter freezer capacity and 56-liter refrigerator capacity, along with their respective optimal temperature ranges.

7. WARRANTY AND SUPPORT

Your YASHE BCD-86 Mini Fridge with Freezer comes with a standard manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions.

For technical assistance, troubleshooting beyond this manual, or to inquire about warranty claims, please contact YASHE customer support. Contact information can typically be found on the product packaging or the official YASHE website.

Included Components:

- 1 x YASHE Mini Fridge
- 2 x Removable Shelves
- 1 x Instruction Manual
- 1 x 220V-240V Power Cable

