



Manuals.plus /

› MXV /

› MXV 80-inch Fireplace TV Stand User Manual

## MXV 21029

# MXV 80-inch Fireplace TV Stand User Manual

Model: 21029

## INTRODUCTION

---

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your MXV 80-inch Fireplace TV Stand, Model 21029. This unit combines a spacious TV console with an integrated electric fireplace, designed to enhance your living space.

Please read all instructions carefully before assembly and use to ensure safe and proper operation of the product.

## IMPORTANT SAFETY INFORMATION

---

- Always place the TV stand on a flat, stable, and level surface.
- Ensure all assembly hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload the TV stand or shelves. Refer to the "Specifications" section for weight capacities.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front and sides of the electric fireplace.
- Do not block air vents of the fireplace. Ensure proper airflow for safe operation.
- The electric fireplace is equipped with an automatic safety cut-off mechanism to prevent overheating. If the heater shuts off, unplug the unit, wait 10 minutes, and then plug it back in. If it continues to shut off, contact customer support.
- Only use the provided power cord and plug into a properly grounded 120V AC outlet. Do not use extension cords or power strips.
- Do not operate the fireplace if the cord is damaged or if the unit malfunctions.
- Keep children and pets away from the fireplace when it is operating, as surfaces can become hot.

- This product is CETL certified, indicating compliance with applicable safety standards.

## PACKAGE CONTENTS

Your MXV Fireplace TV Stand is shipped in two separate boxes. Please ensure you have received both packages before beginning assembly.



Image: Product dimensions diagram indicating the product ships in two boxes. If only one box is received, please wait for the second package.

Verify that all components listed in the assembly guide (included in the packaging) are present and undamaged. Typically, the package includes:

- TV Stand panels and hardware
- Electric Fireplace insert
- Remote control for fireplace
- Assembly instructions and hardware kit

## ASSEMBLY AND SETUP

Assembly of the MXV Fireplace TV Stand requires two people. Follow the step-by-step instructions provided

in the separate assembly manual included with your product. Ensure you have a clear, spacious area for assembly.

### Key Assembly Features:

- **Adjustable Shelves:** The glass door cabinets feature movable shelves that can be adjusted vertically to accommodate various item sizes.
- **Cable Management:** Integrated cable holes are provided for organizing media player wires and other electronics.
- **Durable Hardware:** High-quality damping hinges are used for the cabinet doors, ensuring smooth and quiet operation.



Image: Detailed view of cable holes for wire management, high-quality damping hinges for cabinet doors, and matte black cabinet door handles.



Image: A cabinet with a glass door, illustrating the adjustable shelf feature and storage capacity. The desktop supports up to 135 lbs, and each shelf supports up to 35 lbs.

### TV Placement:

The MXV 80-inch Fireplace TV Stand is designed to accommodate televisions up to 90 inches in size. Ensure the TV's base fits securely on the top surface and does not exceed the stand's weight capacity.



Image: Visual representation of TV size compatibility, demonstrating that the stand can safely support televisions up to 90 inches.

## OPERATING THE ELECTRIC FIREPLACE

---

The electric fireplace can be operated using the control panel on the unit or the included remote control.

# 50" Fireplace Remote Control



Timer 0-9H



ON/OFF



12 Flame Color



Temperature  
60°F- 99°F



Adjustable Brightness  
in 5 Levels



Heater  
750W/1500W


Image: The remote control for the 50-inch electric fireplace, displaying buttons for timer, power, flame color, temperature, brightness, and heater settings.

## Remote Control Functions:

- **Power (ON/OFF):** Turns the fireplace unit on or off.
- **Timer (0-9H):** Sets an automatic shut-off timer from 1 to 9 hours.
- **12 Flame Color:** Cycles through 12 different LED flame color options.
- **Temperature (60°F-99°F):** Adjusts the desired room temperature.
- **Adjustable Brightness (5 Levels):** Changes the intensity of the flame effect.
- **Heater (750W/1500W):** Selects between low (750W) and high (1500W) heat settings.

## Flame Effects:

The electric fireplace offers realistic 3D flame effects with options for both log and crystal stone displays. You can customize the ambiance with 12 dynamic LED color options and five adjustable flame intensity levels.



## 12 Color Flame & 5-Levels Brightness



Image: Visual demonstration of the electric fireplace's flame effects, showcasing both the traditional log effect and the modern crystal stone effect, along with the range of 12 color options and 5 brightness levels.

## MAINTENANCE AND CARE

- **Cleaning the Stand:** Wipe the surfaces of the TV stand with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the melamine veneer.
- **Cleaning the Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Gently wipe the glass and exterior surfaces with a soft, lint-free cloth. Do not spray cleaners directly onto the unit.
- **Dust Removal:** Regularly dust the unit, especially around the air intake and exhaust vents of the fireplace, to maintain optimal performance and prevent dust buildup.
- **Hardware Check:** Periodically inspect all screws and fasteners to ensure they remain tight. Re-tighten if necessary.

## TROUBLESHOOTING

### Fireplace Not Turning On:

- Check if the power cord is securely plugged into a grounded outlet.

- Ensure the wall outlet is functional by testing it with another appliance.
- If the unit has overheated and shut off, unplug it for 10 minutes, then plug it back in.
- Verify that the power button on the unit or remote control is pressed.

### Remote Control Not Working:

- Replace the batteries in the remote control.
- Ensure there are no obstructions between the remote and the fireplace sensor.
- Try operating the fireplace using the control panel on the unit itself.

### No Heat Output:

- Check if the heater function is activated on the control panel or remote.
- Ensure the temperature setting is higher than the current room temperature.
- Verify that the air vents are not blocked.

For issues not covered here, please contact MXV customer support.

## SPECIFICATIONS

|                                       |                            |
|---------------------------------------|----------------------------|
| <b>Brand</b>                          | MXV                        |
| <b>Model Number</b>                   | 21029                      |
| <b>Product Dimensions (L x W x H)</b> | 80.68 x 12.6 x 22.3 inches |
| <b>Item Weight</b>                    | 80 pounds                  |
| <b>Material</b>                       | Engineered Wood            |
| <b>Color</b>                          | Black                      |
| <b>Fireplace Size</b>                 | 50 inches                  |
| <b>Heat Settings</b>                  | 750W / 1500W               |
| <b>Temperature Range</b>              | 62°F to 82°F (Adjustable)  |
| <b>Flame Colors</b>                   | 12 options                 |
| <b>Flame Brightness</b>               | 5 levels                   |
| <b>Timer</b>                          | 1 to 9 hours               |
| <b>Desktop Weight Capacity</b>        | Up to 135 lbs (60 kg)      |
| <b>Shelf Weight Capacity</b>          | Up to 35 lbs per shelf     |
| <b>TV Size Compatibility</b>          | Up to 90 inches            |
| <b>Certifications</b>                 | CETL                       |

## WARRANTY AND SUPPORT

---

Specific warranty information is typically provided with your purchase documentation. Please refer to the warranty card or contact the retailer for details regarding your product's warranty period and coverage.

For technical assistance, missing parts, or any questions regarding your MXV Fireplace TV Stand, please contact MXV customer support through the retailer where the product was purchased or refer to the contact information provided in your product packaging.