



[Manuals.plus](#) /

› [Rolanstar](#) /

› Rolanstar Twin Bed Frame Instruction Manual - Model hq-chj038-07

Rolanstar hq-chj038-07

Rolanstar Twin Bed Frame Instruction Manual

Model: hq-chj038-07

1. PRODUCT OVERVIEW

The Rolanstar Twin Bed Frame (Model hq-chj038-07) is a metal platform bed designed for comfort and functionality. It features a 2-tier storage headboard with an integrated charging station, RGB LED lighting, and four spacious sliding drawers for under-bed storage. This bed frame is engineered for easy assembly and a noise-free experience, eliminating the need for a box spring.



Figure 1: Rolanstar Twin Bed Frame with all features visible.

2. SPECIFICATIONS

Feature	Detail
Size	Twin
Material	Metal frame, Wood headboard
Product Dimensions (L x W x H)	81.5" x 39" x 41.3"
Item Weight	64.82 Pounds
Maximum Weight Recommendation	800 Pounds
Number of Drawers	4
Charging Station	2 USB Ports, 1 Type-C Port

Special Features	Easy Assembly, No Box Spring Needed, Squeak Resistant, Sturdy Structure, Water-Resistant
Color	Walnut



Figure 2: Detailed dimensions of the Twin Bed Frame.

3. SETUP AND ASSEMBLY

The Rolanstar Twin Bed Frame features a pre-assembled design for simplified setup. No complex tools are required, and the installation process is straightforward.

3.1 Unpacking and Preparation

- Carefully unpack all components from the packaging.
- Verify that all parts listed in the included assembly guide are present.
- Clear an adequate space for assembly to avoid obstruction.

3.2 Assembly Steps

Follow the step-by-step instructions provided in the physical assembly manual included with your product.

Key features for easy assembly include:

- **Pre-Assembled Frame:** Major frame sections are designed for quick connection.
- **Tool-Free Connections:** Many connections utilize a simple clip or slot-in mechanism.




Figure 3: Illustration of the pre-assembled frame components for simplified setup.

Your browser does not support the video tag.

Video 1: Overview of the Rolanstar Multifunctional Bed Frame, demonstrating its features including storage drawers, charging headboard, LED lights, and pre-assembled design.

4. OPERATING INSTRUCTIONS

4.1 LED Lights Operation

The integrated RGB LED light strip can be controlled via a dedicated app or the included remote control. This allows for customization of colors, brightness, lighting modes, and timers. The lights can also sync with music to enhance your room's ambiance.

- **Power On/Off:** Use the remote or app to turn the LED lights on or off.
- **Color Selection:** Choose from over 60,000 colors to match your preference.

- **Brightness Adjustment:** Dim or brighten the lights as needed.
- **Mode Selection:** Select various dynamic lighting modes.
- **Music Sync:** Activate music mode to synchronize lights with audio.
- **Timer Function:** Set a timer for automatic shut-off.



Figure 4: The RGB LED bed frame showcasing various color options and app control functionality.




Figure 5: A lifestyle image of the bed frame with LED lights illuminated, demonstrating its aesthetic appeal.

4.2 Charging Station Usage

The 2-tier storage headboard includes a built-in charging station with 2 USB ports and 1 Type-C port. This allows convenient charging of electronic devices directly from your bed.

- Connect your device's charging cable to the appropriate USB or Type-C port.
- Ensure the bed frame is connected to a power outlet for the charging station to function.



Figure 6: Close-up of the headboard's charging station, showing USB and Type-C ports.

4.3 Storage Drawers

The bed frame is equipped with four deep, sliding drawers, ideal for storing bedding, seasonal clothing, or other items. Each drawer includes screw clips to prevent accidental slipping.

- To open, gently pull the drawer outwards.
- To secure, ensure the screw clips are engaged to prevent the drawer from moving freely.

4 Drawers with Wheels & Buckles

Smooth to Pull, Secure to Lock



Figure 7: View of the four spacious sliding drawers with wheels and a fixture system for secure closure.

5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your Rolanstar bed frame.

- **Cleaning:** Wipe down the metal and wood surfaces with a soft, damp cloth. The wood components are water-resistant, allowing for easy cleaning of spills. Avoid harsh chemicals that may damage the finish.
- **Tightening Fasteners:** Periodically check and tighten all screws and bolts to maintain stability and prevent squeaks.
- **Drawer Maintenance:** Keep the drawer wheels and tracks free of dust and debris for smooth operation.



Figure 8: Demonstration of the water-resistant surface for easy cleaning.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your bed frame.

6.1 Noise/Squeaking

The bed frame is designed to be noise-free, featuring a soft sponge on the middle beam to prevent squeaks and metal friction. If you experience noise:

- Ensure all bolts and screws are securely tightened. Loose connections are a common cause of noise.
- Check for any foreign objects between the mattress and the frame, or between frame components.
- Verify that the mattress is properly seated within the embedded design to prevent sliding and potential noise.

Perfectly Fits 6-10" Mattresses to Prevent Sliding




Figure 9: Illustration of the embedded design that helps prevent mattress sliding and reduces noise.



Figure 10: Detail showing the noise-free construction of the bed frame.

6.2 LED Lights Not Functioning

- Ensure the bed frame's power cord is securely plugged into a working electrical outlet.
- Check the connection of the LED strip to the power source within the headboard.
- Replace the remote control batteries if the remote is unresponsive.

6.3 Charging Ports Not Working

- Confirm the bed frame is plugged into a live power outlet.
- Test with a different charging cable and device to rule out device or cable issues.

7. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or contact Rolanstar customer service directly. Keep your purchase receipt and model number (hq-chj038-07) handy for faster service.