Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

boAt Airdopes 212

boAt Airdopes 212 TWS Earbuds User Manual

Model: Airdopes 212 (PA0039)

1. Introduction

Thank you for choosing the boAt Airdopes 212 True Wireless Stereo (TWS) Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. The Airdopes 212 offers a seamless audio experience with features like 50 hours of total playtime, ENx Technology for clear calls, Beast Mode for low-latency gaming, and ASAP Charge for quick power-ups.




Image: boAt Airdopes 212 TWS Earbuds and their charging case.

2. What's in the Box

The boAt Airdopes 212 package includes the following items:

- TWS Earbuds (Left and Right)
- Charging Case
- Additional Earbuds (Eartips of various sizes)
- USB Charging Cable
- User Manual

3. Setup

3.1. Charging the Earbuds and Case

Before first use, fully charge the Airdopes 212. Place the earbuds into the charging case and connect the USB cable to the case and a power source. The LED indicator on the case will show the charging status. A full charge provides up to 50 hours of total playtime with the charging case.

- **ASAP Charge:** A quick 5-minute charge provides approximately 140 minutes of playtime.
- **Battery Average Life:** Up to 50 hours (including case charges).

Image: The boAt Airdopes 212 charging case, highlighting its 50-hour total playtime capacity.

3.2. Initial Pairing (IWP Technology)

1. **Step 1:** Open the lid of the charging case. The earbuds will automatically power on and enter pairing mode.
2. **Step 2:** Enable Bluetooth on your smartphone or other device.
3. **Step 3:** Search for "Airdopes 212" in the list of available Bluetooth devices.
4. **Step 4:** Select "Airdopes 212" to connect. Once connected, you will hear an audio prompt.
5. **Note:** The earbuds feature IWP (Insta Wake N' Pair) Technology, allowing them to connect instantly to your last paired device once the case lid is opened.

Image: A smartphone displaying a successful Bluetooth connection to the Airdopes 212 earbuds.

4. Operating the Earbuds

4.1. Touch Controls

The Airdopes 212 features intuitive touch controls on each earbud for managing music, calls, and voice assistants:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Long press (2 seconds) on either earbud.
- **Activate Voice Assistant:** Triple tap on either earbud.
- **Toggle Beast Mode:** Long press (3 seconds) on the right earbud.

Image: Visual representation of touch control functions on the earbud surface.

4.2. Beast Mode (Low Latency)

Activate Beast Mode for a low-latency audio experience, ideal for gaming. This mode minimizes audio delay, ensuring synchronized sound with on-screen action.

Image: Illustration of Beast Mode, emphasizing its 45ms low latency for an enhanced gaming experience.

4.3. ENx Technology (Environmental Noise Cancellation)

The Airdopes 212 features ENx Technology with dual microphones to enhance call clarity by suppressing environmental noise. This ensures your voice is heard clearly during calls, even in noisy surroundings.

Image: A user wearing the Airdopes 212, demonstrating the dual microphones with ENx Technology for clear communication.

4.4. boAt Signature Sound

Experience immersive audio with boAt Signature Sound, engineered for a balanced and powerful listening experience across various music genres.

Image: An exploded view diagram illustrating the internal structure of the earbud's audio driver, representing boAt Signature Sound.

5. Maintenance

5.1. Cleaning and Storage

- Gently wipe the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Ensure the charging ports are free from dust and debris.
- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid exposing the earbuds to extreme temperatures or direct sunlight for extended periods.

5.2. Water Resistance (IPX4)

The Airdopes 212 earbuds are rated IPX4 for splash and sweat resistance. This means they can withstand splashes of water and sweat, making them suitable for workouts and light rain. However, they are not designed for submersion in water or exposure to heavy rain.

- Do not intentionally submerge the earbuds in water.
- Dry the earbuds thoroughly before placing them back in the charging case if they get wet.

Image: The Airdopes 212 earbuds shown with water droplets, signifying their IPX4 splash and sweat resistance.

6. Troubleshooting

If you encounter any issues with your Airdopes 212, please refer to the following common solutions:

1. **Earbuds not pairing:**
   - Ensure both earbuds are charged.
   - Place earbuds back in the case, close the lid, wait a few seconds, then open again to re-enter pairing mode.
   - Forget "Airdopes 212" from your device's Bluetooth settings and try pairing again.
2. **No sound from one earbud:**
   - Ensure both earbuds are charged.
   - Try resetting the earbuds (refer to the full product manual for specific reset instructions if available).

- Clean the charging contacts on both the earbuds and the case.

3. **Earbuds not charging:**
   - Ensure the charging cable is securely connected to both the case and the power source.
   - Check if the power source is working correctly.
   - Clean the charging pins on the earbuds and the charging contacts in the case.
4. **Low volume:**
   - Adjust the volume on both your connected device and via the earbud controls.
   - Ensure the eartips are properly sealed in your ear canal. Try different sized eartips.

7. Specifications

Feature	Detail
Brand	boAt
Model Name	Airdopes 212
Model Number	PA0039
Ear Placement	In Ear
Form Factor	In Ear
Impedance	16 Ohms
Control Method	Touch
Battery Average Life	50 Hours (Total Playtime)
Battery Charge Time	5 Minutes (for 140 mins playtime with ASAP Charge)
Noise Control	Environmental Noise Cancellation (ENx Technology)
Audio Driver Type	Dynamic Driver
Water Resistance Level	IPX4 (Splash Resistant)
Network Connectivity Technology	Bluetooth
Wireless Technology Type	Bluetooth
Item Weight	75 Grams
Compatible Devices	Smartphones, Tablets, Laptops, Desktops

8. Warranty and Support

The boAt Airdopes 212 comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product is free from material and workmanship flaws under normal use.
For warranty claims, technical support, or any inquiries, please contact:

- **Manufacturer:** Imagine Marketing Ltd

- **Manufacturer Contact Information:** info@imaginemarketingindia.com
- **Importer Contact Information:** Imagine Marketing Ltd, Mumbai, Maharashtra 400093, India

Please retain your purchase receipt as proof of purchase for warranty services.

© 2026 boAt. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G48L1X1S

More documents and user manuals: **https://manuals.plus/**