Shot Navi VELLIX (1.2 inch)

Shot Navi VELLIX Golf GPS Watch (1.2 inch)

User Manual

Brand: Shot Navi | Model: VELLIX (1.2 inch)

1. Overview

The Shot Navi VELLIX Golf GPS Watch is designed to enhance your golf experience with precise distance measurements and intuitive course navigation. This model features an AMOLED color touch screen for clear visibility, even in bright sunlight, and utilizes the latest M10 multi-satellite GPS chip for high-accuracy positioning. It includes functions for automatic shot tracking, green undulation display, and elevation difference guidance.



The Shot Navi VELLIX display showing key distances and a detailed hole map.

2. Key Features

- **AMOLED Color Touch Screen:** The first Shot Navi model to feature an AMOLED (Organic EL) display, offering exceptional visibility with bright, high-definition visuals. Text and numbers are clearly displayed even under direct sunlight, allowing for instant information confirmation during a round.
- **Multi-Satellite Positioning:** Equipped with the latest U-blox M10 GPS chip, supporting Michibiki, GLONASS, and Galileo satellites for more precise measurements compared to conventional products.
- **Advanced Green Strategy:** Displays green undulations as a heatmap and includes arrow indicators for intuitive understanding of slopes. The green shape automatically rotates in real-time based on your current position, simultaneously showing distances to the width, depth, front edge, and center.
- **Automatic Shot Tracking:** Automatically records shots and counts scores, providing valuable data for performance analysis.
- **Elevation Difference Guidance:** Provides adjusted distances considering elevation changes, helping you make more accurate club selections.
- **Lightweight Design:** Weighing approximately 24g (excluding strap), the device offers a comfortable fit for extended wear.

- **Made in Japan Quality:** All manufacturing processes, including mounting, assembly, and inspection, are conducted at our ISO9001 certified domestic factory, ensuring high quality and reliability.
- **PGA of Japan Recommended:** Recognized for its proven track record in official matches and tournaments, it is the only product in Japan registered as a 'PGA of Japan Recommended Product'.



The lightweight design of the VELLIX ensures comfort during play.

3. Getting Started (Setup)

3.1. Initial Charge

Before first use, fully charge the device using the provided charging cable. Connect the cable to the charging port on the back of the watch and a USB power source. A full charge typically takes approximately 2-3 hours.

3.2. Power On/Off

- **To Power On:** Press and hold the power button (usually located on the side) until the Shot Navi logo appears.
- **To Power Off:** Press and hold the power button, then select 'Power Off' on the screen.

3.3. GPS Acquisition

For accurate distance measurements, the device needs to acquire GPS signals. Ensure you are in an open area with a clear view of the sky. The watch will automatically search for satellites when you start a round. Initial acquisition may take a few minutes.

The VELLIX utilizes a multi-satellite system for enhanced accuracy.

4. Operating the Device


4.1. Display and Navigation

The VELLIX features an intuitive touch screen interface. Swipe left/right or tap to navigate through different screens and functions.

4.2. Hole View and Distances

Upon starting a round, the watch displays a detailed hole view with distances to the front, center, and back

of the green. The green shape automatically rotates to match your current perspective.



Dynamic Green Eye and Slope Direction features provide detailed green information.

4.3. Fairway Navigation (Real Distance)

When the green is not directly visible (e.g., dogleg holes), the Fairway Navi displays the distance from your current position to the fairway center, and from the fairway center to the green center. This helps in planning your shots.



Fairway Navi provides real distances for strategic play.

4.4. Layup Navigation

The Layup Navi function allows you to measure distances between three points by tapping on the screen. This is useful for planning layups or checking distances to hazards.



Use Layup Navi to plan your shots and measure distances to specific points.

4.5. Automatic Shot Tracking (Auto Measure)


The watch automatically detects and records your shots, providing instant feedback on shot distance. This feature helps in analyzing your game without manual input.



Auto View Change and Auto Measure provide dynamic and automatic shot data.

4.6. Elevation Difference Guidance

The VELLIX can display distances adjusted for elevation changes. You can toggle this feature ON/OFF. When ON, the displayed distance accounts for uphill or downhill slopes, providing a more accurate 'play-as' distance.



Elevation difference guidance helps in selecting the correct club.

4.7. Notifications

When paired with your smartphone via Bluetooth (iOS 12.4+ and Bluetooth 4.0+ required), the watch can receive notifications for LINE messages, incoming calls, and SMS. This allows you to check important communications without taking your phone out of your pocket.



Receive smartphone notifications directly on your watch.

5. Specifications

Feature	Description
Screen Size	1.2 inches
Display Type	AMOLED (Organic EL)
Continuous Use Time	15 Hours
Map Type	Worldwide
Product Weight	24 grams

Connectivity Technology	Bluetooth
Features	Bluetooth, Touch Screen
Included Components	Quick Guide/Warranty Card, Charging Cable, Product Main Unit/Dedicated Case
Manufacturer Reference	JTB_172014_EG080a

6. Care and Maintenance

- **Cleaning:** Wipe the watch body and screen with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and then dry thoroughly. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** Refer to the quick guide for specific water resistance ratings. Avoid prolonged submersion or exposure to high-pressure water.
- **Charging:** Use only the provided charging cable. Do not attempt to charge if the device or cable is wet.

7. Troubleshooting

- **Device Not Powering On:** Ensure the device is fully charged. If it still doesn't turn on, try performing a soft reset (refer to the quick guide for instructions).
- **GPS Not Acquiring Signal:** Ensure you are in an open area with a clear view of the sky. Wait a few minutes for the device to acquire signals. If the issue persists, try restarting the device.
- **Inaccurate Distances:** Verify that the GPS signal is strong. Ensure the course data is up-to-date.
- **Touch Screen Unresponsive:** Restart the device. Ensure the screen is clean and dry.
- **Notifications Not Appearing:** Check Bluetooth connection with your smartphone. Ensure notification permissions are granted in your phone's settings for the Shot Navi app. Verify your smartphone meets the minimum OS and Bluetooth version requirements (iOS 12.4+ and Bluetooth 4.0+).

8. Warranty and Support

The Shot Navi VELLIX Golf GPS Watch is manufactured in Japan at an ISO9001 certified factory, ensuring high standards of quality and reliability. It is also a PGA of Japan Recommended Product, reflecting its proven performance.
For detailed warranty information, please refer to the warranty card included with your product. For further assistance or technical support, please visit the official Shot Navi website or contact customer service.



Commitment to quality and professional endorsement.