

KWENRUN B0G4BYN714

KWENRUN AI Smart Glasses User Manual

Model: B0G4BYN714

INTRODUCTION

The KWENRUN AI Smart Glasses integrate an AI voice assistant, photochromic lenses, and Bluetooth audio capabilities into a single device. This manual provides instructions for the proper setup, operation, and maintenance of your smart glasses to ensure optimal performance and longevity.

This device is compatible with both Android and iOS operating systems, connecting via Bluetooth for seamless interaction with your smartphone.

PRODUCT OVERVIEW

The KWENRUN AI Smart Glasses combine three core functionalities:

- 1. **AI Voice Assistant:** Powered by advanced AI models like ChatGPT, Gemini, and Deepseek for intelligent responses and assistance.
- 2. **Photochromic Lenses:** Lenses that automatically adjust their tint based on UV light exposure, offering UV and blue light protection.
- 3. **Bluetooth Open-Back Headphones:** Integrated audio for music playback and hands-free calls.

AI Audio Glasses

Crystal-Clear Audio with Advanced Noise-Canceling Chip

180
mAh

10
HOURS
Music Playback

8
HOURS
Calls

Figure 1: Diagram showing the components of the KWENRUN AI Smart Glasses, including open-ear speakers, Type-C charging port, photochromic lenses, and power button.

SETUP

1. Charging the Glasses

Before first use, fully charge your KWENRUN AI Smart Glasses. Use the provided Type-C charging cable.

- Connect the Type-C cable to the charging port on the glasses.
- Connect the other end of the cable to a compatible USB power source.
- A charging indicator light will typically show the charging status. Refer to the indicator light section for details.
- A full charge provides up to 10 hours of music playback or 8 hours of talk time.



Figure 2: Battery life indication for music playback and call time.

2. Downloading the Companion App

To unlock the full potential of your smart glasses, download the "Ear Dance" application on your smartphone.

- For iOS devices, search for "Ear Dance" in the Apple App Store.
- For Android devices, search for "Ear Dance" in the Google Play Store.
- Install the application and follow the on-screen instructions to create an account or log in.




Figure 3: The Ear Dance companion application interface for managing smart glasses features.

3. Bluetooth Pairing

Pair your smart glasses with your smartphone via Bluetooth 5.4 for a stable connection.

1. Ensure the smart glasses are charged and powered on.
2. Enable Bluetooth on your smartphone.
3. Open the "Ear Dance" app and follow the prompts to add a new device.
4. Select your KWENRUN AI Smart Glasses from the list of available Bluetooth devices.
5. Confirm pairing if prompted.

4. Lens Replacement

Your smart glasses come with interchangeable lenses. To replace them:

1. Gently hold the frame and carefully push the current lens out from the front.
2. Align the new lens (e.g., sunglasses lenses) with the frame grooves.
3. Press firmly until the lens clicks securely into place.

OPERATING INSTRUCTIONS

1. Basic Controls

The smart glasses feature touch controls on the right temple area for various functions:

Action	Function
Long press right temple touch area for 5 seconds	Power ON / Power OFF (when disconnected from device)
Double tap on the touch control bar	Answer Call / Hang Up Call (call volume adjustable on phone)
One tap on the touch control bar	Pause / Play Music
Double tap the touch control bar	Next Song
Long press the touch control bar	Volume +

Action	Function
Triple tap the touch control bar	Wake Up Voice Assistant




Figure 4: Touch control guide for the smart glasses.

2. AI Voice Assistant

Activate the AI voice assistant by triple-tapping the touch control bar. You can then ask questions or issue commands. The assistant leverages ChatGPT, Gemini, and Deepseek for comprehensive responses.




Figure 5: The AI voice assistant feature, powered by multiple AI models.

3. Real-Time Translation

The smart glasses offer real-time translation for over 160 languages. This feature is managed through the "Ear Dance" app.

- **Free Talk Translation:** Automatically detects, splits, and translates conversations without requiring phone interaction.
- **Voice, Video & Photo Translation:** Supports over 98% of global languages for fast and accurate translations in various formats.



Figure 6: Free Talk Translation Mode in action, showing real-time language conversion.

4. AI Meeting Assistant

Utilize the AI Meeting Assistant feature to record discussions and convert them into text. The app can also generate mind maps from the recorded content, aiding in organization and recall.




Figure 7: The AI Meeting Assistant converting audio to text and generating mind maps.

5. Music and Calls

The integrated open-back headphones allow for discreet audio playback and hands-free communication. Use the touch controls for managing music and calls as described in the Basic Controls section.

6. Photochromic Lenses

The lenses automatically adjust their tint based on ambient UV light. They provide UV protection outdoors and blue light blocking indoors, adapting to various lighting conditions.




Figure 8: Photochromic lenses demonstrating color-changing capabilities for indoor and outdoor use.

MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the lenses and frame. For stubborn smudges, a lens cleaning spray designed for eyewear can be used. Avoid abrasive materials or harsh chemicals.
- **Storage:** Store the glasses in the provided case when not in use to protect them from scratches and damage.
- **Water Resistance:** The glasses are **not water resistant**. Avoid exposure to water, rain, or excessive moisture.
- **Temperature:** Do not expose the glasses to extreme temperatures, either hot or cold, as this can affect battery life and electronic components.

TROUBLESHOOTING

- **Glasses not powering on:** Ensure the glasses are fully charged. Connect them to the Type-C charging cable and allow sufficient time to charge.
- **Cannot connect via Bluetooth:**
 - Ensure Bluetooth is enabled on your smartphone.
 - Make sure the glasses are in pairing mode (refer to the app for specific instructions).
 - Try restarting both the glasses and your smartphone.
 - Ensure the glasses are within the Bluetooth range of your device.
- **Translation not working:**
 - Verify that the "Ear Dance" app is open and connected to the glasses.
 - Check your internet connection, as translation features often require online access.
 - Ensure the correct source and target languages are selected in the app.
- **Audio quality issues:**
 - Check the volume levels on both the glasses and your connected device.
 - Ensure there are no obstructions blocking the open-ear speakers.
 - Move closer to your connected device to improve Bluetooth signal strength.

SPECIFICATIONS

Feature	Detail
Brand	KWENRUN
Model Number	B0G4BYN714
Operating System Compatibility	Android, iOS
Connectivity Technology	Bluetooth 5.4
Special Features	AI Voice & Meeting Assistant, Hands-Free Music & Calls, Photochromic Lenses, Voice & Video Translation
Battery Cell Composition	Lithium Polymer
Music Playback Time	Up to 10 hours
Talk Time	Up to 8 hours
Charging Port	Type-C
Water Resistance Level	Not Water Resistant
Human Interface Input	Microphone, Touch Control Bar
Supported Application	Voice Assistant (Ear Dance App)



Figure 9: Physical dimensions of the smart glasses.

WARRANTY INFORMATION

The KWENRUN AI Smart Glasses come with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or exposure to water. Please retain your proof of purchase for warranty claims.

SUPPORT

For further assistance, technical support, or warranty inquiries, please refer to the contact information provided on

your After-sales Warranty Card included in the product packaging.
You may also find additional support and FAQs within the "Ear Dance" companion application.

© 2026 KWENRUN. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Do I need Wi-Fi to use the KWENRUN AI Smart Glasses, and is the Ear Dance app required for operation?

To use the KWENRUN AI Smart Glasses (B0G4BYN714), the requirements depend on which features you intend to use: Wi-Fi/Internet: While the glasses connect to your phone via Bluetooth 5.4, an internet connection (Wi-Fi or...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B0G4BYN714>

More documents and user manuals: <https://manuals.plus/>