Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GarveeHome PHK_34UT

GarveeHome 6-Drawer Dresser Instruction Manual

Model: PHK_34UT

Introduction

Thank you for choosing the GarveeHome 6-Drawer Dresser. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The GarveeHome 6-Drawer Dresser, grey finish, featuring six handle-free drawers, positioned in a bedroom with decorative items on top.

Safety Information

To ensure safe use of this product, please observe the following:

- Always assemble the dresser on a soft, clean surface to prevent damage.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- **Install the anti-tipping device immediately after assembly.** This device is crucial for preventing serious injury from furniture tip-over.
- Do not allow children to climb on or play with the dresser.
- Distribute weight evenly across drawers to maintain stability.



Image: A diagram illustrating the correct installation of the anti-tipping device, showing the dresser secured to the wall, and a warning against not securing it.

Package Contents

Before assembly, verify that all components are present and undamaged. Refer to the included parts list in your packaging. If any parts are missing or damaged, contact GarveeHome customer support.

Tools Required (Not Included):

- Phillips Head Screwdriver
- Rubber Mallet (recommended for certain assembly steps)

Setup and Assembly

Follow the step-by-step instructions provided in the separate assembly guide included with your product. Pay close attention to diagrams and part labels. While assembly is designed to be straightforward, some steps may require careful attention to detail.

Important Assembly Notes:

- Identify all parts before starting. Lay them out in an organized manner.
- Do not overtighten screws, as this may damage the engineered wood material.
- If you encounter difficulty with aligning holes or parts, re-check the assembly guide for correct orientation. Sometimes, a slight adjustment or re-evaluation of the step can resolve the issue.
- Ensure drawer slides are installed correctly for smooth operation.
- **Crucially, install the anti-tipping device as the final step of assembly to secure the dresser to a wall.**

Operating Instructions

Drawer Usage:

The GarveeHome dresser features a handle-free design for a sleek appearance. To open a drawer, gently pull from the bottom edge of the drawer front. To close, push firmly until the drawer is fully seated.



Image: A detailed view of the handle-free drawer design, highlighting the smooth runners for easy opening and closing.

Storage Capacity:

The six spacious drawers provide ample storage. Organize items such as clothing, linens, or personal belongings. For optimal stability and drawer function, distribute weight evenly and avoid overloading individual drawers.



Image: The GarveeHome dresser with its drawers partially open, showcasing the internal storage space and how various items can be neatly organized.

Maintenance

Cleaning:

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the painted finish.
- Promptly clean up spills to prevent staining or damage to the engineered wood.

General Care:

- Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary.
- Keep the dresser away from direct sunlight and extreme temperature changes to prevent warping or fading.
- Avoid placing hot items directly on the surface; use coasters or protective pads.

Troubleshooting

Problem	Possible Cause	Solution
Drawers do not align or close smoothly.	Incorrect drawer slide installation; uneven assembly; loose hardware.	Verify drawer slide orientation and attachment. Check that the dresser frame is assembled squarely. Tighten all hardware.
Dresser feels unstable or wobbly.	Loose connections; uneven floor; anti-tipping device not installed.	Ensure all assembly hardware is fully tightened. Place the dresser on a level surface. **Install the anti-tipping device to secure it to the wall.**
Missing or damaged parts.	Shipping damage; packaging error.	Do not proceed with assembly. Contact GarveeHome customer support immediately for replacement parts.

Specifications

Feature	Detail
Brand	GarveeHome
Model Number	PHK_34UT
Material	Engineered Wood
Finish Type	Painted
Product Dimensions (D x W x H)	15.6" x 47.2" x 32.1"
Number of Drawers	6

Feature	Detail
Item Weight	100.1 pounds
Color	Grey
Room Type	Bedroom
Shape	Rectangular



Image: A technical drawing illustrating the overall dimensions of the dresser: 47.2 inches wide, 15.6 inches deep, and 32.1 inches high, with individual drawer dimensions also shown.

Warranty Information

For detailed warranty information regarding your GarveeHome 6-Drawer Dresser, please refer to the documentation included with your purchase or contact GarveeHome customer support directly. GarveeHome is committed to customer satisfaction and provides after-sales service for any issues that may arise.

Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact GarveeHome customer support. Our reliable team is available to assist you.
You can also visit the official GarveeHome store for more information and support resources:GarveeHome Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G4C6VLS1

More documents and user manuals: **https://manuals.plus/**