

[Manuals.plus](#) /

› [BLOKEES](#) /

› Blokees Evangelion Legend Edition: EVA-01 TV Version Action Figure Instruction Manual

BLOKEES 73514

Blokees Evangelion Legend Edition: EVA-01 TV Version Action Figure Instruction Manual

Model: 73514

INTRODUCTION

This manual provides essential instructions for the assembly, operation, and maintenance of your Blokees Evangelion Legend Edition: EVA-01 TV Version action figure. Please read this manual thoroughly before handling the product to ensure proper use and longevity.

SAFETY INFORMATION

- **Choking Hazard:** Not recommended for children under 3 years of age due to small parts that may cause choking.
- **Adult Supervision:** Use under adult supervision, especially with young children.
- **Retain Packaging:** Keep the original packaging as it contains important product information.
- **Avoid Ingestion:** Do not insert parts into the mouth, nose, or ears.
- **Heat and Liquids:** Keep the product away from fire, heat sources, and liquids.
- **Pre-Use Inspection:** Periodically check for any missing or damaged parts before each use.
- **Intended Use:** This product is designed exclusively for display and collection; it is not a protective item.

SETUP AND ASSEMBLY

The Blokees Evangelion Legend Edition EVA-01 is a model kit requiring assembly. Carefully follow the steps below.



Figure 1: All components of the EVA-01 model kit, including various body parts, accessories, and the internal frame.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all 282 pieces are present according to the included parts list (refer to Figure 1 for a general overview of components).
2. **Assemble Core Body:** Begin by assembling the internal frame of the EVA-01. Connect the torso, hip, and leg frame pieces.
3. **Attach Armor Panels:** Once the frame is stable, attach the purple, black, and yellow armor panels to the corresponding body sections. Ensure each piece clicks securely into place.
4. **Arm Assembly:** Assemble the arms, including the shoulder pylons. Exercise caution when attaching the shoulder pieces as they can be delicate.
5. **Head Assembly:** Attach the head to the neck joint.
6. **Accessory Attachment:**
 - **Hands:** Select the desired hand poses (e.g., open, gripping) and attach them to the wrist joints.
 - **Weapons:** If using the included rifle or other weapons, carefully place them into the gripping hands.
 - **Display Stand:** Assemble the display stand as shown in Figure 2. The figure can be mounted onto the stand for dynamic poses or stable display.




Figure 2: The assembled EVA-01 figure with its included accessories, such as interchangeable hands, a rifle, and a multi-part display stand.



Figure 3: The EVA-01 figure securely mounted on its display stand, showcasing its stability and dynamic posing capabilities.

OPERATING AND POSING

The EVA-01 figure features multiple points of articulation for dynamic posing. Handle with care to avoid damage.

- **Joint Movement:** Gently manipulate the joints in the arms, legs, torso, and head to achieve desired poses. Avoid forcing joints beyond their natural range of motion.
- **Shoulder Pylons:** The shoulder pylons are articulated but may have a limited range of movement. Adjust them carefully to prevent stress on the connection points.
- **Stability:** For complex or dynamic poses, utilize the included display stand to ensure the figure's stability and prevent accidental falls.








Figure 4: The EVA-01 figure demonstrating an action pose with its rifle, highlighting its articulation.



Figure 5: The EVA-01 figure in a dynamic leaping pose, showcasing its flexibility and ability to hold accessories like a knife.

MAINTENANCE

Proper care will help preserve the appearance and integrity of your action figure.

- **Cleaning:** Dust the figure regularly with a soft, dry cloth or a soft brush. For stubborn dirt, lightly dampen a cloth with water and gently wipe the surface, then dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the figure away from direct sunlight, extreme temperatures, and high humidity to prevent material degradation or discoloration.
- **Handling:** Always handle the figure by its main body parts. Avoid gripping small, delicate components or accessories too tightly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Shoulder piece breaks easily.	Thin design of the shoulder piece.	Exercise extreme caution when assembling and posing the shoulder pylons. Avoid applying excessive force.
Difficulty posing due to shoulder pylons.	Pylons limit articulation range.	Adjust pylons gently within their intended range. Some poses may be restricted. Use the display stand for support.
Figure is unstable on its own.	Center of gravity or dynamic pose.	Utilize the included display stand for enhanced stability, especially for action poses.

SPECIFICATIONS

Brand:	BLOKEES
Model Name:	Evangelion Legend Edition: 04 EvangelionTest Type-01 TV ver.
Model Number:	73514
Character:	04 EvangelionTest Type-01 TV
Material:	Polyvinyl Chloride (PVC)
Dimensions (L x W x H):	14 x 8.9 x 15.2 cm (5.5 x 3.5 x 6 inches)
Number of Pieces:	282 (as indicated on packaging)
Recommended Age:	17 years and up
Special Features:	Articulation, Collectible Figure
Assembly Required:	Yes (Model Kit)

WARRANTY AND SUPPORT

Warranty Information: Specific warranty details for this product are not provided in this manual. Please refer to the retailer's return policy or contact the manufacturer, Blokees, directly for warranty inquiries.

Customer Support: For further assistance, missing parts, or product-related questions, please contact the retailer where the product was purchased or visit the official Blokees website for support information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question