

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [VASAGLE](#) /

> [VASAGLE UKKS124K03 Bakers Rack with Power Outlet Instruction Manual](#)

VASAGLE UKKS124K03

VASAGLE UKKS124K03 Bakers Rack with Power Outlet Instruction Manual

Model: UKKS124K03 | Brand: VASAGLE

INTRODUCTION

Thank you for choosing the VASAGLE UKKS124K03 Bakers Rack with Power Outlet. This manual provides essential information for the safe assembly, operation, and maintenance of your new kitchen storage unit. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

- **Anti-Tip Kit:** Always secure the unit to the wall using the included anti-tip kit to prevent tipping. This is crucial for stability and safety, especially in households with children or pets.
- **Weight Capacity:** Do not overload shelves beyond their specified weight capacity. The maximum weight capacity for this unit is 85 pounds. Distribute weight evenly.
- **Assembly:** Follow all assembly instructions carefully. Ensure all screws and fasteners are tightened securely before use.
- **Electrical Safety:** The integrated power outlet features 3 AC outlets (125V/15A) with a maximum power of 1875 Watts. Do not exceed these electrical ratings. Ensure the power cord is not pinched or damaged.
- **Placement:** Place the unit on a flat, stable, and level surface. Use the adjustable feet to compensate for uneven floors.
- **Cleaning:** Disconnect from power before cleaning. Wipe with a dry cloth only.




Image: Anti-tip kit installation for enhanced stability.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- 1 x Kitchen Baker's Rack (Disassembled)
- 1 x Assembly Kit (Hardware and Tools)
- 1 x Anti-Tip Kit
- 6 x S-Hooks
- 1 x Instruction Manual

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is recommended to have two people for assembly, though it can be completed by one person. Follow the step-by-step instructions provided in the included assembly kit. Ensure you have a clear, spacious area for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Identify Parts:** Refer to the parts list in your assembly kit to identify each component (e.g., frame pieces, shelves, screws, etc.).
3. **Assemble Frame:** Begin by assembling the main metal frame structure according to the diagrams. Do not fully tighten screws until all parts are loosely connected.
4. **Attach Shelves:** Secure the particleboard shelves to the frame. Note the adjustable middle lower shelf; choose your desired height during this step.
5. **Install Power Outlet:** Attach the power outlet unit to the designated area on the rack. Ensure the wiring is routed safely and not pinched.
6. **Attach S-Hooks:** Install the 6 S-hooks onto the side bars for hanging utensils or towels.
7. **Final Tightening:** Once all components are in place, systematically tighten all screws and fasteners.
8. **Install Anti-Tip Kit:** Secure the rack to the wall using the provided anti-tip kit. This step is critical for safety.
9. **Adjust Feet:** Use the adjustable feet at the bottom of the rack to level the unit on uneven floors.

VASAGLE

by SONGMICS HOME



Image: Fully assembled VASAGLE Bakers Rack with Power Outlet.

Detachable & Adjustable Shelves

Fit items of various sizes



- 2 detachable shelves in the upper section
- The middle shelf in the lower section has 2 height options





Image: Detachable and adjustable shelves for versatile storage.



**Built-in
Power Strip**



125V/15A
3 AC Outlets



On/Off
Switch



Max. Power
1875 Watts



4.9 ft (1.5 m)
Extension Cord

Image: Integrated power outlet with 3 AC sockets and an on/off switch.



Image: S-hooks for hanging accessories.



Note: The image shows various options, and availability may vary.

Image: Bakers rack used as a coffee bar.

OPERATING INSTRUCTIONS

- **Power Outlet Usage:** Plug the rack's power cord into a standard wall outlet. Use the red on/off switch on the power strip to control power to the 3 AC outlets. Ensure total wattage of connected appliances does not exceed 1875 Watts.
- **Adjustable Shelves:** The middle shelf in the lower section can be adjusted to two different heights. To adjust, remove items from the shelf, detach the shelf, and re-position it to the desired height using the available mounting holes.
- **S-Hooks:** Utilize the six included S-hooks to hang kitchen utensils, towels, or other lightweight accessories on the side bars.

Your browser does not support the video tag.

Video: Demonstration of product features and usage.

MAINTENANCE

- **Cleaning:** For general cleaning, wipe the surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.

- **Dusting:** Regularly dust the shelves and frame to maintain appearance.
- **Fastener Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Power Cord Inspection:** Inspect the power cord and plug for any signs of damage. If damaged, discontinue use and contact customer support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Rack is wobbly or unstable.	Uneven floor; loose fasteners; anti-tip kit not installed.	Adjust the leveling feet. Tighten all assembly screws. Install the anti-tip kit to the wall.
Power outlets not working.	Power switch off; rack not plugged in; circuit overload.	Ensure the red on/off switch is in the 'on' position. Verify the rack's power cord is securely plugged into a functional wall outlet. Reduce the number of appliances or total wattage connected.
Shelf does not fit correctly.	Incorrect orientation; wrong shelf used; assembly error.	Refer to the assembly instructions to ensure the correct shelf is used and oriented properly. Disassemble and reassemble the section if necessary.

SPECIFICATIONS

Model: UKKS124K03

Brand: VASAGLE

Dimensions (Overall): 15.7"D x 23.6"W x 65.7"H (40 cm D x 60 cm W x 167 cm H)

Material: Alloy Steel, Engineered Wood (Particleboard)

Number of Shelves: 6

Weight Capacity: 85 lbs (38.5 kg)

Power Outlet: 3 AC Outlets, 125V/15A, Max. 1875 Watts

Power Cord Length: 4.9 ft (1.5 m)

Color: Rustic Brown + Ink Black

Special Features: Adjustable Middle Lower Shelf, Anti-Tip Kit, 6 S-Hooks

Spacious & Sturdy



Robust Panels



Image: Product dimensions and weight limits.

WARRANTY AND SUPPORT

For warranty information, missing parts, or technical support, please contact VASAGLE customer service through your purchase platform or the official VASAGLE website. Please have your model number (UKKS124K03) and purchase date ready when contacting support.

Online Support: Visit the [VASAGLE Store on Amazon](#) for more information and contact options.

