

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [GRUNDIG](#) /

› [Grundig 3-in-1 Wireless Charging Station User Manual](#)

GRUNDIG 3-in-1 Wireless Charging Station

Grundig 3-in-1 Wireless Charging Station User Manual

Model: 3-in-1 Wireless Charging Station

INTRODUCTION

Thank you for choosing the Grundig 3-in-1 Wireless Charging Station. This device is designed to provide a convenient and efficient way to charge your Qi-compatible smartphone, smartwatch, and wireless earbuds simultaneously. Please read this manual carefully before use to ensure proper operation and to maximize the lifespan of your product.

SAFETY INFORMATION

- Do not disassemble or modify the device.
- Keep the device away from water, moisture, and high temperatures.
- Avoid dropping or subjecting the device to strong impacts.
- Use only certified power adapters that meet the specified input requirements (5V/2A or 9V/1.67A).
- The charging station features integrated protection against overcharge, overheating, and overvoltage to ensure safe operation.
- Do not place metal objects or magnetic cards on the charging surface, as this may interfere with charging or damage the device.

PACKAGE CONTENTS

- 1x Grundig 3-in-1 Wireless Charging Station
- 1x USB-C Charging Cable
- 1x User Manual

PRODUCT OVERVIEW

The Grundig 3-in-1 Wireless Charging Station is designed for convenience and efficiency. It features a foldable design for portability and three dedicated charging zones for your smartphone, smartwatch, and wireless earbuds.



The Grundig 3-in-1 Wireless Charging Station provides a convenient solution for simultaneously charging your smartphone, smartwatch, and wireless earbuds.



Compact design with approximate dimensions of 13 cm in height (with phone), 15 cm in depth, and 17 cm in width, making it suitable for various spaces.



Station de charge rapide

*Prend en charge la charge rapide Qi
10W, 7,5W et 5W*

The foldable design allows for easy storage and portability, reducing clutter on your desk or nightstand.

SETUP

1. Unpack the Grundig 3-in-1 Wireless Charging Station and the USB-C cable.
2. Connect the provided USB-C cable to the input port on the charging station.
3. Connect the other end of the USB-C cable to a compatible power adapter (not included). Ensure the power adapter meets the input specifications (5V/2A or 9V/1.67A) for optimal performance, especially for fast charging.
4. Place the charging station on a stable, flat surface.

OPERATING INSTRUCTIONS

Charging Your Devices

1. **Smartphone Charging:** Place your Qi-compatible smartphone vertically on the designated smartphone charging pad. Ensure the phone is centered for proper alignment. The charging station supports 10W, 7.5W, and 5W wireless

charging for smartphones.

2. **Smartwatch Charging:** Place your Apple Watch or other compatible smartwatch on the dedicated smartwatch charging module. The module provides 2W charging output.
3. **Earbuds Charging:** Place your wireless earbuds case on the designated earbuds charging pad. This pad provides 5W charging output.

LED Indicators

The charging station is equipped with LED indicators to show the charging status of your devices. Refer to the product's specific LED behavior for detailed status information (e.g., solid light for charging, blinking for error, off for fully charged or no device).



Equipped with integrated protection against overcharge, overheating, and overvoltage for safe and reliable daily use.

MAINTENANCE

- To clean the charging station, disconnect it from the power source and wipe it with a soft, dry cloth.

- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the surface or internal components.
- Ensure the charging pads are free from dust and debris to maintain optimal charging efficiency.

TROUBLESHOOTING

- **Device not charging:**
 - Ensure the charging station is properly connected to a power source.
 - Verify that your device is Qi-compatible.
 - Check if the device is correctly aligned on the charging pad. Remove any thick cases that might interfere with wireless charging.
 - Try using a different USB-C cable and power adapter.
- **Slow charging:**
 - Ensure you are using a power adapter that supports fast charging (e.g., a Quick Charge 3.0 or Power Delivery adapter).
 - Confirm proper alignment of the device on the charging pad.
- **LED indicators not working:**
 - Check the power connection to the charging station.
 - If the issue persists, contact customer support.

SPECIFICATIONS

Brand	GRUNDIG
Model	3-in-1 Wireless Charging Station
Input	USB-C 5V/2A, 9V/1.67A
Smartphone Output	10W / 7.5W / 5W (Qi)
Smartwatch Output	2W
Earbuds Output	5W
Dimensions (folded)	Approx. 140 × 70 × 14 mm
Weight	Approx. 150 g
Wireless Charging Zones	Smartphone, Smartwatch, Earbuds
Compatibility	Qi-enabled smartphones, Apple Watch, other smartwatches, wireless earbuds
Protection Features	Overcharge, Overheat, Overvoltage Protection

WARRANTY INFORMATION

This Grundig 3-in-1 Wireless Charging Station comes with a manufacturer's warranty of **2 years** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or failure to follow the

instructions in this manual. Please retain your proof of purchase for warranty claims.

For full warranty terms and conditions, please refer to the official Grundig website or contact customer support.

SUPPORT

If you encounter any issues or have questions regarding your Grundig 3-in-1 Wireless Charging Station that are not addressed in this manual, please visit the official Grundig website for further assistance or contact their customer support.

You can find more information and support resources by visiting the [GRUNDIG Brand Store](#).