

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [AONIMI](#) /

> [AONIMI Portable Charger HX100M9 User Manual](#)

## AONIMI HX100M9

# AONIMI Portable Charger HX100M9 User Manual

## 1. INTRODUCTION

Thank you for purchasing the AONIMI Portable Charger HX100M9. This device is a versatile 26800mAh power bank designed for convenient charging of multiple electronic devices. It features built-in charging cables, an integrated AC wall plug for self-charging, and multiple output ports. Please read this manual carefully to ensure proper use, maintenance, and optimal performance of your portable charger.

## 2. PRODUCT OVERVIEW

The AONIMI Portable Charger HX100M9 is an all-in-one charging solution. Its compact and lightweight design makes it ideal for travel. Key features include:

- **High Capacity:** 26800mAh battery for multiple device charges.
- **Integrated AC Wall Plug:** Foldable plug for direct self-charging from a wall outlet.
- **Built-in Cables:** Includes a Lightning cable and a USB-C cable for direct device connection.
- **Multiple Outputs:** Features additional USB-A and USB-C ports, allowing up to four devices to charge simultaneously.
- **Pass-through Charging:** Capable of charging external devices while the power bank itself is being recharged via the AC plug.
- **LCD Digital Display:** Provides an accurate indication of the remaining battery level.

## 3. PACKAGE CONTENTS

Please check the package for the following items:

- 1x AONIMI 26800mAh Portable Charger Power Bank (Model: HX100M9)
- 1x User Manual

## 4. PRODUCT COMPONENTS

Familiarize yourself with the components of your AONIMI Portable Charger:



Image: AONIMI Portable Charger HX100M9. This image displays the compact design of the power bank, highlighting its built-in Lightning and USB-C cables, the foldable AC wall plug on one side, and the additional USB-A and USB-C output ports. The LCD display is also visible, showing battery status.

The device features a sleek casing, an LCD screen for battery percentage, a foldable AC plug for direct wall charging, and integrated cables (Lightning and USB-C) for various devices. Additional USB-A and USB-C ports are available for broader compatibility.

## 5. CHARGING THE POWER BANK (SELF-CHARGING)

Before first use, fully charge the power bank. To recharge the AONIMI Portable Charger:

1. Locate the foldable AC wall plug on the side of the power bank.
2. Fold out the AC plug.
3. Insert the power bank directly into a standard wall outlet.
4. The LCD display will show the charging status, indicating the battery percentage increasing.
5. The power bank will be fully charged within approximately 5 hours. Disconnect it from the wall outlet once fully charged.

Alternatively, the power bank can be recharged via its USB-C input port using a compatible USB-C cable and wall adapter (not included).

## 6. OPERATING INSTRUCTIONS (CHARGING EXTERNAL DEVICES)

---

The AONIMI Portable Charger can charge up to four devices simultaneously.

### Using Built-in Cables:

1. Identify the appropriate built-in cable for your device (Lightning for Apple devices, USB-C for compatible Android/other devices).
2. Gently pull out the desired cable from its storage slot.
3. Connect the cable to your device's charging port.
4. Charging will begin automatically. The power bank's LCD display will show its remaining charge.

### Using USB Ports:

1. Use your device's original charging cable or a certified compatible cable.
2. Connect one end of the cable to the USB-A or USB-C output port on the power bank.
3. Connect the other end of the cable to your device's charging port.
4. Charging will commence automatically.

### Pass-through Charging:

The power bank supports pass-through charging. This means you can recharge the power bank via its AC wall plug while simultaneously charging your mobile devices using the built-in cables or USB output ports.

## 7. SAFETY PRECAUTIONS

---

To ensure safe operation and prevent damage to the device or injury, please observe the following:

- Do not expose the power bank to extreme temperatures (hot or cold), direct sunlight, or high humidity.
- Do not disassemble, modify, or attempt to repair the device.
- Keep the power bank away from water and other liquids.
- Avoid dropping or subjecting the device to strong impacts.
- Use only certified charging cables and adapters.
- Keep out of reach of children.
- Do not use the power bank if it is damaged, swollen, or leaking.
- Dispose of the product responsibly according to local regulations.

## 8. CARE AND MAINTENANCE

---

Proper care will extend the life of your AONIMI Portable Charger:

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the power bank in a cool, dry place when not in use. Avoid storing it in places with extreme temperatures or high humidity.
- **Battery Life:** For optimal battery health, fully charge the power bank at least once every three months if it is not used regularly.
- **Cable Care:** When retracting or extending the built-in cables, do so gently to prevent damage.

## 9. TROUBLESHOOTING

---

If you encounter issues with your portable charger, refer to the following common solutions:

- **Device not charging:**

- Ensure the power bank is sufficiently charged (check the LCD display).
- Verify that the charging cable is securely connected to both the power bank and your device.
- Try a different cable or port on the power bank.
- Ensure your device's charging port is clean and free of debris.

- **Power bank not recharging:**

- Ensure the AC wall plug is fully extended and securely inserted into a working wall outlet.
- If using the USB-C input, ensure the cable and wall adapter are functional and properly connected.
- Try a different wall outlet.

- **Slow charging:**

- Ensure you are using a fast-charging compatible cable and your device supports fast charging.
- Charging multiple devices simultaneously may reduce the charging speed for each individual device.

## 10. TECHNICAL SPECIFICATIONS

<b>Model Number</b>	HX100M9
<b>Battery Capacity</b>	26800mAh
<b>Product Dimensions</b>	5.9 x 2.7 x 0.7 inches (approximate)
<b>Item Weight</b>	3.53 ounces (approximate)
<b>Input (AC Wall Plug)</b>	Standard AC input (details not specified, assumes typical wall outlet)
<b>Input (USB-C)</b>	USB-C (details not specified)
<b>Output (Built-in Lightning Cable)</b>	Standard Lightning output
<b>Output (Built-in USB-C Cable)</b>	USB-C output (supports fast charging)
<b>Output (USB-A Port)</b>	USB-A output
<b>Output (USB-C Port)</b>	USB-C output (supports fast charging)
<b>Simultaneous Charging</b>	Up to 4 devices

## 11. WARRANTY AND CUSTOMER SUPPORT

AONIMI provides a worry-free 24-month warranty for this product, covering manufacturing defects from the date of purchase. Additionally, lifetime technical support and friendly customer services are available.

For warranty claims, technical assistance, or any product-related inquiries, please contact AONIMI customer support through the retailer's platform or the official AONIMI website. Please have your purchase receipt and product model number (HX100M9) ready when contacting support.

