

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FREDEES](#) /

› [FREDEES Arched Display Cabinet QM-97053-25 User Manual](#)

FREDEES QM-97053-25

FREDEES Arched Display Cabinet

MODEL: QM-97053-25

User Manual

Introduction

Thank you for choosing the FREDEES Arched Display Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

- Always assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not use damaged parts.
- **Important:** Secure the cabinet to the wall using the provided anti-tip kit. This is crucial to prevent tipping, especially in households with children or pets.
- Do not overload shelves. Refer to the specifications for weight limits.
- Keep electrical components (LED lights) away from water.




Figure 1: Anti-Tip Kit Installation Diagram. This kit is essential for stability and safety.

Package Contents

Verify that all components listed below are included in your package:

- Arch Display Cabinet x1
- Installation Package x1 (includes hardware and tools)
- User Manual x1

Specifications

Feature	Detail
Brand	FREDEES
Model Name	Arched Display Cabinet
Model Number	QM-97053-25
Color	Arch-white
Product Dimensions (D x W x H)	13.78" x 27.55" x 76.77"
Item Weight	80.7 Pounds
Material	Engineered Wood, Metal (Handle)
Number of Shelves	6 (2 adjustable, 4 fixed)
Special Features	2 Adjustable Shelves, 3-Color LED Lights, Arch Storage Space, Human Sensor, Smoked Black Acrylic Doors
Assembly Required	Yes

PRODUCT SIZE



Figure 2: Product Dimensions and Features Overview.

Setup and Assembly

The FREDEES Arched Display Cabinet is designed for straightforward assembly. Follow the step-by-step instructions provided in the included Installation Package. It is recommended to have a second person assist during certain steps for ease and safety.

Key Assembly Points:

- **Door Installation:** The smoked black acrylic doors can be attached or left off, depending on your preference for an open or closed display. The doors feature a pneumatic design for smooth operation.
- **Adjustable Shelves:** Two of the shelves are adjustable. Plan your shelf placement before securing them to accommodate items of various heights.
- **Anti-Tip Kit:** Always install the anti-tip kit as instructed in the safety section to prevent accidental tipping.



Figure 3: Cabinet Interior with Doors Open, showcasing adjustable shelves.

Operating Instructions

LED Lighting System:

The cabinet features integrated LED lighting with three color modes and a smart human sensor.

1. **Power Connection:** Connect the power cord from the LED system to a nearby electrical outlet.
2. **Changing Light Colors:** Locate the touch-sensitive button on the side of the cabinet. Short press the button to cycle through the three available light colors: blue, white, and yellow.
3. **Human Sensor:** The built-in human sensor automatically activates the lights when motion is detected within approximately 1 meter and turns them off after 30 seconds of inactivity, conserving energy.



Figure 4: LED Lighting Options (White, Yellow, Blue).



Figure 5: Smart Human Sensor Functionality.

Adjustable Shelves:

The two adjustable shelves allow for customized storage space. To adjust a shelf:

1. Empty the shelf of all items.
2. Carefully lift the shelf and remove the support pins from their current holes.
3. Reinsert the support pins into the desired holes at the new height. Ensure all four pins are securely in place and level.
4. Place the shelf back onto the support pins.



Figure 6: Adjustable Shelf Mechanism.

Maintenance

The cabinet's high-quality MDF construction and waterproof, scratch-resistant surface make it easy to maintain.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Dusting:** Regularly dust the cabinet and shelves to maintain its appearance.
- **Door Care:** The smoked black acrylic doors can be cleaned with a soft cloth and a mild acrylic

cleaner if necessary.

Troubleshooting

- **LED Lights Not Working:** Check if the power cord is securely plugged into both the cabinet and the electrical outlet. Ensure the outlet is functional.
- **Doors Not Closing Properly:** Verify that the hinges are correctly aligned and tightened. Ensure no items on the shelves are obstructing the doors.
- **Cabinet Wobbles:** Confirm that the cabinet is placed on a level surface. Re-check all assembly screws for tightness. Ensure the anti-tip kit is properly installed and secured to the wall.

Warranty and Support

For warranty information or technical support, please contact FREDEES customer service. Refer to your purchase documentation for specific warranty terms and contact details.

Customer Service: Please visit the official FREDEES website or contact your retailer for assistance.