

[Manuals.plus](#) /

› [Powants](#) /

› Powants 24x36 Inch Folding A-Frame Sidewalk Sign Instruction Manual

Powants A Frame Sign-010

Powants 24x36 Inch Folding A-Frame Sidewalk Sign Instruction Manual

Model: A Frame Sign-010

1. PRODUCT OVERVIEW

The Powants Folding A-Frame Sidewalk Sign is a versatile, double-sided display solution designed for outdoor and promotional use. It features a robust all-iron frame and includes both a whiteboard and a blackboard surface, allowing for customizable messaging with dry erase markers. The sign is foldable for easy transport and storage.




Image 1.1: The Powants A-Frame Sign, showcasing the frame, included whiteboard, blackboard, and non-slip feet. Dry erase markers are recommended for use.

2. PACKAGE CONTENTS

Please verify that all components are present in the package:

- 1 x Folding A-Frame Sign (Black, all-iron frame)
- 1 x PVC Whiteboard (24x36 inches)
- 1 x PVC Blackboard (24x36 inches)

The PVC boards are designed for durability and non-fading performance.

3. SETUP AND ASSEMBLY

Assembly of the A-Frame Sidewalk Sign is straightforward and typically takes 5-8 minutes. Follow these steps for proper setup:

1. Carefully remove all components from the packaging.
2. Unfold the A-frame structure until it forms a stable 'A' shape. Ensure the locking mechanisms (if any) are engaged to secure the frame in its open position.
3. Remove the protective films from both sides of the PVC whiteboard and blackboard.
4. Insert the PVC whiteboard into one side of the A-frame. Ensure it is securely seated within the frame's grooves or clips.

5. Insert the PVC blackboard into the other side of the A-frame, ensuring it is also securely seated.
6. Verify that the sign stands stably on a flat surface. The sign is equipped with non-slip feet for enhanced stability.

A Frame + 1pc PVC Whiteboard + 1pc PVC Blackboard



Recommend using Dry Erase Markers.

Image 3.1: Detailed dimensions of the A-Frame Sign, showing its height of 41.54 inches and width of 22.64 inches when open, and its folded thickness of 2.56 inches.

4. OPERATING INSTRUCTIONS

The A-Frame sign is designed for easy use and display of your messages.

- **Writing on Surfaces:** Use dry erase markers exclusively on both the whiteboard and blackboard surfaces. Do not use permanent markers or chalk on the whiteboard.
- **Display:** Position the sign on a flat, stable surface. Its heavy-duty construction and non-slip feet make it suitable for various outdoor and indoor environments.
- **Folding for Storage:** To fold the sign, gently collapse the A-frame structure. Ensure the PVC boards are removed or secured if the frame allows for folding with boards inserted.



Image 4.1: The A-Frame sign positioned outside a flower shop, demonstrating its use as a promotional display.



Image 4.2: The A-Frame sign in an outdoor market setting, showcasing its versatility for various business environments.

5. MAINTENANCE

Proper maintenance ensures the longevity and appearance of your A-Frame sign.

- **Cleaning Surfaces:** The whiteboard and blackboard surfaces can be easily cleaned with a dry erase eraser or a soft, damp cloth. For stubborn marks, use a specialized dry erase board cleaner.
- **Frame Care:** The frame surface is treated with waterproof paint. To clean the frame, wipe it with a damp cloth and mild detergent if necessary. Avoid abrasive cleaners.
- **Storage:** When not in use, store the sign in a dry, protected area to prevent unnecessary wear and tear.



Frame surface treated with waterproof paint

PVC whiteboard and PVC blackboard are completely waterproof

Image 5.1: A close-up view of the A-Frame sign's frame, highlighting its waterproof paint treatment and durable construction.

6. TROUBLESHOOTING

If you encounter issues with your A-Frame sign, consider the following:

- **Boards Not Staying Flat:** If the PVC boards appear curled or do not sit flat within the frame, ensure they are fully inserted into the designated grooves. In some cases, additional backing material (not included) may be required to provide extra rigidity and ensure the boards remain flat and secure.
- **Difficulty Erasing Marks:** Ensure you are using only dry erase markers. If marks are difficult to erase, try a dry erase board cleaner. Avoid using permanent markers, as they will stain the surface.
- **Sign Instability:** Confirm the A-frame is fully extended and locked into position. Ensure the sign is placed on a level surface.

7. SPECIFICATIONS

Brand	Powants
-------	---------

Model Number	A Frame Sign-010
Size	24x36 inches (for display area)
Product Dimensions (L x W)	41.34"L x 23.62"W (when open)
Color	Black
Material	All-iron frame, Polyvinyl Chloride (PVC) boards
Mounting Type	Floor Standing
Orientation	Landscape
Weight	Approximately 9.56 lb