

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [Baetaey](#) /
- › Baetaey WiFi Booster Instruction Manual

## Baetaey B0G4ZSSFKP

# Baetaey WiFi Booster Instruction Manual

Model: B0G4ZSSFKP

## 1. INTRODUCTION

The Baetaey WiFi Booster is designed to extend the coverage of your existing wireless network, eliminating dead zones and improving signal strength throughout your home or office. This device acts as a repeater, taking your current WiFi signal and rebroadcasting it to reach areas that previously had weak or no signal. It supports a 2.4 GHz radio frequency for reliable connectivity.



*Image: People using various devices with a Baetaey WiFi Booster in the center, illustrating boosted WiFi coverage throughout a home.*

## Boost Your Existing WiFi Signals' Coverage

No more worrying about low signal areas and enjoy a WiFi signal that can cover your entire home or office. The WiFi extender connects wirelessly to your existing WiFi signal and extends its coverage to areas like never before.



Image: A diagram illustrating how the WiFi booster extends the signal coverage within a house, reaching areas previously without strong WiFi.

## 2. SETUP INSTRUCTIONS

Follow these steps to set up your Baetaey WiFi Booster:

1. **Power On:** Plug the WiFi Booster into an electrical outlet in a central location between your router and the area with weak WiFi signal. Wait for the power indicator light to turn on.
2. **Connect to Booster's Network:** On your computer or mobile device, search for available WiFi networks. Connect to the network named 'Baetaey\_EXT' or similar (check the label on your device for the exact name). No password is required for the initial connection.
3. **Access Setup Page:** Open a web browser (e.g., Chrome, Firefox) and enter the default IP address or domain name (usually found in the quick start guide or on the device label, common examples are 192.168.1.254 or repeater.net).
4. **Login:** Enter the default username and password (often 'admin' for both, refer to your device's label).
5. **Select Operating Mode:** The setup wizard will guide you. Choose the 'Repeater' or 'Extender' mode to boost your existing WiFi signal.
6. **Select Host Network:** Scan for available WiFi networks and select your main home WiFi network. Enter your main WiFi network's password when prompted.
7. **Configure Extended Network:** You can choose to keep the same network name (SSID) as your main router or create a new one (e.g., 'YourNetworkName\_EXT').
8. **Complete Setup:** Follow the on-screen instructions to finalize the setup. The booster will restart. Once restarted, the indicator lights should show a successful connection to your main router.
9. **Reconnect Devices:** Disconnect your devices from the booster's temporary network and reconnect them to the newly extended network.

The Baetaey WiFi Booster features a **1-Tap Setup** for simplified configuration. Refer to the device's specific quick start guide for detailed instructions on using this feature.

Designed for everyone to enjoy a more efficient network that loads faster without the need for performance



Image: A close-up of the Baetaey WiFi Booster, highlighting its design and antennas, ready for initial setup.

### 3. OPERATING MODES

The Baetaey WiFi Booster supports multiple operating modes to suit various networking needs. It offers **4 Modes**, typically including:

- **Repeater Mode (Default):** Extends the coverage of an existing wireless network. This is the most common mode for boosting WiFi signals.
- **Access Point (AP) Mode:** Converts a wired network connection into a wireless one. Ideal for creating a new WiFi hotspot from an Ethernet port.
- **Router Mode:** Functions as a primary router, creating a new private network. (Less common for boosters, but some advanced models may include this).
- **Client Mode:** Allows wired-only devices to connect to a wireless network.

You can switch between these modes via the web management interface during or after the initial setup, depending on your specific network requirements.

### 4. KEY FEATURES

- **High-Performance WiFi Chip:** Equipped with a smart advanced processor for stable and efficient signal amplification. Includes features like overvoltage protection and LED indicators.




#### Ethernet Port

Quickly connect your device to an Ethernet port and experience wired speed and reliability anywhere in your home.

*Image: A detailed view of the internal high-performance WiFi chip, highlighting its advanced processing capabilities and integrated features.*

- **Ethernet Port:** Provides a wired connection option for devices such as smart TVs, gaming consoles, or desktop computers, offering stable and fast internet access.



*Image: The Baetaey WiFi Booster with an Ethernet cable connected to its port, demonstrating its wired connectivity option.*

- **Powerful External Antennas:** Features four adjustable external antennas to centralize WiFi to devices for stronger and more reliable connectivity.



*Image: A close-up view of the four external antennas, emphasizing their role in boosting WiFi signal strength.*

- **Universal Compatibility:** Connects to over 70 devices and is compatible with all WiFi-enabled devices, routers, and access points.



*Image: A diagram showing the WiFi booster connected to various device icons, representing its universal compatibility with different types of WiFi-enabled electronics.*

- **Wireless Security Protocols:** Supports various wireless security protocols to protect your network.
- **WPS / Reset Button:** For quick setup via WPS or to restore factory settings.

## 5. MAINTENANCE

---

To ensure optimal performance and longevity of your Baetaey WiFi Booster, consider the following maintenance tips:

- **Optimal Placement:** Position the booster in an open area, away from obstructions like thick walls, large metal objects, or other electronic devices that may cause interference.
- **Firmware Updates:** Periodically check the manufacturer's website for firmware updates. Keeping your device's firmware up-to-date can improve performance, security, and stability.
- **Cleaning:** Keep the device clean and free from dust. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners.
- **Avoid Overheating:** Ensure proper ventilation around the device. Do not cover the ventilation holes.
- **Regular Restart:** Occasionally restarting the booster (unplugging and plugging it back in after 10-15 seconds) can help resolve minor connectivity issues and refresh its performance.

## 6. TROUBLESHOOTING

---

If you encounter issues with your Baetaey WiFi Booster, try the following troubleshooting steps:

- **No Power:**
  - Ensure the booster is securely plugged into a working electrical outlet.
  - Check if the outlet is receiving power.
- **No Signal / Weak Signal:**
  - **Reposition the Booster:** Move the booster closer to your main router. The ideal location is halfway between your router and the WiFi dead zone.
  - **Check Router Signal:** Ensure your main router is functioning correctly and emitting a strong signal.
  - **Interference:** Move the booster away from other electronic devices (microwaves, cordless phones, Bluetooth devices) that might cause interference.
  - **Adjust Antennas:** Try adjusting the position of the external antennas for better reception.
- **Slow Connection Speed:**
  - **Bandwidth Limitations:** WiFi extenders typically halve the bandwidth as they receive and re-transmit the signal on the same frequency. This can result in slower speeds compared to a direct connection to the main router.

- **Overloaded Network:** Too many devices connected to the extended network can reduce speed.
- **Interference:** As above, check for sources of interference.
- **Router Speed:** Ensure your main router is providing adequate internet speed.
- **Cannot Access Setup Page:**
  - Ensure your device is connected to the booster's temporary WiFi network (e.g., 'Baetaey\_EXT').
  - Try a different web browser.
  - Clear your browser's cache and cookies.
  - Reset the booster to factory defaults using the reset button (usually a small pinhole button) and try setup again.
- **Connection Drops Frequently:**
  - **Firmware Update:** Ensure the booster's firmware is up to date.
  - **Reposition:** Experiment with different locations for the booster.
  - **Channel Interference:** Your router's WiFi channel might be congested. Try changing the WiFi channel on your main router.

## 7. SPECIFICATIONS

<b>Model</b>	B0G4ZSSFKP
<b>Brand</b>	Baetaey
<b>Wireless Communication Standard</b>	2.4 GHz Radio Frequency
<b>Data Transfer Rate</b>	300 Megabits Per Second
<b>Frequency Band Class</b>	Single-Band
<b>Special Features</b>	1-Tap Setup, 4 Modes, Adjustable External Antennas, Wireless Security Protocols, Bank-Level Financial Security
<b>Item Weight</b>	7.4 ounces
<b>Package Dimensions</b>	10.16 x 3.66 x 2.17 inches

## 8. WARRANTY AND SUPPORT

The Baetaey WiFi Booster comes with the following assurances:

- **18-Month Warranty:** Your device is covered by an 18-month warranty from the date of purchase.
- **Lifetime Support:** Access to lifetime technical support and assistance for any product-related inquiries.
- **30-Day Free Trial:** A 30-day trial period is offered to ensure satisfaction with the product.
- **24/7 Customer Support:** Dedicated customer support is available around the clock to assist you.

For support, please refer to the contact information provided with your product packaging or visit the official Baetaey website.