Bellemave FST00216-CF-AP1

Bellemave Full Loft Bed with Stairs and Movable Desk and Shelves Instruction Manual

Model: FST00216-CF-AP1

Introduction

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Bellemave Full Loft Bed with Stairs and Movable Desk and Shelves. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Ensure all parts are present and undamaged before proceeding.

Safety Information

- **Weight Capacity:** The bed has a weight capacity of 600 lbs. The movable desk has a weight capacity of 66 lbs. The desk storage shelf has a weight capacity of 22 lbs. Do not exceed these limits.
- **Safety Rails:** The upper bunk is equipped with safety rails. Ensure they are properly installed and maintained to prevent falls.
- **Assembly:** Assembly should be performed by at least two adults. Follow all steps precisely.
- **Regular Checks:** Periodically check all bolts and screws to ensure they are tight. Retighten as necessary.
- **Ventilation:** Ensure adequate ventilation around the bed, especially if using the desk area for extended periods.

Setup and Assembly

Your Bellemave Full Loft Bed requires assembly. A detailed assembly instruction guide and all necessary tools are included with your purchase. Please refer to that guide for step-by-step instructions. The following provides a general overview and important considerations:

1. **Unpack Components:** Carefully unpack all boxes and identify all parts against the provided parts list

in your separate assembly guide.

2. **Prepare Workspace:** Clear a spacious area for assembly. It is recommended to assemble the bed in the room where it will be used.
3. **Assemble Frame:** Follow the instructions to assemble the main loft bed frame, ensuring all connections are secure.
4. **Install Stairs:** Attach the storage staircase, ensuring it is firmly connected to the main frame.
5. **Assemble Movable Desk and Shelves:** Assemble the movable desk and its integrated shelving unit according to the instructions.
6. **Position Desk:** The desk is designed to be movable. Position it as desired under the loft bed or as a standalone unit.
7. **Final Checks:** Before use, double-check all bolts, screws, and connections to ensure they are fully tightened and secure.



Image: The Bellemave Full Loft Bed with the movable desk positioned separately, showcasing the bed's overall structure and potential room arrangement.



Image: The Bellemave Full Loft Bed with the movable desk and its shelving unit placed directly beneath the loft, illustrating a compact setup.

Operation

Using the Loft Bed

- **Access:** Use the integrated stairs to access the upper bunk. Always use caution when climbing or descending.
- **Mattress:** Place a standard full-size mattress on the slat base. Ensure the mattress fits snugly within the guardrails.
- **Guardrails:** The guardrails are designed for safety. Do not remove or modify them.

Using the Movable Desk and Shelves

- **Positioning:** The desk unit can be moved freely. It can be placed directly under the loft bed for a compact study area or moved away for a separate workspace.
- **Storage:** Utilize the multi-tiered open shelving units above the desk for organizing books, stationery, and other items. Do not overload shelves beyond the 22 lbs capacity.
- **Desk Surface:** The desk surface is suitable for computers, writing, and other activities. Do not place excessively heavy items on the desk (max 66 lbs).

Using the Storage Stairs

- **Storage Compartments:** Each step of the staircase features built-in storage shelves. These can be used for books, toys, or other small items.
- **Access:** Open the storage compartments carefully. Ensure items are placed securely to prevent them from falling out.



Image: A detailed view of the movable desk and its shelving, demonstrating its functionality as a study or work area.



Image: A close-up of the storage stairs, highlighting the integrated shelves within each step.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Tighten Hardware:** Periodically check all bolts, screws, and fasteners. Retighten them as needed to ensure the bed remains stable and secure.
- **Avoid Moisture:** Protect the wood from excessive moisture and direct sunlight to prevent warping or fading.
- **Weight Distribution:** Distribute weight evenly on the bed and shelves to prevent stress on the structure.

Troubleshooting

Problem	Possible Cause	Solution
Bed feels wobbly or unstable	Loose hardware (bolts, screws)	Check and tighten all assembly hardware. Ensure the bed is on a level surface.
Squeaking noises	Loose connections or friction between parts	Tighten all bolts. Apply a small amount of paraffin wax or silicone spray to contact points if squeaking persists.
Desk or shelves not moving smoothly	Obstruction or uneven surface	Clear any debris from the path of the movable desk. Ensure the floor is level.
Missing or damaged parts	Shipping damage or packaging error	Contact Bellemave customer support immediately for assistance.

Specifications




Image: Dimensional diagram of the Bellemave Full Loft Bed and its movable desk, indicating length, width, and height measurements.

- **Model:** FST00216-CF-AP1
- **Size:** Full
- **Product Dimensions:** 79"L x 57"W x 65"H
- **Color:** Espresso

- **Material:** Engineered Wood, Pine Wood
- **Item Weight:** 111 Pounds
- **Bed Weight Capacity:** 600 lbs
- **Desk Weight Capacity:** 66 lbs
- **Desk Storage Shelf Weight Capacity:** 22 lbs
- **Included Components:** Bookcase, Guardrails, Slat, Stairs
- **Assembly Required:** Yes
- **Manufacturer:** Bellemave
- **UPC:** 810212245263

Warranty Information

Bellemave products are designed for quality and durability. Specific warranty details may vary. Please refer to the warranty card included with your product or contact Bellemave customer support for detailed warranty information. Optional protection plans may be available for purchase separately.

Customer Support

For any questions, missing parts, or assistance with assembly or operation, please contact Bellemave customer support. You can typically find contact information on the packaging, the separate assembly guide, or by visiting the official Bellemave store on Amazon:
Visit the Bellemave Store on Amazon
Please have your model number (FST00216-CF-AP1) and purchase date ready when contacting support.

© 2025 Bellemave. All rights reserved.