

Lefant M330 Plus

Lefant M330 Plus Robot Vacuum Cleaner and Mop User Manual

Model: M330 Plus | Brand: Lefant

1. INTRODUCTION

The Lefant M330 Plus is an advanced robot vacuum cleaner and mop designed to provide a comprehensive cleaning solution for your home. It features powerful suction, intelligent navigation, and convenient control options to simplify your daily cleaning routine.

Key features include a 3-in-1 cleaning system (vacuum, sweep, mop), 5000Pa suction power, dToF laser mapping for precise navigation, and an anti-tangle design ideal for pet owners. The robot also intelligently adapts to different floor types and supports smart home integration.



Lefant

Lefant M330 Plus

Navigazione LiDAR dToF & Evitamento ostacoli | Doppie spazzole anti-capelli | Pulizia in profondità 3 in 1 | Aspirazione potente 5000 Pa

 Pulizia 3 in 1	 Navigazione LiDAR dToF 15 m	 Aspirazione 5000 Pa	 Tempo di funzionamento massimo 150 min	 Cestino della polvere trasparente	 Sollevamento automatico per pulizia senza interruzioni
--	---	---	--	---	--

Image: The Lefant M330 Plus robot vacuum cleaner operating in a living room with a family and their pet, highlighting its integration into a modern home environment.

2. SAFETY INFORMATION

Before using the Lefant M330 Plus, please read all safety instructions carefully to prevent injury or damage. Keep this

manual for future reference.

- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Ensure the charging base is placed on a flat, stable surface away from water or heat sources.
- Do not use the robot in wet environments or on wet surfaces.
- Remove any loose cables, small objects, or fragile items from the cleaning path to prevent entanglement or damage.
- Do not operate the robot if it is damaged or malfunctioning. Contact customer support.

For detailed safety information, refer to the provided safety document: [Safety Information \(PDF\)](#).

3. PACKAGE CONTENTS

Verify that all items are included in the package:

- Lefant M330 Plus Robot Vacuum Cleaner and Mop
- Charging Docking Station *1
- Water Tank *1
- Side Brushes *4
- Filters for Dustbin *2
- Washable Mop Pads *2
- Quick Start Guide / Instruction Manual

Contenuto della confezione




Image: A visual representation of all components included in the Lefant M330 Plus package, including the robot, charging station, water tank, brushes, filters, and mop pads.

4. PRODUCT OVERVIEW AND FEATURES

4.1. 3-in-1 Cleaning System

The M330 Plus combines sweeping, vacuuming, and mopping functions into one device, providing comprehensive cleaning without the need to switch tools. It effectively handles fine dust, long hair, daily dirt, and pet fur.

Funzione 3 in 1: spazzola, aspira e lava

Nessuna necessità di cambiare attrezzi. Elimina polvere, sporco e macchie in un unico ciclo efficiente.



Capacità 450 ml – Tutto in vista completa

Il cestino della polvere trasparente rende la manutenzione semplice; non dovrai più indovinare se è pieno.

Image: The Lefant M330 Plus robot vacuum cleaner illustrating its 3-in-1 function, showing how it simultaneously sweeps, vacuums, and mops to remove dirt and stains.

4.2. Powerful Suction and Anti-Tangle Design

Equipped with 5000Pa suction power, the robot efficiently removes stubborn dirt. Its unique brush-less central structure

prevents hair and pet fur from tangling, reducing manual maintenance.

Potenza estrema: Aspirazione 5000 Pa

Dotato di potenza sufficiente per rimuovere ciò che sembra impossibile. Estrae anche lo sporco più ostinato: da briciole e capelli alla polvere incastrata nei tappeti. La pulizia perfetta è l'unico obiettivo.



Image: The Lefant M330 Plus robot vacuum cleaner showcasing its powerful 5000Pa suction, lifting debris from a carpeted floor.

4.3. Intelligent dToF Laser Navigation and Mapping

The M330 Plus uses dToF laser technology to create precise maps of your home, enabling efficient room-by-room cleaning paths. It supports up to 3 independent maps, making it suitable for multi-story homes.

Intelligenza di livello superiore, guidata dalla precisione

M330 Plus Robot Aspirapolvere: Il nuovo M330 Plus utilizza l'avanzata tecnologia dToF per mappare le stanze in tempo record e evitare gli ostacoli con precisione. Il suo design senza spazzole previene l'avvolgimento dei capelli per un funzionamento senza manutenzione.




Image: The Lefant M330 Plus robot vacuum cleaner utilizing dToF laser navigation to accurately map its surroundings and detect obstacles, ensuring thorough cleaning.

4.4. Adaptive Surface Cleaning

The robot automatically recognizes different floor types. During mopping, it avoids carpets to protect them from moisture. In vacuuming mode, it automatically increases suction power on carpets for deeper cleaning.

Intelligenza adattativa per ogni superficie

Il suo sensore rileva i tappeti per un aumento istantaneo dell'aspirazione, mentre supera gli ostacoli alti oltre 16 mm per una pulizia potente e ininterrotta.



Image: The Lefant M330 Plus robot vacuum cleaner demonstrating its adaptive intelligence, increasing suction power from 2000Pa (standard) to 5000Pa (max) when transitioning from hard floor to carpet.

4.5. Long Runtime and Low Noise

With a battery life of up to 150 minutes, the M330 Plus can clean areas up to 150 square meters on a single charge. It operates at a low noise level (55dB), ensuring minimal disturbance.

Potenza compatta e di lunga durata

Con una durata di funzionamento di 150 minuti, pulisce fino a 150 m².




Image: The Lefant M330 Plus robot vacuum cleaner highlighting its long runtime of 150 minutes, capable of cleaning up to 150 square meters on a single charge.

5. SETUP GUIDE

5.1. Charging the Robot

1. Place the charging station against a wall in an open area, ensuring there are no obstacles within 1 meter to the sides and 1.5 meters in front.
2. Connect the power adapter to the charging station and plug it into a wall outlet.
3. Place the robot onto the charging station. Ensure the charging contacts on the robot align with those on the station. The indicator light will show charging status.
4. Allow the robot to fully charge before its first use (approximately 4-5 hours).



Ricarica automatica e ripresa senza interruzioni



Rumore a basso decibel



Potenza di aspirazione di 5000 Pa

Image: The Lefant M330 Plus robot vacuum cleaner demonstrating automatic recharging and its low noise operation (55dB), with a child and cat sleeping undisturbed.

5.2. Connecting to the Lefant App

The Lefant app allows you to control your robot, set cleaning schedules, view maps, and more.

1. Download the "Lefant" app from your mobile app store.
2. Register or log in to your account.
3. Add your M330 Plus robot vacuum to the app.
4. Connect to a 2.4 GHz or 5 GHz Wi-Fi network.
5. Power on the robot vacuum by pressing the power button.
6. Press and hold the start button for 6 seconds to enter network configuration mode.
7. Select M330 Plus in the app and wait for successful pairing.





Image: A step-by-step visual guide demonstrating the process of connecting the Lefant M330 Plus robot vacuum cleaner to the Lefant mobile application.

5.3. Voice Control Setup (Alexa/Google Home)

Integrate your M330 Plus with voice assistants for hands-free control.

1. Open the Lefant app, go to 'Third-party voice service'.
2. Note your account and voice password.
3. Launch the Alexa App, go to 'Skills & Games'.
4. Search for the 'Smart Life' skill.
5. Tap 'Enable to Use'.
6. Select your region, enter your account and voice password from step 2.
7. Wait for the account to be successfully linked.



Guida alla configurazione del controllo vocale Alexa

1. Apri l'app Lefant, vai a Il mio > Servizio vocale di terze parti
2. Annota il tuo account e password vocali
3. Avvia l'app Alexa, vai a Altro > Skill & Giochi
4. Cerca la skill Smart Life
5. Tocca Abilita per usare
6. Seleziona la tua regione, poi inserisci l'account e la password vocali del passaggio 2
7. Attendi che l'account venga collegato con successo

Image: A visual guide detailing the steps to configure Alexa voice control for the Lefant M330 Plus robot vacuum cleaner.

6. OPERATING INSTRUCTIONS

6.1. Cleaning Modes

The Lefant app provides various cleaning modes and customization options:

- **Auto Clean:** The robot intelligently cleans the entire mapped area.
- **Zone Clean:** Select specific areas on the map for the robot to clean.
- **Spot Clean:** Direct the robot to clean a concentrated area of dirt.
- **Scheduled Clean:** Set specific times for the robot to automatically start cleaning.



Image: The Lefant M330 Plus robot vacuum cleaner being controlled through its mobile app and voice commands, showcasing smart home integration in a living room.

6.2. Setting Forbidden Zones

You can define virtual boundaries to prevent the robot from entering specific areas.

1. Open the Lefant app and access the map interface.
2. Select the 'Forbidden Zones' option.
3. Draw rectangular areas on the map where you do not want the robot to clean or mop. This is useful for delicate

carpets, cable clusters, or pet areas.

4. Save the settings.

Hai il pieno controllo: imposta le Zone Vietate

Marca le aree vietate sulla mappa affinché il tuo robot pulisca solo dove vuoi tu. Evita con precisione tappeti delicati, grovigli di cavi o la zona del tuo animale domestico.



imposta le
Zone Vietate



Image: The Lefant M330 Plus app interface displaying the functionality to set customizable forbidden zones on the cleaning map, preventing the robot from entering specific areas.

6.3. Multi-Level Mapping

The M330 Plus can store up to 3 different maps, making it ideal for multi-story homes. The robot will automatically recognize which floor it is on and use the corresponding map.



Image: The Lefant M330 Plus app interface illustrating its multi-level mapping capability, allowing it to store and utilize maps for up to three different floors.

6.4. Apple Watch Control

Control your Lefant M330 Plus directly from your Apple Watch for added convenience.

1. Download the Lefant app on your iPhone and Apple Watch.
2. Pair your Apple Watch with your iPhone.
3. Open the Lefant app on your Apple Watch.
4. Access the Lefant app on your iPhone and log in.
5. Connect your Lefant robot to the app.
6. Control your robot seamlessly from your Apple Watch.




Image: A visual guide demonstrating how to control the Lefant M330 Plus robot vacuum cleaner directly from an Apple Watch, showing the app interface on both devices.

7. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Lefant M330 Plus.

7.1. Emptying the Dustbin

The transparent 450ml dustbin allows you to easily see when it needs emptying. Empty it after each cleaning cycle or when full.

1. Press the dustbin release button and pull out the dustbin.
2. Open the dustbin lid and empty its contents into a trash can.
3. Close the lid and reinsert the dustbin into the robot until it clicks into place.

7.2. Cleaning Filters

Clean the filters regularly to maintain strong suction. Replace them every 3-6 months depending on usage.




Image: A set of replacement filters for the Lefant M330 Plus robot vacuum cleaner.

1. Remove the dustbin.
2. Take out the filter assembly.
3. Tap the filter against a trash can to remove dust. Do not wash the HEPA filter with water.
4. Brush off any remaining debris with a cleaning brush.
5. Reassemble and reinsert.

7.3. Cleaning Side Brushes

Inspect and clean the side brushes weekly to remove tangled hair or debris. Replace them if they are worn or damaged.



Image: A set of replacement side brushes for the Lefant M330 Plus robot vacuum cleaner.

1. Pull the side brushes upwards to remove them.
2. Remove any hair or debris wrapped around the brushes.
3. Reattach the brushes, ensuring they click into place.

7.4. Cleaning Mop Pads

The magnetic mop pads are washable and should be cleaned after each use to ensure hygiene.



Image: A pair of replacement mop pads for the Lefant M330 Plus robot mop.

1. Detach the mop pad from the water tank.
2. Hand wash the mop pad with water and mild detergent.
3. Allow it to air dry completely before reattaching.

8. TROUBLESHOOTING

If you encounter issues with your Lefant M330 Plus, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Robot does not turn on	Low battery; Power button not pressed	Charge the robot; Press and hold the power button for a few seconds.
Robot cannot charge	Charging contacts dirty; Charging station not powered	Clean charging contacts on robot and station; Ensure charging station is plugged in.
Robot gets stuck frequently	Obstacles in path; Robot stuck on high thresholds	Clear loose cables and small objects; Use forbidden zones for high thresholds.
Poor cleaning performance	Dustbin full; Filters clogged; Side brushes worn	Empty dustbin; Clean/replace filters; Clean/replace side brushes.
App connection issues	Incorrect Wi-Fi password; Robot not in pairing mode; Router issues	Verify Wi-Fi password; Re-enter pairing mode; Restart router.

If the problem persists, please contact Lefant customer support for assistance.

9. SPECIFICATIONS

Feature	Detail
Brand	Lefant
Model Name	M330 Plus
Suction Power	5000 Pa
Navigation Type	LiDAR (dToF)
Battery Life	150 Minutes
Battery Composition	Lithium Ion
Dustbin Capacity	450 ml
Control Method	App, Voice (Alexa, Google Assistant)
Special Features	LiDAR Navigation, Anti-Tangle Design, Carpet Detection, Multi-Level Mapping
Dimensions (LxWxH)	28L x 28W x 9.5H cm
Item Weight	2.15 Kilograms
UPC	609484081439

10. WARRANTY AND SUPPORT

Lefant products come with a standard manufacturer's warranty. For specific warranty details and duration, please refer to the warranty card included in your product packaging or contact Lefant customer support.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please visit the official Lefant website or contact their customer service team. You can also refer to the [Data Transparency Statement \(PDF\)](#) for additional information.

Online resources and FAQs may also be available on the Lefant brand store [Lefant Store](#).

© 2023 Lefant. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question