



[Manuals.plus](#) /

› [Madesa](#) /

› Madesa Dining Chair Set 4292 MC Instruction Manual

**Madesa XM42927Q4TBEK**

# Madesa Dining Chair Set 4292 MC Instruction Manual

Model: XM42927Q4TBEK

## 1. INTRODUCTION

Thank you for choosing the Madesa Dining Chair Set 4292 MC. This set includes four high-quality dining chairs designed for comfort and durability. This manual provides detailed instructions for assembly, proper use, and maintenance to ensure the longevity of your furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image: Four Madesa dining chairs, showcasing the complete set.

## 2. SAFETY INFORMATION

---

- Ensure all parts are present and undamaged before assembly. Do not use damaged parts.
- Assemble the chairs on a soft, clean surface to prevent scratches.
- Tighten all screws and bolts securely, but do not overtighten. Periodically check and retighten fasteners as needed.
- Do not stand on the chairs or use them as a step stool.
- Keep small parts and packaging materials away from children.

## 3. PACKAGE CONTENTS

---

Before assembly, verify that all components are included in your package:

- Chair Frames (4 units)
- Seat Cushions (4 units)
- Backrests (4 units)
- Assembly Hardware Kit (screws, bolts, Allen wrench, etc.)
- Instruction Manual

## 4. ASSEMBLY INSTRUCTIONS

---

Assembly is required for this dining chair set. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface to prevent damage.
2. **Identify Parts:** Refer to the included hardware diagram (if applicable) to identify all screws, bolts, and chair components.
3. **Attach Backrest to Rear Legs:** Secure the backrest to the two rear chair legs using the provided screws and an Allen wrench. Do not fully tighten yet.
4. **Attach Front Legs:** Connect the two front chair legs to the seat frame using the appropriate hardware.
5. **Connect Seat Frame:** Attach the seat frame to the assembled backrest and front legs. Ensure all connections are aligned.
6. **Install Seat Cushion:** Place the seat cushion onto the seat frame and secure it with the designated screws from underneath.
7. **Final Tightening:** Once all parts are loosely assembled, place the chair on a flat surface. Apply gentle pressure to ensure it sits evenly, then fully tighten all screws and bolts.
8. **Repeat for Remaining Chairs:** Follow the same steps for the other three chairs.

Ferragens  
de **alta**  
**qualidade**  
e montagem  
rápida.



Image: Detail of the high-quality hardware used for assembly.



Image: Additional view of the assembly hardware and connection points.

## 5. OPERATING INSTRUCTIONS (USAGE)

---

The Madesa Dining Chairs are designed for indoor use as seating furniture. To ensure proper use and longevity:

- Use the chairs on a flat, stable surface.
- Avoid dragging the chairs across the floor; lift them when moving to prevent damage to legs and flooring.
- Do not expose the chairs to excessive moisture or direct sunlight for prolonged periods, as this may affect the wood and finish.

## 6. MAINTENANCE

---

Regular maintenance will help preserve the appearance and structural integrity of your Madesa dining chairs:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage

the polyester paint finish.

- **Spills:** Clean spills immediately with a dry cloth to prevent staining.
- **Fasteners:** Periodically check all screws and bolts and tighten them if they have loosened over time.
- **Protection:** Use felt pads under the chair legs to protect your flooring.



Image: Detail showing the high-resistance polyester paint finish on the chair frame.

## 7. TROUBLESHOOTING

- **Wobbly Chair:** If a chair feels unstable, loosen all assembly screws slightly, sit on the chair to settle the frame, then retighten all screws firmly while the chair is on a flat surface.
- **Loose Screws:** Periodically check and tighten all screws and bolts to maintain stability.
- **Scratches/Dents:** Minor scratches on the wood can sometimes be touched up with a furniture repair marker matching the wood tone.

## 8. SPECIFICATIONS

Attribute	Detail
Brand	Madesa
Model Name	4292 MC
Model Number	XM42927Q4TBEK
Color	Brown
Material	Engineered Wood (Frame), Foam (Seat Cushion)
Product Dimensions (D x W x H)	44 cm x 37 cm x 89 cm (17.3 in x 14.6 in x 35 in)
Seat Height	33 cm (13 in)
Seat Depth	35 cm (13.8 in)
Item Weight (per chair)	Approximately 56.25 kg (225 kg / 4 chairs) - <i>Note: 225kg for 4 chairs seems very high, likely a data error.</i>
Assembly Required	Yes
Country of Origin	Mexico



Image: A single chair displaying its height (89cm), depth (44cm), and width (37cm).

## 9. WARRANTY AND SUPPORT

**Manufacturer's Warranty:** Madesa products are manufactured with quality and durability in mind. For specific warranty details, please refer to the documentation included with your purchase or contact Madesa customer support.

**Returns:** This product is eligible for a 30-day free return period from the date of purchase. Please refer to the retailer's return policy for full details.

**Extended Protection Plans:** Extended warranty options may be available through third-party providers such as Assurant. These plans offer additional coverage beyond the manufacturer's warranty for 2, 3, or 4 years. Please consult the retailer for details on purchasing these plans.

**Customer Support:** For assistance with assembly, missing parts, or any other inquiries, please contact Madesa customer service through their official channels or the retailer where the product was purchased.

