Bellemave FST00216-CT-AK1

Bellemave Twin Loft Bed with Stairs and Movable Desk and Shelves Instruction Manual

Product Overview

The Bellemave Twin Loft Bed is designed to maximize space and functionality, featuring a tiered structure that combines a sleeping area with a versatile study and storage zone. This loft bed includes a movable desk with multi-tiered open shelving units for organizing books, stationery, and decorative items. Integrated storage stairs provide additional space while ensuring sturdy access to the upper bunk. The bed is constructed from premium Pine, MDF, and Plywood, offering a robust and durable structure. Safety rails are installed around the upper bunk, complying with child safety standards to prevent falls.




Figure 1: Overall view of the Bellemave Twin Loft Bed with its movable desk and storage stairs.

Safety Guidelines

Please read and adhere to all safety instructions to ensure safe use of the Bellemave Twin Loft Bed.

- **Weight Capacity:** The upper bed has a maximum weight capacity of 400 lbs. Do not exceed this limit.
- **Guardrails:** Ensure children do not climb on the guardrails. Guardrails are designed to prevent falls from the upper bunk.
- **Mattress Size:** Use only a twin-size mattress that fits snugly within the bed frame to prevent gaps.
- **Assembly:** Ensure all components are securely fastened according to the assembly instructions before use. Regularly check and tighten all connections.
- **Ventilation:** Ensure adequate ventilation around the bed, especially if placed against a wall.

Setup and Assembly

The Bellemave Twin Loft Bed is designed for straightforward assembly. Each order includes a clear and detailed assembly instruction guide, and all necessary tools are provided. It is recommended to assemble the bed in the room where it will be used.

Preparation

- Unpack all components and verify against the parts list in the included manual.
- Clear a spacious area for assembly.
- Keep children and pets away from the assembly area to prevent accidents.

Assembly Steps

Refer to the step-by-step instructions and diagrams in the provided assembly manual for detailed guidance. Key components include the bed frame, storage stairs, and movable desk with shelves.



Figure 2: Product dimensions for the loft bed and movable desk, essential for planning your space.



Figure 3: The storage stairs feature multiple compartments for organization.



Figure 4: The movable desk includes tiered open shelving for convenient storage and display.

Operating Instructions

Movable Desk Functionality

The desk unit beneath the loft bed is designed to be movable, allowing for flexible room arrangements. It can be pulled out for use as a study or workspace and pushed back in to save space when not needed. The desk has a weight capacity of 66 lbs, and the desk storage shelf has a weight capacity of 22 lbs.



Figure 5: The movable desk is equipped with wheels for easy repositioning.

Storage Stairs Usage

The stairs leading to the upper bunk feature integrated storage compartments. These compartments can be used to store books, toys, clothing, or other personal items, helping to keep the room tidy and organized.



Figure 6: Each step of the stairs provides accessible storage space.

Care and Maintenance

Proper care and maintenance will extend the life and appearance of your Bellemave Twin Loft Bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or water damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.

- **Temperature and Humidity:** Maintain a stable room temperature and humidity level to prevent wood from warping or cracking.
- **Hardware Check:** Periodically check all bolts, screws, and fasteners to ensure they are tight. Re-tighten as necessary to maintain structural integrity.

Troubleshooting

If you encounter any issues with your Bellemave Twin Loft Bed, refer to the following common troubleshooting tips:

- **Squeaking Noises:** Squeaking often indicates loose hardware. Re-tighten all bolts and screws, especially those connecting the bed frame and slats.
- **Wobbly Structure:** If the bed feels unstable, ensure all connections are fully tightened and that the bed is placed on a level surface. Check for any missing or incorrectly installed components.
- **Desk Not Moving Smoothly:** Check the wheels on the movable desk for any obstructions or debris. Ensure the floor surface is clean and clear.
- **Damaged Parts:** If any part is damaged or missing upon arrival, do not proceed with assembly. Contact customer support for replacement parts.

Product Specifications

Feature	Detail
Model Number	FST00216-CT-AK1
Brand	Bellemave
Size	Twin
Product Dimensions (L x W x H)	79"L x 41.2"W x 65"H
Material	Engineered Wood, Pine Wood
Color	White With Movable Desk
Item Weight	109 pounds
Bed Weight Capacity	400 lbs
Desk Weight Capacity	66 lbs
Desk Storage Shelf Weight Capacity	22 lbs
Assembly Required	Yes
Included Components	Bookcase, Guardrails, Slat, Stairs
UPC	810212245614

Warranty and Customer Support

For warranty information or to obtain assistance with your Bellemave Twin Loft Bed, please refer to the

documentation included with your purchase or contact Bellemave customer support directly. Ensure you have your model number (FST00216-CT-AK1) and proof of purchase available when contacting support.

Return Policy: This product is eligible for a 90-day easy return policy. Please refer to your retailer's specific return guidelines for more details.