

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [YITAHOME](#) /

› [YITAHOME 55" Farmhouse Shoe Storage Bench \(Model MAYIHI4cAY\) User Manual](#)

YITAHOME MAYIHI4cAY

YITAHOME 55" Farmhouse Shoe Storage Bench User Manual

Model: MAYIHI4cAY

1. PRODUCT OVERVIEW

The YITAHOME 55" Farmhouse Shoe Storage Bench is designed to provide both seating and organized storage for your entryway, mudroom, or hallway. It features a rustic farmhouse style with a flip-top seat for concealed storage and three tilt-out drawers for shoe organization.



Image: The YITAHome 55-inch Farmhouse Shoe Storage Bench, closed, positioned in an entryway with a decorative pillow and bag on top.

This versatile piece helps maintain a tidy living space by offering dedicated spots for footwear and other essentials.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Weight Limit:** Do not exceed the maximum weight recommendation of **220 pounds (100 kg)** on the bench seat.
- **Indoor Use:** This bench is designed for indoor use only. Keep it in a dry environment to protect the engineered wood finish from moisture and extreme temperature changes.
- **Assembly:** Always assemble the bench according to the provided instructions. Ensure all fasteners are securely tightened before use.
- **Stability:** Place the bench on a flat, level surface to prevent tipping.
- **Children:** Keep small parts and packaging materials away from children during assembly. Do not allow

children to climb on or play with the bench unsupervised.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed in the assembly guide are present and undamaged. If any parts are missing or damaged, contact customer support immediately.

Typical package contents include:

- Wood panels (top, side, bottom, back, drawer fronts)
- Hardware pack (screws, dowels, cam locks, hinges, drawer slides)
- Assembly tools (e.g., Allen wrench, if required)
- Instruction manual

4. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Follow the step-by-step instructions provided in the included assembly guide. All parts are pre-labeled for easier identification.

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches. Identify each part using the labels and the parts list in your assembly guide.
2. **Assemble Frame:** Begin by assembling the main frame of the bench, connecting the side panels to the bottom and back panels using the specified hardware.
3. **Install Flip-Top Mechanism:** Attach the hinges for the flip-top seat according to the instructions. Ensure they are aligned correctly for smooth operation.
4. **Assemble Drawers:** Construct the three tilt-out drawers. Attach the drawer fronts and the internal shoe racks.
5. **Install Drawers:** Insert the assembled tilt-out drawers into their designated compartments. Test their tilting mechanism for smooth movement.
6. **Attach Top Panel:** Secure the flip-top seat to the installed hinges.
7. **Final Check:** Once assembled, ensure all screws and fasteners are tight. Gently test the stability of the bench and the functionality of the flip-top and drawers.

ADJUSTABLE TILT-OUT SHOES ORGANIZER



Image: A detailed view of the adjustable tilt-out shoe organizer mechanism within the bench, showing how shoes are stored.



UNIQUE DETAILS

DETAILS FROM YITAHOME STORAGE SHOE BENCH



Image: Close-up details of the bench, highlighting the cross-shaped decorative design on the drawer fronts and the 15mm thickness of the engineered wood panels.

5. OPERATING INSTRUCTIONS

The YITAHOME Shoe Storage Bench offers two primary storage functions:

5.1 Using the Flip-Top Seat Storage

The left section of the bench features a flip-top lid. To access the storage compartment:

1. Gently lift the top panel from the front edge.
2. The lid will open upwards, revealing a spacious compartment suitable for larger items like boots, bags, or blankets.
3. To close, carefully lower the lid until it rests securely on the bench frame.

5.2 Using the Tilt-Out Shoe Drawers

The right section of the bench contains three tilt-out drawers designed for shoe storage.

1. To open a drawer, pull the handle on the front panel. The drawer will tilt forward and down.

2. Place shoes onto the internal racks. Each drawer can typically hold 2-3 pairs of shoes, depending on size and style.
3. To close, push the drawer back into the bench until it is flush with the front panel.



Image: The YITAHOME storage bench with its flip-top lid open on the left, revealing internal storage, and one tilt-out shoe drawer open on the right, displaying various pairs of shoes.

6. MAINTENANCE AND CARE

Proper care will extend the life and appearance of your YITAHOME shoe storage bench.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent water damage or staining to the engineered wood.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.
- **Moisture:** Keep the bench away from areas with high humidity or direct water contact.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.

7. TROUBLESHOOTING

If you encounter any issues with your shoe storage bench, refer to the following common solutions:

- **Bench is Wobbly:**

Solution: Ensure the bench is placed on a flat, level surface. Check all assembly screws and re-tighten any loose connections.

- **Drawers Do Not Tilt Smoothly:**

Solution: Verify that the drawer slides are correctly installed and free from obstructions. Ensure no items inside the drawer are blocking its movement. Check that the drawer assembly itself is square.

- **Flip-Top Lid Does Not Close Properly:**

Solution: Check the hinges for proper alignment and ensure no items in the storage compartment are preventing the lid from closing fully.

- **Missing Parts or Damaged Components:**

Solution: Do not proceed with assembly. Contact YITAHOME customer support with your purchase details and a description of the issue.

8. SPECIFICATIONS

Key specifications for the YITAHOME 55" Farmhouse Shoe Storage Bench:



Image: A diagram illustrating the overall dimensions of the YITAHOME 55-inch shoe storage bench, including length, width, and height, along with internal drawer measurements.

Feature	Detail
Product Dimensions (L x W x H)	55" x 15.7" x 21.3" (140cm x 40cm x 54cm)

Feature	Detail
Material	Engineered Wood
Color	Black-brown
Style	Farmhouse
Maximum Weight Recommendation	220 Pounds (100 kg)
Item Weight	73.3 pounds (33.2 kg)
Model Number	MAYIH14cAY

9. WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact YITAHOME customer service directly. Refer to your purchase documentation or the YITAHOME official website for contact details. When contacting support, please have your model number (MAYIH14cAY) and purchase date available.