

VGT-800

Generic Ultrasonic Cleaner VGT-800 Instruction Manual

Model: VGT-800

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before operating the ultrasonic cleaner. Retain this manual for future reference.

- **Electrical Safety:** Do not immerse the unit, power cord, or plug in water or other liquids. Ensure hands are dry before plugging in or unplugging the unit. Disconnect from power when not in use and before cleaning.
- **Placement:** Place the unit on a stable, level surface away from heat sources and direct sunlight. Ensure adequate ventilation.
- **Liquid Usage:** Only use water or approved ultrasonic cleaning solutions in the tank. Do not use flammable, corrosive, or abrasive liquids.
- **Overfilling/Underfilling:** Do not fill the tank above the MAX line or below the MIN line.
- **Children and Pets:** Keep the appliance out of reach of children and pets.
- **Damaged Unit:** Do not operate the unit if it has a damaged cord, plug, or if it malfunctions or has been dropped. Contact customer support for assistance.
- **Certified Standards:** This product is certified by FCC, CE, and RoHS, ensuring adherence to safety and environmental standards.

2. PRODUCT OVERVIEW

The Generic Ultrasonic Cleaner VGT-800 utilizes ultrasonic technology to provide thorough cleaning for various small items. It features an intuitive digital interface and a transparent lid for monitoring the cleaning process.

2.1 What's in the Box

What's in the Box

+



1 PCS

Image: The package includes the ultrasonic cleaner unit, a power cable, and a detachable cleaning basket.

- Ultrasonic Cleaner Unit (VGT-800)
- Power Cable
- Detachable Cleaning Basket

3. PRODUCT SPECIFICATIONS

Product Dimensions



Image: The ultrasonic cleaner with its dimensions labeled: 7.87 inches (length), 5.51 inches (width), and 4.92 inches (height).

Feature	Detail
Model	VGT-800
Capacity	600 ml
Product Dimensions (L x W x H)	7.87 x 5.51 x 4.92 inches (20 x 14 x 12.5 cm)
Item Weight	2.43 pounds
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	White
Power	35W
Certifications	FCC, CE, RoHS

4. SETUP INSTRUCTIONS

- Unpack:** Carefully remove the ultrasonic cleaner and all accessories from the packaging.
- Placement:** Place the unit on a firm, level, and dry surface near a power outlet. Ensure there is enough space around the unit for ventilation.
- Fill Tank:** Open the lid and fill the stainless steel tank with water. For enhanced cleaning, you may add a small amount of specialized ultrasonic cleaning solution. Do not exceed the 'MAX' fill line.
- Insert Basket:** If cleaning delicate items or multiple small items, place them into the detachable cleaning basket and then lower the basket into the tank.
- Connect Power:** Plug the power cable into the unit and then into a standard electrical outlet.

5. OPERATING INSTRUCTIONS

The VGT-800 features an intuitive digital interface for easy operation.



Image: The ultrasonic cleaner positioned on a table with various items like glasses, jewelry, and a watch, demonstrating its multipurpose functionality.

- Power On:** Press the 'ON/OFF' button to turn on the unit. The display will illuminate.
- Select Cleaning Time:** Use the 'TIME' button to cycle through the preset cleaning cycles (e.g., 90s, 180s, 280s, 380s, 480s). Choose the appropriate time based on the items being cleaned and their level of dirtiness.
- Start Cleaning:** Press the 'START' button to begin the ultrasonic cleaning process. The transparent lid allows you to monitor the cleaning.
- Pause/Stop:** You can press 'START' again to pause the cleaning cycle. To stop the cycle completely, press the 'ON/OFF' button.
- End of Cycle:** The unit will automatically shut off once the selected cleaning cycle is complete.
- Remove Items:** Carefully open the lid. Use the cleaning basket to lift items out of the tank. Rinse items under clean water and dry them thoroughly with a soft cloth.
- Power Off:** Press the 'ON/OFF' button to turn off the unit and unplug it from the power outlet.

5.1 Recommended Cleaning Times

- Jewelry (rings, necklaces, earrings):** 180-280 seconds
- Glasses/Sunglasses:** 90-180 seconds
- Watches (waterproof only):** 180-280 seconds
- Dentures/Retainers:** 280-380 seconds
- Small Metal Parts/Tools:** 380-480 seconds

Note: Always ensure items are suitable for ultrasonic cleaning. Delicate or porous items may not be suitable. Consult the item's manufacturer if unsure.

6. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your ultrasonic cleaner.

- Empty Tank:** After each use, unplug the unit and carefully empty the water from the tank. Do not pour water over the control panel.
- Clean Tank:** Wipe the inside of the stainless steel tank with a soft cloth. For stubborn residue, use a mild detergent and rinse thoroughly. Avoid abrasive cleaners.
- Exterior Cleaning:** Wipe the exterior of the unit with a soft, damp cloth. Do not use harsh chemicals or immerse the unit in water.
- Storage:** Store the unit in a cool, dry place away from direct sunlight and moisture. Ensure the tank is completely dry before storage.
- Detachable Basket:** Clean the detachable basket with water and mild soap as needed.

7. TROUBLESHOOTING

If you encounter issues with your ultrasonic cleaner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	Power cord is not connected or damaged.	Check power cord and plug into a working outlet.

Unit does not power on	Not plugged in; Power outlet issue; Unit malfunction	Ensure power cable is securely plugged into both the unit and a working outlet. Test the outlet with another appliance. If problem persists, contact customer support.
Cleaning results are poor	Insufficient cleaning time; Incorrect water level; Items too dirty; No cleaning solution used	Increase cleaning time. Ensure water is between MIN and MAX lines. Pre-rinse heavily soiled items. Consider adding a suitable ultrasonic cleaning solution.
Unit makes unusual noise	Normal operation noise; Unit not on a stable surface; Internal issue	A slight buzzing sound is normal during operation. Ensure the unit is on a stable, flat surface. If the noise is excessively loud or unusual, discontinue use and contact support.
Water is not heating up (if applicable)	This model does not feature a heating function.	The VGT-800 is designed for ultrasonic cleaning without a heating element.

If the problem persists after attempting these solutions, please contact customer support.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.

For any questions or assistance, please reach out to the manufacturer or authorized reseller.