

[Manuals.plus](#) /

› [Jedel](#) /

› Jedel KL141 68% Mechanical Gaming Keyboard User Manual

## Jedel KL141

# Jedel KL141 68% Mechanical Gaming Keyboard User Manual

Model: KL141 | Brand: Jedel

## INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Jedel KL141 68% Mechanical Gaming Keyboard. Please read this guide thoroughly to ensure optimal performance and longevity of your device.



Figure 1: Jedel KL141 68% Mechanical Gaming Keyboard. This image shows the full keyboard layout with its vibrant RGB backlighting and English/Arabic keycap legends.

## SETUP

1. **Unpacking:** Carefully remove the keyboard from its packaging. Ensure all components, including the keyboard and user manual, are present.
2. **Connection:** Connect the USB cable from the keyboard to an available USB port on your computer, laptop, tablet, or smartphone. The keyboard is plug-and-play and does not require additional drivers for basic functionality.
3. **Initial Power-On:** Upon connection, the keyboard's RGB backlight will illuminate, indicating it is powered on and ready for use.

# Jedel®

YOUR IT HOME




Comfortable  
Hand Feel



Pu Line Length  
1.5 M



Link Mode  
Type-C



Keyboard Layout  
68 Keys

Figure 2: Key features of the Jedel KL141 keyboard, including its 1.5-meter cable length and Type-C connection mode.

## OPERATING INSTRUCTIONS

### Keyboard Layout and Keycaps

The Jedel KL141 features a 68% layout, providing a compact design while retaining essential keys. It includes English and Arabic legends on its keycaps.



Figure 3: Detached keycaps illustrating the double-shot ABS construction and the underlying mechanical switches.

The keycaps are made from durable double-shot ABS plastic, ensuring excellent light transmission for the backlight and preventing legends from fading over time. The suspended design of the keycaps enhances tactile feedback and comfort.

## Backlight Control

The keyboard features a smart rainbow LED backlight system with multiple lighting modes and 10 distinct backlight effects. You can customize the lighting to your preference.

- **Changing Modes:** Use the **Fn** key in combination with specific function keys (refer to keyboard legends for specific combinations, often indicated by icons or secondary functions) to cycle through different backlight effects.
- **Adjusting Brightness:** Typically, **Fn + Up Arrow / Down Arrow** keys control backlight brightness.
- **Adjusting Speed:** For dynamic lighting modes, **Fn + Left Arrow / Right Arrow** keys may adjust the effect speed.

Experiment with the **Fn** key combinations to discover all available lighting options.

## MAINTENANCE

- **Cleaning Keycaps:** The double-shot molded keycaps are easy to clean. You can gently wipe them with a soft, damp cloth. For deeper cleaning, keycaps can be carefully removed using a keycap puller (not included) and cleaned individually. Ensure they are completely dry before reattaching.
- **Cleaning the Keyboard Base:** Use a soft brush or compressed air to remove dust and debris from between the keys. Avoid using harsh chemicals or abrasive materials.
- **Cable Care:** Avoid bending or twisting the USB cable excessively to prevent damage.

## TROUBLESHOOTING

| Problem                 | Possible Cause                                                               | Solution                                                                                                                                                                                                                              |
|-------------------------|------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Keyboard not responding | Loose USB connection, faulty USB port, driver issue (rare for plug-and-play) | <ul style="list-style-type: none"><li>• Ensure the USB cable is securely connected.</li><li>• Try a different USB port on your device.</li><li>• Test the keyboard on another computer to rule out a device-specific issue.</li></ul> |

| Problem                        | Possible Cause                                                | Solution                                                                                                                                                                                                                 |
|--------------------------------|---------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Backlight not working or stuck | Backlight turned off, specific mode selected, software glitch | <ul style="list-style-type: none"><li>Press <b>Fn</b> + <b>Up Arrow</b> to increase brightness.</li><li>Cycle through backlight modes using <b>Fn</b> + relevant keys.</li><li>Unplug and replug the keyboard.</li></ul> |
| Certain keys not registering   | Debris under keycap, faulty switch                            | <ul style="list-style-type: none"><li>Remove the keycap and clean any debris around the switch.</li><li>If the issue persists, contact customer support.</li></ul>                                                       |

## SPECIFICATIONS

- Brand:** Jedel
- Model:** KL141
- Keyboard Type:** Mechanical Gaming Keyboard
- Layout:** 68% (68 keys)
- Keycap Language:** English and Arabic
- Switch Type:** Red Mechanical Switches
- Backlight:** Rainbow LED (RGB effects, 10 modes)
- Connectivity:** Wired USB (Type-C cable)
- Cable Length:** 1.5 meters
- Keycap Material:** Double-shot ABS Plastic
- Compatible Devices:** Computer, Laptop, Tablet, Smartphone (Windows, Mac, Android)
- Recommended Use:** Gaming, Office







Figure 4: Side profiles of the Jedel KL141 keyboard, highlighting the ergonomic keycap design.

## **WARRANTY AND SUPPORT**

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the

official Jedel website. Keep your proof of purchase for warranty claims.

© 2023 Jedel. All rights reserved.

## ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

### Name

Anonymous

### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

### Question

Example: How do I reset this device or fix this error?

### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question