Tineco S9 Master

Tineco FLOOR ONE S9 Master Floor Washer and Vacuum Cleaner User Manual

Model: S9 Master

1. Introduction

This manual provides essential information for the safe operation, maintenance, and troubleshooting of your Tineco FLOOR ONE S9 Master floor washer and vacuum cleaner. Please read this manual thoroughly before using the appliance and retain it for future reference.

2. Product Overview

2.1 What's Included

The Tineco FLOOR ONE S9 Master package includes the following components:

- 1 x Roller brush
- 1 x Dry filter
- 1 x Cleaning solution
- 1 x Cleaning tool
- 1 x Charging and Drying Base



Figure 2.1: All included components for the Tineco FLOOR ONE S9 Master.

2.2 Key Features

- **Continuous Hot Water Cleaning:** The advanced heating technology instantly heats water as needed, ensuring a continuous flow of hot water for improved cleaning efficiency and effectiveness throughout the cleaning session.
- **ThermoBlast Technology:** This system delivers a high-pressure jet of heated water to dissolve stubborn stains and dirt more effectively than cold water, reaching even crevices for thorough cleaning.



Figure 2.2: ThermoBlast Technology in action, showing an ideal jet angle with boosted water flow.

- **Powerful 23,000 Pa Suction:** The device easily lifts dirt, debris, and hair from all surfaces, ensuring deep and accurate cleaning.



Figure 2.3: The powerful 23,000 Pa suction capability of the device.

- **StreakFree Squeegee:** Surfaces are scraped and dry quickly, leaving them ready to walk on without water marks. The squeegee automatically lowers when the device is pulled backward.



Figure 2.4: The innovative StreakFree Squeegee ensures quick drying and no water marks.

- **FlashDry Self-Cleaning System:** Features self-cleaning with heated water and drying with 85°C hot air. It offers dual drying modes: FlashDry (5 minutes) and SilentDry (40 minutes).



Figure 2.5: The FlashDry Self-Cleaning System with two drying modes.

- **DustReveal Green Light Head:** A green light on the cleaning head illuminates the floor, making dust and debris clearly visible for thorough cleaning.



Figure 2.6: The DustReveal Green Light Head enhances visibility of dirt and dust.

- **Ultra-Slim 9.9 cm Body:** The slim design allows the device to easily reach under furniture and into tight spaces.



Figure 2.7: The ultra-slim body design for cleaning under low furniture.

- **Long Runtime:** Provides up to 65 minutes of runtime in Silent Mode or 50 minutes in Auto Mode on a single charge, allowing for comprehensive home cleaning.



Figure 2.8: Runtime details and water tank capacities.

3. Setup

3.1 Assembly

To assemble your Tineco FLOOR ONE S9 Master, follow these steps:

1. Align the handle with the main body of the device.
2. Insert the handle firmly into the main body in the correct direction.
3. Listen for a "click" sound, which indicates that the handle is correctly and securely attached.



Figure 3.1: Correct handle assembly for the device.

3.2 Initial Charging

Before first use, fully charge the device. Place the main unit on the charging base. The display will indicate charging status. A full charge typically takes several hours.

3.3 Filling Water Tanks

Fill the clean water tank with clean water and, if desired, a small amount of Tineco cleaning solution. Do not overfill. Ensure the dirty water tank is empty before starting a cleaning session.

4. Operating Instructions

4.1 Power On/Off

Press the power button located on the handle to turn the device on or off.

4.2 Cleaning Modes

The device features a high-visibility touchscreen display that guides you with real-time updates on status and allows selection of different cleaning modes:

- **MAX Mode:** For intensive cleaning of heavily soiled areas.
- **HEAT Mode:** Activates hot water cleaning for stubborn stains.
- **QUIET Mode:** For quieter operation, suitable for less demanding cleaning tasks.
- **AUTO Mode:** The device automatically adjusts suction power and water flow based on detected dirt levels.



Figure 4.1: High-visibility touchscreen display with mode selection.

4.3 Using the Device

Push the device forward to wash and vacuum. Pull it backward to dry the floor. The DustReveal green light will help identify hidden dirt. The iLoop Smart Sensor will automatically adjust settings in Auto Mode.

4.4 Smart Features

The Tineco FLOOR ONE S9 Master is equipped with an iLoop Smart Sensor that automatically detects the level of dirt on your floor and adjusts suction power and water flow accordingly for optimal cleaning efficiency.



Figure 4.2: The iLoop Smart Sensor automatically adjusts cleaning parameters.

5. Maintenance

5.1 Emptying Dirty Water Tank

After each use, or when the dirty water tank is full, it must be emptied. The detachable tank can be easily removed with one hand for quick disposal of dirty water.



Figure 5.1: Quick disposal of dirty water from the detachable tank.

5.2 Running the Self-Cleaning Cycle (FlashDry)

Place the device on its charging base and initiate the FlashDry self-cleaning cycle. This process uses heated water for cleaning and 85°C hot air for drying the roller brush and internal components. You can choose between FlashDry (5 min) or SilentDry (40 min) modes.

5.3 Cleaning Roller Brush and Filter

Regularly inspect and clean the roller brush and HEPA filter. Remove the roller brush and rinse it under running water. Allow it to air dry completely before reinserting. Tap the dry filter to remove debris or rinse if necessary, ensuring it is completely dry before reuse.

6. Troubleshooting

If you encounter any issues with your Tineco FLOOR ONE S9 Master, please refer to the following general troubleshooting tips:

- **Device not turning on:** Ensure the device is fully charged. Check if the handle is correctly assembled and clicked into place.
- **Poor suction:** Check if the dirty water tank is full or if the clean water tank is empty. Inspect the roller brush and filter for blockages or excessive dirt.
- **Streaks on floor:** Ensure the dirty water tank is not overfilled. Clean the roller brush thoroughly. Run the self-cleaning cycle.
- **Unusual noise:** Check for any foreign objects caught in the roller brush or suction path.

For more detailed troubleshooting or persistent issues, please contact Tineco customer support.

7. Specifications

Specification	Detail
Brand	Tineco
Model Name	S9 Master

Special Feature	Hot Water Washing
Filter Type	HEPA Filter
Recommended Surfaces	Hard Floor
Power Source	Battery Powered
Color	Black
Noise Level	78 Decibels
Portable	Yes
Indoor/Outdoor Use	Indoor
Cordless	Yes
Item Weight	5.1 Kilograms
Item Dimensions (LxWxH)	23.9L x 26.7W x 110.5H cm
Control Method	Touch
Voltage	25.2 Volts
Wattage	450 Watts
Runtime	1 hour and 5 minutes
Form Factor	Stick Vacuum

8. Warranty and Support

Tineco is committed to providing excellent customer service and support for your FLOOR ONE S9 Master.

- **Warranty:** The product comes with a 2-year warranty.
- **Customer Service:** Expect a quick response within 24 hours for inquiries.
- **Repair Service:** Tineco offers a global repair service with a typical turnaround time of 5 days.

For any assistance, please visit the official Tineco website or contact their customer support directly.



Figure 8.1: Tineco Premium Service overview.

9. Product Video

Watch the official product video for a visual guide on the Tineco FLOOR ONE S9 Master's features and operation.

Your browser does not support the video tag.

Video 9.1: Official product demonstration of the Tineco FLOOR ONE S9 Master.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question