

ANGELBLISS B001

ANGELBLISS Electric Baby Bassinet B001 User Manual

Model: B001

[Overview](#) [Assembly](#) [Operation](#) [Safety Information](#) [Product](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembling and using the ANGELBLISS Electric Baby Bassinet. Failure to follow these instructions could result in serious injury or death to your child. Keep this manual for future reference.

- **Suffocation Hazard:** Infants can suffocate in gaps between an extra mattress and the side of the bassinet, or on soft bedding. Use only the mattress provided by the manufacturer. NEVER add a pillow, comforter, or another mattress for padding.
- **Fall Hazard:** To prevent falls, do not use this product once your infant begins to push up on hands and knees, or has reached the maximum weight of 19.8 pounds (9 kg), whichever comes first.
- **Strangulation Hazard:** Keep cords, including the power cord, away from children. Never place the bassinet near windows where cords from blinds or drapes could strangle a child.
- Always ensure the bassinet is placed on a firm, flat surface.
- Do not use the bassinet if any parts are missing, damaged, or broken. Contact customer service for replacement parts.
- Regularly check all fasteners to ensure they are tight and secure.
- Never leave your child unattended in the bassinet.
- This bassinet is not intended for prolonged periods of sleep for older infants.

2. PRODUCT OVERVIEW

The ANGELBLISS Electric Baby Bassinet (Model B001) is a versatile 3-in-1 solution designed for infant comfort and parental convenience. It functions as a standalone bassinet, a bedside sleeper, and an electric rocking bassinet. Key features include adjustable height, remote control operation, multiple rocking speeds, soothing sounds, and a convenient storage basket.



Image: The ANGELBLISS Electric Baby Bassinet, showcasing its modern design and black fabric with wooden-look frame.

Key Features:

- **3-in-1 Functionality:** Easily converts between a bedside sleeper, electric rocking bassinet, and a stationary bassinet.
- **Adjustable Height:** 6 height settings (33.46" to 38.78") to match various bed heights.
- **Electric Rocking:** Features 5 adjustable rocking speeds and 3 timer settings (15, 30, 45 minutes).
- **Soothing Sounds:** Includes 12 built-in melodies and white noise options.
- **Remote Control:** Conveniently adjust settings from a distance.
- **Breathable Mesh Sides:** Ensures optimal airflow and visibility of your baby.
- **Lockable Wheels:** Allows for easy room-to-room movement and secure positioning.
- **Storage Basket:** A lower basket provides easy access to baby essentials.
- **Comfortable Mattress:** Includes a firm, supportive mattress with a removable, washable cover.

Product Video Overview

Your browser does not support the video tag.

Video: An overview of the Angelbliss Bassinet Bedside Sleeper, demonstrating its features and functionality.

3. PACKAGE CONTENTS

Ensure all components are present before assembly:

- Bassinet Frame (main structure with legs and wheels)
- Bassinet Basket (fabric and mesh sleeping area)
- Mattress
- Mattress Cover (pre-installed or separate)
- Remote Control
- Power Adapter
- Storage Basket (lower attachment)
- Instruction Manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your ANGELBLISS Electric Baby Bassinet:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all package contents are present.
2. **Assemble the Frame:** Connect the main frame components according to the diagrams in the included printed manual. Ensure all locking mechanisms click into place securely.
3. **Attach the Bassinet Basket:** Secure the bassinet fabric basket to the assembled frame. Ensure the zippers and fasteners are fully engaged and tight.
4. **Insert Mattress:** Place the provided mattress into the bassinet basket. Ensure it fits snugly without gaps.
5. **Attach Storage Basket:** Connect the lower storage basket to the designated points on the frame.
6. **Power Connection:** Plug the power adapter into the bassinet's control panel and then into a wall outlet.

Your browser does not support the video tag.

Video: Demonstrates how to set up the bedside sleeper, adjust height, and use the wheels.

5. OPERATING INSTRUCTIONS

5.1 Adjusting Height

The bassinet offers 6 adjustable height levels to align with various bed heights. To adjust:

- Locate the height adjustment buttons/levers on each side of the bassinet frame.
- Press and hold the buttons/levers while simultaneously raising or lowering the bassinet to the desired height.
- Ensure both sides are adjusted to the same level and lock securely into place before use.

5

SWINGING SPEED

15 min (Quick Soothe)

30 min (Mid Nap)

45 min (Extended Rest)



Image: Detail of the height adjustment mechanism on the bassinet leg, showing numbered settings.

5.2 Bedside Sleeper Mode

To use as a bedside sleeper, ensure the bassinet is at an appropriate height for your bed.

- Adjust the bassinet height so the top edge of the bassinet is level with or slightly below your mattress.
- Lower one side panel of the bassinet by unzipping or releasing the fasteners.
- Position the bassinet securely against your bed, ensuring there are no gaps between the bassinet and your mattress.
- Always ensure the bassinet is stable and cannot move away from your bed.



Image: The bassinet positioned as a bedside sleeper, showing its proximity to an adult bed for easy access to the baby.

5.3 Electric Rocking Function

The bassinet features 5 rocking speeds and 3 timer settings (15, 30, 45 minutes).

- **Activation:** Ensure the bassinet is plugged in. Unlock both side sliders, release base supports, and lock all wheels before activating the rocking function.
- **Speed Adjustment:** Use the control panel on the bassinet or the remote control to select one of the 5 rocking speeds.
- **Timer Setting:** Select a timer duration (15, 30, or 45 minutes) for automatic shut-off.

Premium Cotton Fiber Support Mattress Cozy, Breathable And Firm



Image: A baby resting in the bassinet, illustrating the 5 swinging speeds and timer options for soothing.

5.4 Sound Functions

The bassinet includes 12 soothing sounds to help calm your baby.

- Use the control panel or remote control to cycle through the available sounds.
- Adjust the volume to a comfortable level for your baby.

5.5 Remote Control Usage

The remote control allows for convenient adjustment of rocking speed, timer, and sounds.

- Point the remote control directly at the receiver on the bassinet's control panel for optimal response.
- Ensure there are no obstructions between the remote and the bassinet.



BEDSIDE SLEEPER

Ensures Certified Safety and Optimal Comfort

Image: A woman operating the bassinet with a remote control, highlighting the convenience of remote operation for sound and rocking features.

5.6 Wheels and Portability

The bassinet is equipped with smooth-gliding, lockable wheels for easy movement.

- To move the bassinet, unlock all four wheels.
- Once positioned, lock all wheels to ensure stability and prevent accidental movement.
- This bassinet is designed for room-to-room use within the home and is not intended as a compact travel crib.

5.7 Storage Basket

A convenient storage basket is located beneath the bassinet for keeping baby essentials within reach.



Image: A hand placing a baby bottle into the bassinet's lower storage basket, which is shown holding diapers and a soft toy.

6. MAINTENANCE AND CARE

Proper care ensures the longevity and hygiene of your bassinet.

- **Mattress Cover:** The mattress cover is removable and machine-washable. Follow the care instructions on the label, typically machine wash cold on a gentle cycle and tumble dry low.
- **Bassinet Fabric:** The main bassinet fabric should be hand washed only or dry cleaned. Do not machine wash or bleach.
- **Frame:** Wipe the metal and plastic parts of the frame with a damp cloth and mild soap. Dry thoroughly.
- **Regular Checks:** Periodically inspect the bassinet for any loose parts, tears in fabric, or damage to the mesh. Discontinue use if any damage is found.

7. TROUBLESHOOTING

If you encounter issues with your ANGELBLISS Electric Baby Bassinet, refer to the following common solutions:

Problem	Possible Cause	Solution
Bassinet does not rock or power on.	Not plugged in, power adapter faulty, side sliders locked, base supports not released, wheels not locked.	Ensure power cord is securely plugged into the bassinet and a working outlet. Check if side sliders are unlocked, base supports are released, and wheels are locked as per "Auto Rocking Reminder" in the feature bullets. If issues persist, contact support.
Remote control not responding.	Batteries low/dead, remote not pointed correctly, obstruction.	Replace remote control batteries. Ensure the remote is pointed directly at the bassinet's control panel without obstructions.
Clicking sound during rocking.	Mechanism obstruction, loose part.	Inspect the rocking mechanism for any foreign objects or loose components. Ensure all assembly points are secure. If the sound persists, discontinue use and contact customer service.
Bassinet feels unstable.	Wheels unlocked, uneven surface, assembly not secure.	Ensure all wheels are locked. Place the bassinet on a firm, level surface. Recheck all assembly connections to ensure they are tight and secure.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	ANGELBLISS
Model Number	B001
Color	Black
Product Dimensions (L x W x H)	35.24" x 21.46" x 38.78"
Mattress Dimensions (L x W x H)	30.94" x 19.57" x 1"
Material	Mesh, Metal (Iron Frame), Polyester
Maximum Weight Recommendation	19.8 pounds (9 kg)
Adjustable Heights	6 levels (33.46" to 38.78")
Rocking Speeds	5
Timer Settings	3 (15, 30, 45 minutes)
Soothing Sounds	12
Included Components	Mattress, Remote Control
Product Weight	24.3 pounds
Care Instructions	Mattress Cover: Machine Washable. Bassinet Fabric: Hand Wash Only / Dry Clean Only.

9. WARRANTY AND CUSTOMER SUPPORT

ANGELBLISS is committed to providing high-quality products. For specific warranty details, please refer to the warranty card included with your purchase or contact ANGELBLISS customer service directly.

If you have any questions, require assistance with assembly, or need troubleshooting support, please contact our customer service team. Contact information can typically be found on the product packaging or the official ANGELBLISS website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question