ICEVOKE LYCZ628B1-1208

ICEVOKE LYCZ628B1-1208 4-in-1 Water Dispenser and Ice Maker Instruction Manual

Model: LYCZ628B1-1208

1. Introduction

Thank you for choosing the ICEVOKE 4-in-1 Water Dispenser with Bullet Ice Maker. This versatile appliance provides hot, cold, and room-temperature water, along with bullet-shaped ice cubes, offering convenience for various beverage needs. It features a bottom-loading design, child safety lock, UV self-cleaning, and an energy-saving ECO mode. Please read this manual thoroughly before operation to ensure safe and efficient use.



Figure 1: ICEVOKE 4-in-1 Water Dispenser with Smart Integrated Design, offering hot, cold, room temperature water, and ice cubes.

2. Safety Information

- Always ensure the appliance is placed on a flat, stable surface.
- Keep the dispenser at least 8 inches (20 cm) from walls to allow for proper ventilation.
- Do not operate the dispenser without a water bottle installed.
- The hot water function is equipped with a child safety lock. Always engage the child lock when not in use, especially in households with children, to prevent accidental burns.
- Unplug the unit before cleaning or performing any maintenance.
- Do not immerse the appliance, cord, or plug in water or other liquids.

3. Setup

3.1 Unpacking and Placement

1. Carefully remove the dispenser from its packaging.
2. Place the dispenser on a level, stable surface away from direct sunlight and heat sources. Ensure there is at least 8 inches of clearance from walls for adequate airflow.

3. Allow the unit to stand upright for at least 2 hours before plugging it in to allow refrigerants to settle.

3.2 Installing the Water Bottle

1. Open the bottom cabinet door of the dispenser.
2. Remove the protective seal from your 3 or 5-gallon water bottle.
3. Insert the probe (metal tube with cap) into the water bottle opening. Ensure it is securely fitted.
4. Slide the water bottle into the bottom cabinet.
5. Close the cabinet door.



Figure 2: Illustration of the bottom-loading water bottle installation, showing the probe inserted into the bottle.

3.3 Initial Cleaning and Priming

1. Plug the dispenser into a grounded electrical outlet.
2. Allow the internal tanks to fill with water. This may take a few minutes.
3. Activate the self-cleaning mode by pressing and holding the 'Making Ice' button for 3 seconds. The unit will run a 10-minute deep cleaning cycle.
4. After the cleaning cycle, dispense and discard at least 1 liter of water from each tap (hot, cold, room temperature) to flush the system.

4. Operating Instructions

4.1 Control Panel Overview



Figure 3: Easy-to-Use Control Panel with indicators for ECO mode, child lock, water levels, and water/ice dispensing.

- **ON/OFF:** Power button for the entire unit.
- **Cold Water:** Dispenses chilled water.
- **Fresh Water:** Dispenses room-temperature water.
- **Hot Water:** Dispenses hot water (requires child lock release).
- **Child Lock:** Safety feature for hot water.
- **Lack of Water:** Indicator light for low water bottle level.
- **Making Ice:** Indicator for ice production status.
- **Ice Volume:** Indicates the amount of ice available.
- **ECO (Energy Saving):** Activates energy-saving mode.

4.2 Dispensing Water

1. Place a cup on the drip tray beneath the dispenser spouts.
2. **For Cold Water:** Press the 'Cold Water' button.
3. **For Room Temperature Water:** Press the 'Fresh Water' button.
4. **For Hot Water:** First, press the 'Child Lock' button, then press the 'Hot Water' button.

Your browser does not support the video tag.

Video 1: Overview of the 4-in-1 water dispenser functions, including hot, cold, and room temperature water dispensing.

4.3 Ice Making Function

1. Ensure the 'Making Ice' indicator is illuminated. If not, press the 'Making Ice' button to activate.
2. The unit will produce 9 bullet-shaped ice cubes in 7-15 minutes, with a daily capacity of 22 lbs.
3. The ice maker will automatically stop when the ice basket is full.
4. To dispense ice, place a cup under the ice spout and push the ice dispensing paddle.




Figure 4: Details on the fast and efficient ice making capability, producing bullet-shaped ice cubes.

4.4 ECO Mode (Energy Saving)

- Press the 'ECO' button to activate energy-saving mode.
- In ECO mode, the machine will stop heating water at night to reduce unnecessary energy consumption.

4.5 Nightlight Feature

- The built-in nightlight illuminates the operating area and outlet, providing visibility in dark environments and preventing spills.

4.6 Water Shortage Indicator

- The 'Lack of Water' indicator light will illuminate when the water bottle is low, prompting you to replace it and extending the service life of the water pump.

5. Maintenance

5.1 UV Self-Cleaning System

1. The dispenser features an advanced dual cleaning system with built-in UV light.
2. To activate the self-cleaning mode, press and hold the 'Making Ice' button for 3 seconds. The unit will run a 10-minute deep cleaning cycle to keep ice pure and the machine fresh.



Figure 5: Illustration of the UV-infused cleaning system, which reduces contaminants and improves water taste.

5.2 Drip Tray Cleaning

- The drip tray is removable for easy cleaning. Regularly remove and clean the drip tray to prevent water overflow and maintain hygiene.

5.3 General Cleaning

- Wipe the exterior of the dispenser with a soft, damp cloth. Do not use abrasive cleaners.
- The internal components are made of food-grade stainless steel for easy cleaning and reduced harmful substances.

6. Troubleshooting

Problem	Possible Cause	Solution
No water dispensing	Water bottle empty; unit unplugged; pump not primed.	Replace water bottle; check power connection; ensure tanks are filled after installation.
Hot water not dispensing	Child lock engaged; heating function off.	Release child lock (press 'Child Lock' then 'Hot Water'); ensure heating is active.
No ice production	Ice making function off; water bottle empty; ice basket full.	Press 'Making Ice' button; replace water bottle; empty ice basket.
Water has unusual taste	Initial use; system needs cleaning.	Run self-cleaning cycle and flush system thoroughly.

7. Specifications

- **Brand:** ICEVOKE
- **Model Number:** LYCZ628B1-1208
- **Color:** Black
- **Material:** Acrylonitrile Butadiene Styrene (ABS), Stainless Steel
- **Capacity:** 5 Gallons (compatible with 3 or 5-gallon bottles)
- **Product Dimensions:** 16.54"D x 12.2"W x 40.75"H
- **Item Weight:** 44 pounds
- **Power Source:** Corded Electric
- **Installation Type:** Freestanding
- **Access Location:** Bottom

8. Warranty and Support

This ICEVOKE water dispenser is backed by a 1-year warranty. For any questions, technical assistance, or warranty claims, please contact our after-sale service and technical team. We are committed to responding to your inquiries within hours to ensure your satisfaction.