

[Manuals.plus](#) /

› [SUNROAD](#) /

› SUNROAD Snowmobile Dolly Set (Model G69000097) Instruction Manual

SUNROAD G69000097

SUNROAD Snowmobile Dolly Set

Model: G69000097

INTRODUCTION

This manual provides instructions for the safe and effective use of your SUNROAD 3-Pack Snowmobile Dolly Set. This set is designed to facilitate the movement and positioning of snowmobiles up to 1500 lb (682 kg) for storage, maintenance, or cleaning. Please read this manual thoroughly before assembly and operation to ensure proper usage and to prevent injury or damage.

SAFETY INFORMATION

- Always ensure the snowmobile's weight does not exceed the dolly set's maximum capacity of 1500 lb (682 kg).
- Verify that all straps are securely fastened and tightened before moving the snowmobile.
- Operate the dollies on a flat, level, and clear surface. Avoid inclines, uneven terrain, or obstacles.
- Move the snowmobile slowly and with caution to maintain control.
- Keep hands and feet clear of moving parts, especially the wheels and the underside of the snowmobile.
- Do not use the dollies for purposes other than moving snowmobiles.
- Inspect dollies for damage or wear before each use. Do not use if components are damaged.

PACKAGE CONTENTS

The SUNROAD Snowmobile Dolly Set includes the following components:

- 2 x Ski Dollies with V-Rubber Trays and Ratchet Straps
- 1 x Track Dolly with Swivel Casters
- Assembly Hardware (bolts, nuts, washers)

Product *Specifications*



Maximum Load
Capacity: **1500lbs**

Image: Overview of the snowmobile dolly set components, including two ski dollies and one track dolly, highlighting the 1500 lbs maximum load capacity.

SETUP

The SUNROAD Snowmobile Dolly Set is designed for quick and minimal assembly. No complex tools are required, and the system can be ready for use within minutes.

1. Unpack all components and verify against the package contents list.
2. Attach the swivel casters to the underside of each dolly (two ski dollies and one track dolly) using the provided hardware. Ensure all bolts are securely tightened.
3. For the ski dollies, ensure the V-rubber trays are properly seated and the ratchet straps are accessible for securing the skis.



*Upgraded
PU material
for wheels*

12

Product usage will be more durable



Image: An assembled set of two blue ski dollies with red straps and one blue track dolly, showcasing the 12 polyurethane swivel casters.

Upgraded PU Material Caster

After



PU Material

Others



PP Material

Image: A close-up comparison showing the upgraded PU material caster with a dual ball-bearing design, indicating its durability and smooth operation compared to a standard PP material caster.

OPERATING INSTRUCTIONS

Follow these steps to safely move your snowmobile using the dolly set:

1. **Prepare the Snowmobile:** Ensure the snowmobile is turned off and the parking brake (if applicable) is engaged.
2. **Position Ski Dollies:** Lift the front of the snowmobile slightly and slide one ski dolly under each ski. Ensure the ski rests securely within the V-rubber tray.
3. **Secure Skis:** Use the heavy-duty adjustable ratchet straps on each ski dolly to firmly secure the skis to the dollies. The V-rubber trays and straps help prevent shifting or slipping.
4. **Position Track Dolly:** Lift the rear of the snowmobile and place the track dolly underneath the track, positioning it centrally.
5. **Verify Stability:** Before moving, gently test the snowmobile's stability on the dollies. Ensure it is balanced and all dollies are properly positioned and secured.
6. **Move Snowmobile:** Slowly push or pull the snowmobile to its desired location. The 360° swivel casters allow for smooth and

controlled movement in any direction.

7. **Remove Dollies:** Once the snowmobile is in its final position, lift the snowmobile slightly to remove the dollies.



1 Lift the sled motor and place it into the dolly. Secure the with Velcro straps.

2 Repeat the action with the other dolly on the opposite side and secure it.



3 Lift the rear wheel of the sled motor and place the third dolly underneath, positioning it in the center.

4 Check if the front and rear are securely fastened and if the sled motor is balanced.




Image: A four-step visual guide demonstrating how to place a snowmobile onto the dollies, including lifting the sled, securing skis with Velcro straps, placing the track dolly, and checking for balance.



**360°
NO DEAD ANGLE**

Free Rotating Wheels

Easily transport your snowmobile

Image: A close-up of a dolly wheel with an arrow indicating 360-degree flexible rotation, emphasizing the ease of maneuvering the snowmobile.



Image: A blue snowmobile resting on the SUNROAD dolly set, showcasing its stable position and readiness for movement within a storage facility.

MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your dolly set:

- **Cleaning:** Wipe down the dollies with a damp cloth to remove dirt, dust, or debris. Avoid harsh chemicals that may damage the finish or rubber components.
- **Caster Inspection:** Periodically check the swivel casters for smooth rotation and ensure they are free of tangled debris (e.g., hair, string). Lubricate if necessary.
- **Hardware Check:** Regularly inspect all bolts, nuts, and fasteners to ensure they remain tight. Re-tighten as needed.
- **Strap Condition:** Examine the ratchet straps for any signs of fraying, cuts, or wear. Replace damaged straps immediately.
- **Storage:** Store the dollies in a dry place when not in use to prevent rust and prolong material life.

TROUBLESHOOTING

If you encounter issues with your snowmobile dolly set, consider the following:

- **Difficulty Moving:**
 - Ensure the surface is clean and free of debris.
 - Check if the snowmobile's weight exceeds the 1500 lb capacity.
 - Verify that all casters are rotating freely and are not obstructed.
- **Snowmobile Instability:**
 - Re-check that skis are properly seated in the V-rubber trays.
 - Ensure ratchet straps are securely tightened.
 - Confirm the track dolly is centered under the snowmobile's track.
- **Damaged Components:** If any part of the dolly set is damaged, discontinue use immediately and contact customer support for assistance.

SPECIFICATIONS

Brand	SUNROAD
Model Number	G69000097
Color	Blue
Load Capacity	1500 Pounds (682 kg)
Item Weight	14.99 pounds
Product Dimensions	9.84"L x 7.87"W x 3.35"H (per dolly)
Number of Wheels	12 (4 per dolly)
Caster Wheel Diameter	1.8 Inches
Material	Reinforced Steel Frame, PU Swivel Casters, V-Rubber Trays

WARRANTY INFORMATION

This SUNROAD Snowmobile Dolly Set is backed by a 6-month limited warranty. This warranty covers manufacturing defects and material flaws under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or normal wear and tear. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your SUNROAD Snowmobile Dolly Set, please contact SUNROAD customer support. You may also visit the official SUNROAD store on Amazon for more information and product details: [Visit the SUNROAD Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question