

Feihe SR-15.6GST

Feihe 15.6 Inch Small Smart TV User Manual

Model: SR-15.6GST

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before using your new Feihe Smart TV. Keep this manual for future reference. Observe all warnings and instructions marked on the product.

- Do not block ventilation openings.
- Do not install near any heat sources.
- Protect the power cord from being walked on or pinched.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods.
- Refer all servicing to qualified service personnel.

2. WHAT'S IN THE BOX

Verify that all components are present upon unboxing:

- 15.6 inch Smart TV
- Remote Control
- TV Stand
- Power Cable
- User Manual (this document)

Feihe | SMART TV

15.6" Compact Size Smart TV Dimensions & Accessories Detail

TV with stand size:

L 14.96 x H 13.78 inch

TV without stand size:

L 14.96 x H 10.71 inch



What in the box:

- 15.6 inch Smart TV
- Power Cable
- TV Stand
- User Manual
- Remote



Image: Contents of the Feihe 15.6 inch Smart TV box.

3. SETUP

3.1 Stand Installation

To install the included TV stand, follow these steps:

1. Carefully place the TV face down on a soft, clean surface to prevent screen damage.
2. Align the stand with the mounting holes on the back of the TV.
3. Secure the stand using the provided screws. Ensure the stand is firmly attached.

Video: Official guide for installing the TV stand. This video demonstrates the process of attaching the stand to the back of the Feihe Smart TV using screws.

3.2 Placement and Dimensions

The Feihe 15.6 inch Smart TV is designed for compact spaces. Consider the following dimensions for optimal placement:

- **TV with Stand Size:** L 14.96 inch × H 13.78 inch × W 4.72 inch
- **TV without Stand Size:** L 14.96 inch × H 10.71 inch × W 1.97 inch

The TV can be placed on a table or mounted using a VESA 100 x 100 mm mount (mounting hardware not included).



Image: Detailed dimensions of the Feihe 15.6 inch Smart TV with and without its stand.

3.3 Power Connection

Connect the power cable to the TV's power input and then plug it into a standard AC 100-240V electrical outlet.

3.4 Initial Setup

Upon first power-on, the TV will guide you through the initial setup process:

1. **Language Selection:** Choose your preferred language.
2. **Network Connection:** Connect to your Wi-Fi network. The TV supports Dual 2.4/5 GHz Wi-Fi.
3. **Smart TV Account:** You may need to create or log in to a Smart TV OS account to access streaming services and smart features. This typically requires a computer or mobile device.
4. **Channel Scan:** If using an antenna, perform a channel scan to find available channels.

4. OPERATING INSTRUCTIONS

4.1 Basic Controls

Use the included remote control to navigate the TV's interface. Common functions include:

- **Power:** Turn the TV on/off.
- **Volume:** Adjust audio levels.
- **Channel:** Change TV channels (if using an antenna).
- **Navigation:** Arrow keys and OK button to move through menus.
- **Home:** Access the Smart TV home screen.
- **Voice Remote:** Press the voice button on the remote to use voice commands for navigation and content search.

4.2 Smart TV Features

Your Feihe Smart TV provides access to a wide range of entertainment options:

- **Streaming Apps:** Access popular services like Netflix, YouTube, Prime Video, Hulu, and Apple TV directly from the TV's interface.
- **Miracast:** Use Miracast technology to mirror content from compatible devices to your TV screen.
- **Live TV Channels:** Explore over 1000+ free live channels.




Image: The Smart TV interface showing available streaming applications.

4.3 Connectivity Options

The TV offers multiple ports for connecting external devices:

- **HDMI (x3):** Connect gaming consoles, Blu-ray players, or other HDMI-enabled devices.
- **USB 2.0 (x2):** Play media files from USB drives.
- **AV-in (x1):** Connect older devices using composite video and stereo audio.
- **RJ45 (Ethernet x1):** For a wired internet connection.
- **SPDIF_OUT (Optical x1):** For digital audio output to soundbars or home theater systems.
- **Earphone (3.5mm x1):** For connecting headphones.
- **Bluetooth 5:** Connect wireless headphones or speakers.



Image: Overview of the TV's input and output ports.

Note: This TV does not support traditional cable TV services from major providers such as Xfinity TV, DirecTV, Comcast TV, Spectrum TV, or Verizon Cable TV apps.

5. MAINTENANCE

5.1 Cleaning the TV

To clean your TV, ensure it is powered off and unplugged. Use a soft, dry cloth to wipe the screen and exterior surfaces. For stubborn marks, lightly dampen the cloth with water or a screen-safe cleaning solution. Avoid using harsh chemicals or abrasive materials.

5.2 Software Updates

Your Smart TV may receive periodic software updates to improve performance and add new features. Ensure your TV is connected to the internet to receive these updates. You can usually check for updates in the TV's settings menu.

6. TROUBLESHOOTING

If you encounter issues with your Feihe Smart TV, refer to the following common solutions:

Problem	Possible Solution
No Power	Ensure the power cable is securely connected to both the TV and the electrical outlet. Check if the outlet is working.
No Picture / Black Screen	Verify the TV is on. Check input source (HDMI, AV) is correctly selected. Ensure external devices are powered on and connected.
No Sound	Check volume levels on both the TV and any connected external audio devices. Ensure mute is not activated. Check audio cables if using external speakers.

Problem	Possible Solution
Wi-Fi Connection Issues	Restart your router and the TV. Ensure the Wi-Fi password is correct. Move the TV closer to the router if possible.
Remote Control Not Working	Replace the AAA batteries (2 required). Ensure there are no obstructions between the remote and the TV's IR sensor.
Poor Viewing Angle	The optimal viewing angle is 150° on both sides. Adjust the TV's position for best viewing.

If the problem persists after trying these solutions, please contact Feihe customer support.

7. SPECIFICATIONS

Feature	Detail
Model Name	SR-15.6GST
Screen Size	15.6 inches
Display Technology	LED
Resolution	1080p (1920x1080)
Refresh Rate	60 Hz
Aspect Ratio	16:9
Contrast Ratio	16:9
Maximum Display Brightness	300 nit
Response Time	15 milliseconds
Connectivity	Wi-Fi (Dual 2.4/5 GHz), Bluetooth 5, HDMI (x3), USB 2.0 (x2), AV-in (x1), RJ45 (x1), SPDIF_OUT (x1), Earphone (x1)
Audio Output	Dual Stereo Speakers, 10 watts total
Tuner Type	ATSC/NTSC
Power Input	AC 100-240V, 110 watts
Product Dimensions (with stand)	14.96"W x 13.78"H x 4.72"D
Product Dimensions (without stand)	14.96"W x 10.71"H x 1.97"D
VESA Mount Standard	100 x 100 mm
Memory Storage Capacity	2 GB
Included Components	15.6 inch Smart TV, Remote Control, Stand, User Manual

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Feihe 15.6 Inch Small Smart TV comes with **aone-year limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. Please retain your proof of purchase for warranty claims.

8.2 Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact Feihe customer support. You can find contact information on the official Feihe website or through your retailer.

We are committed to providing responsive customer support for any issues you may encounter with your product.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question