

[Manuals.plus](#) /

› [Cozyman](#) /

› Cozyman 24" H Saddle Counter Stools (Set of 4) Instruction Manual

## Cozyman B0G5XLZKQ9

# Cozyman 24" H Saddle Counter Stools (Set of 4) Instruction Manual

Model: B0G5XLZKQ9

## INTRODUCTION

This manual provides detailed instructions for the assembly, use, and maintenance of your Cozyman 24" H Saddle Counter Stools. Please read carefully before assembly and retain for future reference.

## SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly.
- Regularly check and tighten all fasteners to ensure stability.
- Do not stand on the stool.
- Maximum weight capacity: 300 lbs (136 kg). Do not exceed this limit.
- Keep children away from small parts during assembly.

## PACKAGE CONTENTS

Verify that all components are included in your package. If any parts are missing or damaged, please contact customer support.

- 4 x Saddle Counter Stool Seats
- 4 x Stool Leg Assemblies
- Hardware Pack (screws, washers, Allen wrench)
- Instruction Manual

## SETUP AND ASSEMBLY

Assembly is straightforward and typically takes 10-15 minutes per stool.

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a clean, soft surface to prevent damage.
2. **Identify Parts:** Refer to the included diagram (if available) to identify each component.

3. **Attach Legs to Seat:** Align the leg assembly with the pre-drilled holes on the underside of the saddle seat. Insert the provided screws and washers.
4. **Secure Fasteners:** Hand-tighten all screws initially. Once all screws are in place, use the included Allen wrench to fully tighten them. Do not overtighten.
5. **Check Stability:** After assembly, gently rock the stool to ensure it is stable. If it wobbles, loosen the screws slightly, sit on the stool to settle the legs, then retighten the screws.



Image: Detailed dimensions of the Cozyman 24-inch saddle counter stool, highlighting the 24-inch seat height and 300 lbs maximum weight capacity. This image helps in understanding the product's size and load limits.

# 24" Counter Height Bar Stools



*Ergonomic & Saddle Seat*



*Sturdy Solid Wood Frame*



*Non-slip & Leveling Feet*

Image: Key features of the Cozyman counter stool, including the ergonomic saddle seat design, solid wood frame construction, and adjustable non-slip leveling feet for stability on uneven surfaces.

## OPERATING INSTRUCTIONS (USAGE)

- **Seating:** Sit centrally on the saddle seat for optimal comfort and stability.
- **Weight Limit:** Do not exceed the maximum weight capacity of 300 lbs (136 kg) per stool.
- **Placement:** Position the stools on a flat, stable surface. Use the leveling feet if necessary to prevent wobbling.
- **Movement:** Lift the stool when moving it to avoid dragging and potential damage to legs or flooring.

# Ergonomic Saddle And Thickness Design



*Skin-friendly, Breathable Fabric*



*Puff Ribbed Design*

Image: Close-up view of the stool's ergonomic saddle and thick cushion, highlighting the skin-friendly, breathable fabric and puff ribbed design for enhanced comfort.

## MAINTENANCE

- **Cleaning:** For fabric upholstery, spot clean with a damp cloth and mild detergent. Blot dry immediately. Do not use harsh chemicals.
- **Wood Care:** Wipe wooden legs with a soft, dry cloth. Avoid abrasive cleaners.
- **Fasteners:** Periodically check all screws and bolts and tighten them as needed to maintain structural integrity.
- **Protection:** Avoid prolonged exposure to direct sunlight or extreme temperatures to prevent fading or warping.

## TROUBLESHOOTING

### Stool is wobbly

**Solution:** Ensure all screws are securely tightened. If wobbling persists, loosen all screws slightly, sit on the stool to evenly distribute weight and settle the legs, then retighten the screws. Adjust the leveling feet if your floor is uneven.

Scratches on floor

**Solution:** Ensure the non-slip leveling feet are properly installed and intact. Replace worn feet if necessary. Avoid dragging the stools; always lift them when moving.

Fabric appears discolored

**Solution:** Note that under different lighting conditions, the color of the product may appear slightly different. This is normal and not a defect. Avoid direct sunlight exposure to prevent fading.



Image: Comparison of Cozyman bar stools under bright and dim lighting, demonstrating that the product's color perception can change based on ambient light conditions.

SPECIFICATIONS

| Feature            | Detail             |
|--------------------|--------------------|
| Product Dimensions | 22"D x 20"W x 24"H |

| Feature                       | Detail              |
|-------------------------------|---------------------|
| Color                         | Cream White         |
| Frame Material                | Wood (Rubberwood)   |
| Seat Material Type            | Linen               |
| Style                         | Modern              |
| Number of Pieces              | 4                   |
| Seat Height                   | 24 Inches           |
| Maximum Weight Recommendation | 300 Pounds (136 kg) |
| Assembly Required             | Yes                 |

## WARRANTY

Cozyman products are manufactured with quality and care. For specific warranty details, please refer to the warranty card included with your purchase or contact Cozyman customer support.

## CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Cozyman customer support.

For the most up-to-date contact information, please visit the official Cozyman store on Amazon:[Cozyman Store](#).

## PRODUCT VIDEO

Watch this video for an overview of the Cozyman Graves Series Bar Stools.

Your browser does not support the video tag.

Video: An official product video showcasing the Cozyman Graves Series Bar Stools, demonstrating their design and features in a home setting.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0G5W7Y6M3>

More documents and user manuals: <https://manuals.plus/>