

## FEELNEEDY FN-W26

# FEELNEEDY Wireless No Filters Cat Water Fountain FN-W26 Instruction Manual

## 1. INTRODUCTION

---

The FEELNEEDY Wireless No Filters Cat Water Fountain (Model FN-W26) is designed to provide continuous fresh water for your pets. This manual provides essential information for the safe and efficient operation of your new pet water fountain. Please read these instructions thoroughly before use and retain them for future reference.

## 2. PRODUCT FEATURES

---

- **Revolutionary Wastewater Separation:** Features independent clean and wastewater tanks, ensuring continuous fresh water. A self-cleaning cycle automatically pours stale water, providing crisp and clean water every time.
- **No Filters, Pure Savings:** This design eliminates the need for weekly filter replacements, saving time and recurring costs.
- **180 Days Cordless Freedom:** Powered by a 3,000mAh USB-C rechargeable battery, offering up to 6 months of cordless operation per full charge. The 3.5L clean-water tank lasts 3–9 days.
- **304 Stainless Steel Bowl:** The drinking surface is made of 304-grade, rust-resistant stainless steel to prevent bacterial buildup and pet acne.
- **Quiet Operation:** A near-silent 30dB motor ensures peace. A brief 30–35dB water-refill sound occurs during pouring.
- **Fully Detachable for Easy Cleaning:** All parts are detachable and made from non-stick materials for quick and thorough cleaning.

## 3. PACKAGE CONTENTS

---



2. **Assemble Main Unit:** Align the main unit with the waste water tank and press vertically to connect.
3. **Attach Clean Water Tank:** Place and fit the clean water tank into the locking position at the bottom of the main unit.
4. **Install Water Bowl:** Insert the water bowl pin into the hole of the main unit, ensuring the horizontal positioning rocker is engaged with the slot.
5. **Attach Water Spout:** Securely attach the water spout to the designated opening.
6. **Charge Battery:** Connect the USB-C charging cable to the charging port and a power source. Ensure the battery is fully charged before first use.
7. **Fill Clean Water Tank:** Open the clean water tank lid and fill with fresh water up to the MAX line.
8. **Power On:** Turn on the power switch located on the side of the main unit. The fountain will perform an initial water change cycle.

Your browser does not support the video tag.

*Video 4.1: This video provides a step-by-step guide on how to properly install the FEELNEEDY Pet Water Fountain, ensuring all components are correctly assembled for optimal function.*



*Figure 4.2: This diagram provides a visual guide for assembling the fountain, showing how to connect the main unit, tanks, and water bowl.*

## 5. OPERATING INSTRUCTIONS

1. **Power On/Off:** Use the power switch on the side to turn the unit on or off.
2. **Manual Water Dispensing:** In the "FEED" mode, press the central dial to manually dispense fresh water into the bowl.
3. **Set Time:** Navigate to the "TIME" setting using the dial and adjust the current time.
4. **Program Schedule ("PLAN"):**
  - Access the "PLAN" mode.
  - Select one of the six available meal/watering times (Meal 1-6).
  - Adjust the desired time (hour and minute) for water dispensing.
  - Select the desired water volume (indicated by 1, 2, or 3 raindrops).
  - Repeat for additional scheduled dispensing times.
5. **Intelligent Alerts:** The display will show alerts for a full wastewater tank, low battery, or any

malfunction, prompting necessary action.

6. **Child Lock:** The unit features a child lock function to prevent accidental changes to settings.



## Intelligent Display Easy to Operate

Please refer to the instruction manual for more details

Figure 5.1: The intelligent display provides clear information and controls for setting water dispensing schedules and monitoring status.



Figure 5.2: The display features intelligent alerts to notify users about low battery, full wastewater tank, and potential malfunctions, ensuring timely action.

## 6. MAINTENANCE

1. **Regular Cleaning:** Regularly clean the stainless steel water bowl and the waste water tank.
2. **Empty Waste Water Tank:** When the "Waste Tank Full Alert" appears on the display, carefully remove the waste water tank and dispose of the dirty water.
3. **Clean Components:** Detach all removable parts (stainless steel bowl, waste tank, clean water tank, lids, spout) and wash them with mild soap and water. The stainless steel bowl is dishwasher safe.
4. **Rinse Thoroughly:** Ensure all components are thoroughly rinsed to remove any soap residue.
5. **Dry and Reassemble:** Dry all parts completely before reassembling the fountain.

Your browser does not support the video tag.

*Video 6.1: Watch this video to understand the innovative wastewater separation system of the FEELNEEDY Cat Water Fountain, demonstrating how clean and dirty water are kept separate for pet health.*



Figure 6.2: The image demonstrates the ease of cleaning the detachable stainless steel water bowl, which is also dishwasher safe.



## SUS 304 Stainless Steel Bowl





Figure 6.3: A detailed view of the 304 stainless steel drinking surface, designed for hygiene and to prevent bacterial buildup.

## 7. TROUBLESHOOTING

### • No Water Dispensing:

- Check if the clean water tank is filled.
- Ensure the battery is charged.
- Verify the water spout is correctly attached.
- Check for any "Malfunction Alert" on the display.

### • Water Tank Full Alert:

- Empty the waste water tank as described in the Maintenance section.

### • Battery Indicator Low:

- Recharge the fountain using the provided USB-C cable.

- **Unusual Noise:**

- Ensure all components are correctly assembled and seated.
- Check for any obstructions in the water flow path.

- **Water Quality Issues:**

- Perform a thorough cleaning of all components.
- Ensure only fresh, clean water is used in the clean water tank.

## 8. SPECIFICATIONS

Feature	Detail
Brand	FEELNEEDY
Model Number	FN-W26
Color	Black
Material	Acrylonitrile Butadiene Styrene (ABS)
Product Dimensions	12.9"L x 9"W x 6.63"H
Capacity	3.5 Liters
Battery	3000mAh USB-C rechargeable (1 Nonstandard Battery included)
Battery Type	Lithium-Ion
Indoor Outdoor Usage	Indoor
Additional Features	No filters, Wastewater Separation
Included Components	Smart Water Fountain

## 9. WARRANTY AND SUPPORT

This FEELNEEDY product comes with a **3-year warranty** from the date of purchase.

For any issues, questions, or support needs, please feel free to contact us. You can reach our customer support team via Amazon message. To do so, click on our store name located under the "Buy Now" button on the product page, and then click "Ask a Question". Our team is committed to resolving your concerns within 12 hours.