Joyway TR013-New

Joyway 5-Piece Hardside Luggage Set (Model TR013-New) Instruction Manual

Introduction

Thank you for choosing the Joyway 5-Piece Hardside Luggage Set. This manual provides essential information for the proper setup, operation, and maintenance of your new luggage set. Please read these instructions carefully before use to ensure optimal performance and longevity of your product.

Product Features

- **5-Piece Luggage Set:** Includes a 20-inch carry-on, 24-inch medium checked luggage, 28-inch large check-in suitcase, a duffel bag, and a toiletry bag. Designed for convenient nesting storage.
- **Quick Access Front Pocket:** The 20-inch carry-on features a top front opening pocket for easy access to passports, electronics, and essentials. It includes a soft cloth lining in the laptop compartment for added device protection.
- **TSA Lock & Detachable Spinner Wheels:** Integrated TSA-approved combination locks provide security for international travel. 360-degree rotating silent spinner wheels offer smooth maneuverability and are detachable for quick repair or replacement.
- **Telescoping Handle & YKK Zipper:** Customizable height telescopic handles ensure comfortable pushing and pulling. High-quality YKK zippers provide smooth and reliable opening and closing.
- **Travel Luggage Assistant & Grip Handles:** The duffel bag is designed for organizing personal items and can be effortlessly attached to luggage handles. Top and side grip handles on suitcases enhance carrying comfort.
- **Spacious Interior & PC Shell Material:** Zippered compartments and retractable cross straps keep the interior organized. Crafted from lightweight and durable PC material.

Setup

1. Setting Your TSA Combination Lock

Your luggage is equipped with a TSA-approved combination lock. The initial combination is set to 0-0-0.

1. Turn the dials to the current opening combination (factory default is 0-0-0).
2. Press down the reset button (usually a small button or hole) with a pen or other pointed tool until you hear a "click" sound.
3. Turn the dials to your desired personal combination.
4. Push the button (usually a larger button or lever) toward the direction of the arrow. You will hear another "click" sound, indicating your new combination is set.



Image: Detailed steps for setting the TSA combination lock on your Joyway luggage.

2. Detachable Spinner Wheels

The spinner wheels are designed for easy detachment and reattachment. This feature allows for quick maintenance or replacement if needed.



Image: Visual guide for detaching and reattaching the universal silent wheels.

Operating Instructions

1. Using the Telescoping Handle

Extend the handle by pressing the push-button locking mechanism and pulling the handle upwards. Adjust to your preferred height. Push the button again to retract the handle for storage.



Image: Demonstrating the adjustable 3-section telescoping handle.

2. Utilizing the Quick Access Front Pocket (20-inch Carry-on)

The front pocket allows for convenient access to items like laptops, tablets, and travel documents without fully opening the main compartment. Unzip the front panel to reveal dedicated compartments for electronics and other essentials.



Image: A laptop being placed into the quick-access front pocket of the carry-on luggage.

3. Internal Organization

Each suitcase features a squared full-capacity design with internal lining, zippered compartments, and cross straps to secure your belongings. This helps in classifying clothes, shoes, and personal documents efficiently.



Image: The interior of the luggage, highlighting the fixation buckle, storage pockets, and durable zippers for organized packing.

4. Expanding Luggage Capacity

For additional packing space, unzip the expansion layer located around the perimeter of the suitcase. This provides approximately 20-25% more capacity.




Image: Visual representation of the luggage expansion feature, increasing capacity by up to 25%.

5. Attaching the Duffel Bag

The duffel bag features a sleeve on its back that allows it to slide over the telescoping handle of any of the suitcases, providing convenient hands-free transport.



Image: The duffel bag conveniently fixed onto the retractable luggage handle.

Maintenance

1. Cleaning

- For the hardside suitcases, wipe the exterior with a soft, damp cloth and mild soap. Avoid abrasive cleaners.
- For the duffel and toiletry bags, spot clean with a damp cloth and mild detergent. Air dry thoroughly.

2. Storage

- Store the luggage set in a cool, dry place away from direct sunlight.
- The suitcases are designed to nest within each other for compact storage.

Troubleshooting

- **TSA Lock Issues:** If you forget your combination, you will need to reset it. Follow the instructions in the 'Setting Your TSA Combination Lock' section. If the lock mechanism is jammed, ensure no foreign objects are obstructing the zippers.
- **Stuck Telescoping Handle:** Ensure no items inside the luggage are pressing against the handle mechanism. Gently pull and push while pressing the release button.
- **Wheel Performance:** If wheels are not spinning smoothly, check for debris or hair caught in the wheel mechanism. Clean as necessary. If a wheel is damaged, utilize the detachable feature for replacement.

Specifications

- **Product Dimensions:** 19 x 12 x 28 inches
- **Item Weight:** 20 pounds
- **Department:** Unisex
- **ASIN:** B0G5YMHL1Z
- **Item Model Number:** TR013-New
- **Material:** PC Hardside
- **Wheel Type:** 360-degree Spinner Wheels (Detachable)

- **Lock Type:** TSA-approved Combination Lock

Size Reference



Image: Detailed size reference for each suitcase in the set, including dimensions, capacity, weight, and recommended travel duration.

Official Product Videos

Joyway Hardside Luggage Set Overview

Video: This video provides a comprehensive overview of the Joyway Hardside Luggage Set, highlighting its key features, including the spinner wheels and TSA lock functionality. (Source: AceJoyway)

Joyway PC Hardside Luggage Sets with Front Pocket

Video: This video showcases the innovative front pocket design of the PC Hardside Luggage Sets, demonstrating its convenience for accessing travel essentials. (Source: VICTORIA TOURIST)

Warranty & Support

For warranty information, product support, or any inquiries not covered in this manual, please refer to the contact information provided with your purchase or visit the official Joyway website. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question