

Philips S9000/89

Philips Rechargeable Shaver 6900 S9000/89 User Manual

Wet & Dry Electric Shaver

1. INTRODUCTION

Thank you for choosing the Philips Rechargeable Shaver 6900 S9000/89. This electric shaver is designed to provide a close and comfortable shave, whether wet or dry. It features advanced technology for skin protection and efficient hair removal. Please read this manual carefully before using the appliance and save it for future reference.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- This appliance is waterproof and suitable for use in the bath or shower. For safety reasons, the shaver can only be used cordlessly.
- Do not use the appliance if it is damaged.
- Keep the charging adapter dry. Do not handle the adapter with wet hands.
- Do not immerse the charging stand or power cord in water.
- This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Only use the original charging adapter provided with the appliance.

3. PACKAGE CONTENTS

Carefully unpack your Philips Shaver 6900 S9000/89 and check that all items are present and in good condition.

- Philips Rechargeable Shaver 6900 S9000/89

- Travel Case
- Power Cord
- Shaver Cleaning Station
- Cleaning Solution Refills (2x)



Image: The Philips Shaver 6900 S9000/89, accompanied by its travel case, cleaning station, and two cleaning solution refills, as included in the package.

4. PRODUCT OVERVIEW

The Philips Shaver 6900 S9000/89 is equipped with advanced features for a superior shaving experience.

- **SteelPrecision Blades:** With up to 150,000 cutting actions per minute, these blades ensure an exceptionally close shave.
- **SenseIQ Technology:** An intelligent sensor reads facial hair density 500 times per second and automatically adapts cutting power for an effortless and gentle shave.
- **ComfortGlide Rings:** Shaving heads are surrounded by a special protective coating with skin gliding properties to shield your face from irritation.
- **360-Degree Contour Heads:** Fully flexible heads pivot 360 degrees to follow your facial contours for optimal skin contact and a comfortable shave.

- **Pop-up Trimmer:** Integrated for precise trimming of sideburns and mustaches.

**PRECISION CARE, MADE
PERSONAL**

Intelligent technology that adapts to you every day



Image: A detailed diagram highlighting the key features of the Philips Shaver 6900, including its 360-degree contour heads, SteelPrecision blades, and SenselQ technology.

PHILIPS

NORELCO

Shaver 6900

360° Contour heads
Fully flexible heads maintain skin contact for a close, skin-friendly shave.

SteelPrecision Blades
45 self-sharpening blades
90,000 cutting actions per minute

SenseIQ technology

Includes:

- Smart Shaver with Pop-up Trimmer
- Travel Case
- Shaver Cleaning Station + 3 Refills

Shave & Flex
1h charging 60 min runtime

Image: A close-up view of the rotary shaving heads of the Philips Shaver 6900, showing the intricate blade design.

5. SETUP

5.1 Charging the Shaver

Before first use, or when the battery indicator shows low charge, fully charge your shaver.

1. Ensure the shaver is dry before charging.
2. Connect the power cord to the charging stand and plug the adapter into a wall outlet.
3. Place the shaver in the charging stand. The battery indicator will show charging progress.
4. A full charge takes approximately 1 hour and provides up to 60 minutes of shaving time. A 5-minute quick charge provides enough power for one shave.



Image: The Philips Shaver 6900 S9000/89 positioned on its dedicated charging stand, indicating it is ready for charging.

6. OPERATING THE SHAVER

6.1 Dry Shaving

For a quick and convenient shave, use the shaver on dry skin.

1. Press the on/off button to switch on the shaver.
2. Move the shaving heads in small, circular movements over your skin.
3. Stretch your skin with your free hand to make the hairs stand upright.

6.2 Wet Shaving

For a refreshing shave, use the shaver with water, shaving foam, or gel.

1. Wet your face with water.
2. Apply shaving foam or gel to your skin.
3. Press the on/off button to switch on the shaver.
4. Move the shaving heads in small, circular movements over your skin.

5. Rinse the shaving heads under warm water during shaving to prevent clogging.

6.3 Using the Pop-up Trimmer

The integrated pop-up trimmer is ideal for shaping sideburns and mustaches.

1. Slide the trimmer release button upwards to activate the pop-up trimmer.
2. Hold the trimmer at a right angle to your skin and move it downwards with light pressure.
3. When finished, push the trimmer back into its closed position.



Image: A man demonstrating the use of the Philips Shaver 6900 S9000/89 for a close shave.




Image: A close-up view of the rotary shaving heads of the Philips Shaver 6900, showing the intricate blade design.

7. MAINTENANCE

7.1 Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene.

1. **Quick Clean:** After each shave, rinse the shaving unit under warm running water.
2. **Thorough Clean:** Once a week, detach the shaving head unit and rinse both the unit and the hair chamber thoroughly under warm running water. Allow all parts to air dry.
3. **Cleaning Station:** For a more comprehensive clean, place the shaver in the cleaning station as per its instructions. The cleaning station cleans, lubricates, and dries your shaver.



Image: The Philips Shaver 6900 S9000/89 being rinsed under running water, demonstrating its waterproof design for easy cleaning.

7.2 Replacing Shaving Heads

For best shaving results, replace the shaving heads every 12 months. Replacement heads are available from Philips retailers or online.

1. Switch off the shaver and disconnect it from the power outlet.
2. Pull the shaving head unit upwards to detach it from the shaver body.
3. Remove the retaining ring by turning it counter-clockwise.
4. Remove the old shaving heads and insert the new ones, ensuring they click into place.
5. Place the retaining ring back and turn it clockwise to secure.
6. Reattach the shaving head unit to the shaver body.

8. TROUBLESHOOTING

If you encounter issues with your shaver, refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Shaver does not switch on.	Battery is empty.	Charge the shaver for at least 5 minutes.
Shaver does not charge.	Power cord or adapter is not properly connected.	Check connections. Ensure the outlet is working.
Poor shaving performance.	Shaving heads are dirty or worn out.	Clean the shaving heads thoroughly. Replace shaving heads if they are older than 12 months.
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure gentle, circular movements. Try wet shaving with foam/gel. Allow skin to adapt to new shaver.

9. SPECIFICATIONS

- **Model Number:** S9000/89
- **Power Source:** Battery Powered (Rechargeable Li-ion)
- **Battery Average Life:** 60 minutes (1-hour charge)
- **Quick Charge:** 5 minutes for one shave
- **Head Type:** Rotary
- **Number of Blades:** 2 (Dual SteelPrecision)
- **Blade Material:** Stainless Steel
- **Features:** Wet & Dry use, Waterproof, SenseIQ Technology, ComfortGlide Rings, Pop-up Trimmer
- **Item Weight:** 9.42 ounces
- **Color:** Gray

10. WARRANTY AND SUPPORT

Philips offers a manufacturer's warranty for this product. Please refer to the warranty card included in your package for specific terms and conditions. For product support, replacement parts, or further assistance, please visit the official Philips website or contact Philips customer service in your region. Keep your proof of purchase for warranty claims.